

Fig. 2-78



4. Insert a compression gauge into the spark plug hole and fully open the throttle valve. While cranking the engine, measure the compression pressure.

Compression pressure

(at 250 rpm):

STD More than 10.5 kg/cm²
(149 psi)

Limit 8.0 kg/cm²
(114 psi)

**Pressure difference between each
cylinder:** Less than 1.0 kg/cm²
(14 psi)

— Note —

Always use a fully charged battery.