

		FM 6-5e Version: 02.11.2016	Maintenance plan for braiding machines Legend for the braiding machine maintenance plan				
Maintenance	Requirements	Check interval	Check / Clean / Lubricate		Oil/Grease		Documentation
Maintenance	schedule	frequency	check	Brand/Article	oil/grease	Photo	Comments documentation
W 1	Rigger	at each setup setup also during setup	Bobbin carrier:	Check thread guide eyelets (3) and sleeve (1) for damage and fit, latch OK (metal clip) Latch OK (metal clip)?			Via maintenance plan
			Base plate:	Check rocker arm function parallel to base plate, (base plate center aligned with take-off)			
			Spindle:	correct size, not bent/damaged, centered in the base plate			
			Track:	check for foreign objects and damage			
			Gear unit:	clean removed gears, grease the new ones	Metol Chassis Grease LBZ		
	Maintenance	Each loading	Braiding spindles	13 Check the thread guide eyelets (3) and the sleeve (1) that they are not damaged and are well fitted			Maintenance plan sheet
				7 Latch OK (metal clip)?			
			Spindle carrier plate:	8 Parallel to the base plate, ring centered in alignment with the trigger			
			Rod:	11 Correct size, not bent/damaged, centered in the square bar			
			track:	Check for foreign objects and damage			
			mechanism	Clean the removed gears, grease the new gears again			
W 2	Rigger	1x per week	Bobbin carrier:	Check locking bolt and cotter pin (undamaged, straight) Check rocker arm and cotter pin (undamaged, straight) Braiding bobbin bearing sleeve wear (locking bolt does not engage in bobbin travel) Check bobbin carrier foot (degree of wear without influence on running properties)			in the machine maintenance plan
			Track:	clean thoroughly, check for damage	B 220 B 220		
			Wing wheels:	oil between the wing wheels oil on the wing wheels oil in and under plate on wing wheel nut			
	Maintenance	1x/week	Braiding spindle:	7 Check the pin and locking pin (undamaged, straight) 12 Check the rocker arm and pin (undamaged, straight) 4 Wear of braiding bobbin sleeves (the locking pin does not engage) 8 Check the spindle foot (not in the bobbin path) (degree of wear without influence on operating properties)			Maintenance plan sheet
			Mechanism:	Clean thoroughly, check for damage. Oil between the wheels			
			Wing wheel	Oil on the turbines, under the plates and the wheel nuts			
W 3		1x/month	Sensor 1 thread presence	Test the function of sensor 1, thread presence Test the function of sensor 1 thread presence			in the machine maintenance plan
			Sensor 2 thread presence	Test the function of sensor 2, thread presence Test the function of sensor 2 bobbin presence			Cut a thread and check that the machine stops Maintenance plan sheet
W 4	Maintenance	1x/month monthly	Take-off: Take-off system	Check rollers for function and wear function and wear of the take-off rollers	Check the		in the machine maintenance plan Maintenance plan sheet
W 5	Maintenance	2 times/year 2 times/year	Bobbin carrier:	Grease sliding rods	Metol Chassis Grease LBZ		in the machine maintenance plan Maintenance plan sheet
	Maintenance		Braiding spindle	Grease the sliding rods			
W 6	Main- tenance	1x per year	Tower gear unit:	check, grease or top up oil if necessary check, retighten if necessary	ARAL Degol BG 150		in the machine maintenance plan
			Wing wheels:	check rollers for function and wear			
			Take-off:	Remove rocker arm springs and oil	ARAL Degol B 220		maintenance plan machine
	Maintenance	1x/year	Bobbin carrier:	Check the grease or oil level, top up if necessary			
			Gear box:	Check, retighten if necessary			
			Wing wheel	Check the function and wear of the rollers.			
			Take-off system	1 Remove and oil the rocker arm springs			
			Braiding spindle				
W 7	Main- tenance	every 2 years Every 2 years	Base frame:	Perform oil change	ARAL Degol BG 150		in the machine maintenance plan maintenance machine
			Tower:	Perform oil change	ARAL Degol BG 150		
			lower chassis	Perform the oil change			
			Tower:	Perform the oil change			

	FM 6-5e Version: 02.11.2016	Maintenance plan for braiding machines	
		Photos for the braiding machine maintenance legend	

Braiding bobbin carrier construction and mair

Construction and maintenance of braiding spindles

Remove and oil the rocker arm springs

Removal and lubrication of the rocker arm springs