True Image for CA44
Switch Real / Upmix Front
2021 11 10
ggm

Left Front (NoCfIn)

Left Front (WithCfIn)

Right Front (NoCfIn)

Right Front (WithCfIn)

Centre Frontt (NoCfIn)

Centre Frontt (WithCfIn)

0   1   0   1   0   1

Left Front

Right Front

Centre Front

IF
input signal does not contain Cf
AND
an output has Speaker Role = Cf
THEN 0
ELSE 1