

How to spot faulty shock absorbers.




Wheels bounce




Steering vibrates




Car body sways




Suspension bottoms out



Car 'dives' during braking



Poor cornering stability



High susceptibility to side winds





Oil on the shock absorber (a fine film of oil is needed for self-lubrication of the piston rod)




Uneven tyre wear 1. Tyre pressure too low

- 2. Tyre pressure too high





Worn-out ball joints



Worn-out rubber-metal attachments

www.bilstein.de • 02333 791-4444

