

Kayıt Düğmesi  
Yedek Düğme  
U3 SIM800\_RX  
U3 SIM800\_TX  
U4 Nextion\_RX  
U4 Nextion\_TX  
Pil Şarj oluyor

|   |        |  |        |           |
|---|--------|--|--------|-----------|
| X | 3V3    |  | GND    | X         |
| X | EN     |  | GPIO23 | VSPI_MOSI |
| X | VP     |  | GPIO22 | I2C_SCL   |
| X | VN     |  | GPIO1  | U0_TX     |
| X | GPIO34 |  | GPIO3  | U0_RX     |
| X | GPIO35 |  | GPIO21 | I2C_SDA   |
| X | GPIO32 |  | GND    | X         |
| X | GPIO33 |  | GPIO19 | VSPI_MISO |
| X | GPIO25 |  | GPIO18 | VSPI_SCK  |
| X | GPIO26 |  | GPIO5  | VSPI_SS   |
| X | GPIO27 |  | GPIO17 | U2_TX     |
| X | GPIO14 |  | GPIO16 | U2_RX     |
| X | GPIO12 |  | GPIO4  | U1_RX     |
| X | GND    |  | GPIO0  | X         |
| X | GPIO13 |  | GPIO2  | U1_TX     |
|   | GPIO9  |  | GPIO15 | X         |
|   | GPIO10 |  | GPIO8  |           |
|   | GPIO11 |  | GPIO7  |           |
| X | 5V     |  | GPIO6  |           |

Pil Seviye (Analog)

NEXTION EXT INT