NXT Ultrasonic Sensor

Non-Visible component

Category	Requires	Version
LEGO® MINDSTORMS® > NXT	API 19, Android 4.4 - 4.4.4 KitKat	1

Overview

A component that provides a high-level interface to an ultrasonic sensor on a LEGO MINDSTORMS NXT robot.

Events

Above Range

Distance has gone above the range.

Below Range

Distance has gone below the range.

Within Range

Distance has gone within the range.

Methods

Get Distance

Returns: Number

Returns the current distance in centimeters as a value between 0 and 254, or -1 if the distance can not be read.

Properties

Above Range Event Enabled

```
Boolean Default: False — Read Write - Designer Blocks
```

Whether the AboveRange event should fire when the distance goes above the TopOfRange.

Below Range Event Enabled

```
Boolean Default: False — Read Write - Designer Blocks
```

Whether the BelowRange event should fire when the distance goes below the BottomOfRange.

Bluetooth Client

```
Component — Write - Designer
```

The BluetoothClient component that should be used for communication.

Bottom Of Range

```
Number Default: 30 — Read Write - Designer Blocks
```

The bottom of the range used for the BelowRange, WithinRange, and AboveRange events.

Sensor Port

The sensor port that the sensor is connected to.

Top Of Range

The top of the range used for the BelowRange, WithinRange, and AboveRange events.

Within Range Event Enabled

Whether the WithinRange event should fire when the distance goes between the BottomOfRange and the TopOfRange.

Last update: January 26, 2020