

# **HIGHLIGHTS**

This section of the manual contains the following major topics:

38.1	Introduction	38-2
38.2	DMA Registers	38-4
38.3	DMA Block Diagram	38-12
38.4	DMA Data Transfer	38-13
38.5	DMA Set Up	38-15
38.6	DMA Operating Modes	38-21
38.7	Starting DMA Transfer	38-45
38.8	DMA Channel Arbitration and Overruns	38-47
38.9	Debugging Support	38-49
38.10	Data Write Collisions	38-49
38.11	Operation in Power-Saving Modes	38-50
38.12	Register Map	38-51
38.13	Related Application Notes	38-53
38.14	Revision History	38-54

**Note:** This family reference manual section is meant to serve as a complement to device data sheets. Depending on the device variant, this manual section may not apply to

all dsPIC33F/PIC24H devices.

Please consult the note at the beginning of the "Direct Memory Access (DMA)" chapter in the current device data sheet to check whether this document supports the device you are using.

Device data sheets and family reference manual sections are available for download from the Microchip Worldwide Web site at: http://www.microchip.com

#### 38.1 INTRODUCTION

The Direct Memory Access (DMA) controller is an important subsystem in Microchip's high-performance 16-bit Digital Signal Controller (DSC) families. This subsystem facilitates the transfer of data between the CPU and its peripheral without CPU assistance. The dsPIC33F/PIC24H DMA controller is optimized for high-performance, real-time, embedded applications, where determinism and system latency are priorities.

The DMA controller transfers data between peripheral data registers and data space SRAM. The dsPIC33F/PIC24H DMA subsystem uses Dual Port SRAM (DPSRAM) memory and register structures that allow the DMA to operate across its own, independent address and data buses with no impact on CPU operation. This architecture eliminates the need for cycle stealing, which halts the CPU when a higher priority DMA transfer is requested. Both the CPU and DMA controller can write and read to/from addresses within data space without interference, such as CPU stalls, resulting in maximized, real-time performance. Alternately, DMA operation and data transfer to/from the memory and peripherals are not impacted by CPU processing. For example, when a Run-Time Self-Programming (RTSP) operation is performed, the CPU does not execute any instructions until RTSP is finished. This condition, however, does not impact data transfer to/from memory and the peripherals. Figure 38-1 illustrates the DMA setup.

DPSRAM

Peripheral

DMA

CPU

Figure 38-1: DMA Controller

The DMA controller supports eight independent channels. Each channel can be configured for transfers to/from selected peripherals. Peripherals supported by the DMA controller include:

- Enhanced Controller Area Network (ECAN™) technology
- Data Converter Interface (DCI)
- 10-bit/12-bit Analog-to-Digital Converter (ADC)
- · Serial Peripheral Interface (SPI)
- Universal Asynchronous Receiver Transmitter (UART)
- · Input Capture
- · Output Compare
- Digital-to-Analog Converter (DAC)
- · Parallel Master Port (PMP)

In addition, DMA transfers can be triggered by timers as well as external interrupts. Each DMA channel is unidirectional. Two DMA channels must be allocated to read and write to a peripheral. Should more than one channel receive a request to transfer data, a simple fixed priority scheme, based on channel number, dictates which channel completes the transfer and which channel, or channels, are left pending. Each DMA channel moves a block of up to 1024 data elements, after which it generates an interrupt to the CPU to indicate that the block is available for processing.

The DMA controller provides these functional capabilities:

- · Eight DMA channels
- · Register Indirect with Post-Increment Addressing mode
- · Register Indirect without Post-Increment Addressing mode
- · Peripheral Indirect Addressing mode (peripheral generates destination address)
- CPU interrupt after half or full block transfer complete
- · Byte or word transfers
- · Fixed priority channel arbitration
- Manual (software) or Automatic (peripheral DMA requests) transfer initiation
- · One-shot or Auto-repeat block transfer modes
- Ping-Pong mode (automatic switch between two DPSRAM start addresses after each block transfer completes)
- DMA request for each channel can be selected from any supported interrupt source
- Debug support features

#### 38.2 DMA REGISTERS

Each DMA channel has a set of six status and control registers.

#### DMAxCON: DMA Channel x Control Register

This register configures the corresponding DMA channel by enabling/disabling the channel, specifying data transfer size, direction and block interrupt method, and selecting DMA Channel Addressing mode, Operating mode and Null Data Write mode.

#### DMAxREQ: DMA Channel x IRQ Select Register

This register associates the DMA channel with a specific DMA capable peripheral by assigning the peripheral IRQ to the DMA channel.

#### DMAxSTA: DMA Channel x DPSRAM Start Address Offset Register A

This register specifies the primary start address offset from the DMA DPSRAM base address of the data block to be transferred by DMA channel x to or from the DPSRAM. Reads of this register return the value of the latest DPSRAM transfer address offset. Writes to this register while the channel x is enabled (that is, active) may result in unpredictable behavior and should be avoided.

#### DMAxSTB: DMA Channel x DPSRAM Start Address Offset Register B

This register specifies the secondary start address offset from the DMA DPSRAM base address of the data block to be transferred by DMA channel x to or from the DPSRAM. Reads of this register return the value of the latest DPSRAM transfer address offset. Writes to this register while the channel x is enabled (that is, active) may result in unpredictable behavior and should be avoided.

#### DMAxPAD: DMA Channel x Peripheral Address Register

This read/write register contains the static address of the peripheral data register. Writes to this register while the corresponding DMA channel is enabled (that is, active) may result in unpredictable behavior and should be avoided.

#### DMAxCNT: DMA Channel x Transfer Count Register

This register contains the transfer count. DMAxCNT + 1 represents the number of DMA requests the channel must service before the data block transfer is considered complete. That is, a DMAxCNT value of '0' will transfer one element. The value of the DMAxCNT register is independent of the transfer data size (SIZE bit in the DMAxCON register). Writes to this register while the corresponding DMA channel is enabled (that is, active) may result in unpredictable behavior and should be avoided.

In addition to the individual DMA channel registers, the DMA Controller has these three DMA status registers.

#### DSADR: Most Recent DMA DPSRAM Address Register

This 16-bit, read-only, status register is common to all DMA channels. It captures the address of the most recent DPSRAM access (read or write). It is cleared at Reset and, therefore, contains the value '0x0000' if read prior to any DMA activity. This register is accessible at any time but is primarily intended as a debug aid.

#### DMACS0: DMA Controller Status Register 0

This 16-bit, read-only, status register contains the DPSRAM and Peripheral Write Collision flags, XWCOLx and PWCOLx, respectively. For more information, refer to **38.10** "Data Write Collisions".

#### • DMACS1: DMA Controller Status Register 1

This 16-bit, read-only, status register indicates which DMA channel was most recently active and provides the Ping-Pong mode status of each DMA channel by indicating which DMA Channel x DPSRAM Start Address Offset register, DMAxSTA or DMAxSTB, is selected.

#### Register 38-1: DMAxCON: DMA Channel x Control Register

R/W-0	R/W-0	R/W-0	R/W-0	R/W-0	U-0	U-0	U-0
CHEN	SIZE	DIR	HALF	NULLW	_	_	_
bit 15							bit 8

U-0	U-0	R/W-0	R/W-0	U-0	U-0	R/W-0	R/W-0
_	_	AMODI	E<1:0>	_	_	MODE<1:0>	
bit 7							bit 0

Legend:			
R = Readable bit	W = Writable bit	U = Unimplemented bit	, read as '0'
-n = Value at POR	'1' = Bit is set	'0' = Bit is cleared	x = Bit is unknown

bit 15 CHEN: Channel Enable bit 1 = Channel enabled 0 = Channel disabled bit 14 SIZE: Data Transfer Size bit 1 = Byte 0 = Word bit 13 **DIR:** Transfer Direction bit (source/destination bus select) 1 = Read from DPSRAM address, write to peripheral address 0 = Read from Peripheral address, write to DPSRAM address bit 12 HALF: Block Transfer Interrupt Select bit 1 = Initiate interrupt when half of the data has been moved 0 = Initiate interrupt when all of the data has been moved bit 11 **NULLW: Null Data Peripheral Write Mode Select bit** 1 = Null data write to peripheral in addition to DPSRAM write (DIR bit must also be clear) 0 = Normal operation bit 10-6 Unimplemented: Read as '0' bit 5-4 AMODE<1:0>: DMA Channel Addressing Mode Select bits 11 = Reserved 10 = Peripheral Indirect Addressing mode 01 = Register Indirect without Post-Increment mode 00 = Register Indirect with Post-Increment mode bit 3-2 Unimplemented: Read as '0' bit 1-0 MODE<1:0>: DMA Channel Operating Mode Select bits 11 = One-shot, Ping-Pong modes enabled (one block transfer from/to each DMA RAM buffer) 10 = Continuous, Ping-Pong modes enabled 01 = One-shot, Ping-Pong modes disabled

00 = Continuous, Ping-Pong modes disabled

# dsPIC33F/PIC24H Family Reference Manual

#### Register 38-2: DMAxREQ: DMA Channel x IRQ Select Register

R/HC-0	U-0						
FORCE <sup>(1)</sup>	_	_	_	_	_	_	_
bit 15							bit 8

U-0	R/W-0	R/W-0	R/W-0	R/W-0	R/W-0	R/W-0	R/W-0
_				IRQSEL<6:0	>		
bit 7							bit 0

 Legend:
 HC = Cleared by Hardware

 R = Readable bit
 W = Writable bit
 U = Unimplemented bit, read as '0'

 -n = Value at POR
 '1' = Bit is set
 '0' = Bit is cleared
 x = Bit is unknown

bit 15 FORCE: Force DMA Transfer bit<sup>(1)</sup>

1 = Force a single DMA transfer (manual mode)

0 = Automatic DMA transfer initiation by DMA Request

bit 14-7 **Unimplemented:** Read as '0'

bit 6-0 IRQSEL<6:0>: DMA Peripheral IRQ Number Select bits

1001111 = DAC1 Left Data Output (DAC1)

1001110 = DAC1 Right Data Output (DAC1)

1000110 = TX Data Request (ECAN1)

0111100 = CODEC Transfer Done (DCI)

0101101 = PMP Master Data Transfer (PMP)

0100010 = RX Data Ready (ECAN1)

0100001 = SPI2 Transfer Done (SPI2)

0011111 = UART2 Transmitter (UART2TX)

0011110 = UART2 Receiver (UART2RX)

0001101 = ADC1 Convert Done (ADC1)

0001100 = UART1 Transmitter (UART1TX)

0001011 = UART1 Receiver (UART1RX)

0001010 = Transfer Done (SPI1)

0001000 = Timer3 (TMR3)

0000111 = Timer2 (TMR2)

0000110 = Output Compare 2 (OC2)

0000101 = Input Capture 2 (IC2)

0000010 = Output Compare 1 (OC1)

0000001 = Input Capture 1 (IC1)

0000000 = External Interrupt 0 (INT0)

**Note 1:** The FORCE bit cannot be cleared by the user. The FORCE bit is cleared by hardware when the forced DMA transfer is complete.

#### Register 38-3: DMAxSTA: DMA Channel x DPSRAM Start Address Offset Register A

R/W-0	R/W-0	R/W-0	R/W-0	R/W-0	R/W-0	R/W-0	R/W-0			
	STA<15:8>									
bit 15										

R/W-0	R/W-0	R/W-0	R/W-0	R/W-0	R/W-0	R/W-0	R/W-0			
	STA<7:0>									
bit 7										

Legend:

R = Readable bit W = Writable bit U = Unimplemented bit, read as '0'

-n = Value at POR '1' = Bit is set '0' = Bit is cleared x = Bit is unknown

bit 15-0 STA<15:0>: Primary DPSRAM Start Address Offset bits (source or destination)

### Register 38-4: DMAxSTB: DMA Channel x DPSRAM Start Address Offset Register B

R/W-0	R/W-0	R/W-0	R/W-0	R/W-0	R/W-0	R/W-0	R/W-0		
			STB<	15:8>					
bit 15									

R/W-0	R/W-0	R/W-0	R/W-0	R/W-0	R/W-0	R/W-0	R/W-0			
	STB<7:0>									
bit 7										

Legend:

R = Readable bit W = Writable bit U = Unimplemented bit, read as '0'

-n = Value at POR  $(1)^2$  = Bit is set  $(0)^2$  = Bit is cleared  $(0)^2$  = Bit is unknown

bit 15-0 STB<15:0>: Secondary DPSRAM Start Address Offset bits (source or destination)

## Register 38-5: DMAxPAD: DMA Channel x Peripheral Address Register

R/W-0	R/W-0	R/W-0	R/W-0	R/W-0	R/W-0	R/W-0	R/W-0			
	PAD<15:8>									
bit 15 bit										

R/W-0	R/W-0	R/W-0	R/W-0	R/W-0	R/W-0	R/W-0	R/W-0		
PAD<7:0>									
bit 7									

Legend:

R = Readable bit W = Writable bit U = Unimplemented bit, read as '0'

-n = Value at POR '1' = Bit is set '0' = Bit is cleared x = Bit is unknown

bit 15-0 PAD<15:0>: Peripheral Address Register bits

# dsPIC33F/PIC24H Family Reference Manual

### Register 38-6: DMAxCNT: DMA Channel x Transfer Count Register

R/W-0	R/W-0	R/W-0	R/W-0	R/W-0	R/W-0	R/W-0	R/W-0
_	_	_	_	_	_	CNT-	<9:8>
bit 15							bit 8

| R/W-0 |
|-------|-------|-------|-------|-------|-------|-------|-------|
|       |       |       | CNT-  | <7:0> |       |       |       |
| bit 7 |       |       |       |       |       |       | bit 0 |

Legend:

R = Readable bit W = Writable bit U = Unimplemented bit, read as '0'

-n = Value at POR '1' = Bit is set '0' = Bit is cleared x = Bit is unknown

bit 15-10 Reserved

bit 9-0 CNT<9:0>: DMA Transfer Count Register bits

#### Register 38-7: DSADR: Most Recent DMA DPSRAM Address Register

R-0	R-0	R-0	R-0	R-0	R-0	R-0	R-0
			DSADF	R<15:8>			
bit 15							bit 8

R-0	R-0	R-0	R-0	R-0	R-0	R-0	R-0
			DSAD	R<7:0>			
bit 7							bit 0

Legend:

R = Readable bit W = Writable bit U = Unimplemented bit, read as '0'

-n = Value at POR '1' = Bit is set '0' = Bit is cleared x = Bit is unknown

bit 15-0 DSADR<15:0>: Most Recent DMA DPSRAM Address Accessed by DMA bits

# Register 38-8: DMACS0: DMA Controller Status Register 0

| R-0    |
|--------|--------|--------|--------|--------|--------|--------|--------|
| PWCOL7 | PWCOL6 | PWCOL5 | PWCOL4 | PWCOL3 | PWCOL2 | PWCOL1 | PWCOL0 |
| bit 15 |        |        |        |        |        |        | bit 8  |

| R-0    |
|--------|--------|--------|--------|--------|--------|--------|--------|
| XWCOL7 | XWCOL6 | XWCOL5 | XWCOL4 | XWCOL3 | XWCOL2 | XWCOL1 | XWCOL0 |
| bit 7  |        |        |        |        |        |        | bit 0  |

Legend:			
R = Readable bit	W = Writable bit	U = Unimplemented bit	, read as '0'
-n = Value at POR	'1' = Bit is set	'0' = Bit is cleared	x = Bit is unknown

11 Value at 1	
bit 15	PWCOL7: Channel 7 Deripheral Write Collision Flog hit
DIL 13	<ul> <li>PWCOL7: Channel 7 Peripheral Write Collision Flag bit</li> <li>1 = Write collision detected</li> <li>0 = No write collision detected</li> </ul>
bit 14	<b>PWCOL6:</b> Channel 6 Peripheral Write Collision Flag bit 1 = Write collision detected 0 = No write collision detected
bit 13	<b>PWCOL5:</b> Channel 5 Peripheral Write Collision Flag bit 1 = Write collision detected 0 = No write collision detected
bit 12	<b>PWCOL4:</b> Channel 4 Peripheral Write Collision Flag bit 1 = Write collision detected 0 = No write collision detected
bit 11	<b>PWCOL3:</b> Channel 3 Peripheral Write Collision Flag bit 1 = Write collision detected 0 = No write collision detected
bit 10	<b>PWCOL2:</b> Channel 2 Peripheral Write Collision Flag bit 1 = Write collision detected 0 = No write collision detected
bit 9	<b>PWCOL1:</b> Channel 1 Peripheral Write Collision Flag bit 1 = Write collision detected 0 = No write collision detected
bit 8	<b>PWCOL0:</b> Channel 0 Peripheral Write Collision Flag bit 1 = Write collision detected 0 = No write collision detected
bit 7	XWCOL7: Channel 7 DPSRAM Write Collision Flag bit  1 = Write collision detected  0 = No write collision detected
bit 6	XWCOL6: Channel 6 DPSRAM Write Collision Flag bit  1 = Write collision detected  0 = No write collision detected
bit 5	XWCOL5: Channel 5 DPSRAM Write Collision Flag bit  1 = Write collision detected  0 = No write collision detected
bit 4	XWCOL4: Channel 4 DPSRAM Write Collision Flag bit  1 = Write collision detected  0 = No write collision detected

# dsPIC33F/PIC24H Family Reference Manual

### Register 38-8: DMACS0: DMA Controller Status Register 0 (Continued)

bit 3 XWCOL3: Channel 3 DPSRAM Write Collision Flag bit

1 = Write collision detected0 = No write collision detected

bit 2

XWCOL2: Channel 2 DPSRAM Write Collision Flag bit

1 = Write collision detected0 = No write collision detected

bit 1 XWCOL1: Channel 1 DPSRAM Write Collision Flag bit

1 = Write collision detected0 = No write collision detected

bit 0 XWCOL0: Channel 0 DPSRAM Write Collision Flag bit

1 = Write collision detected0 = No write collision detected

#### Register 38-9: DMACS1: DMA Controller Status Register 1

U-0	U-0	U-0	U-0	R-1	R-1	R-1	R-1
_	_	_	_		LSTC	H<3:0>	
bit 15							bit 8

| R-0   |
|-------|-------|-------|-------|-------|-------|-------|-------|
| PPST7 | PPST6 | PPST5 | PPST4 | PPST3 | PPST2 | PPST1 | PPST0 |
| bit 7 |       |       |       |       |       |       | bit 0 |

Legend:

R = Readable bit W = Writable bit U = Unimplemented bit, read as '0'

-n = Value at POR '1' = Bit is set '0' = Bit is cleared x = Bit is unknown

bit 15-12 Unimplemented: Read as '0'

bit 11-8 LSTCH<3:0>: Last DMAC Channel Active bits

1111 = No DMA transfer has occurred since system reset

1110-1000 = Reserved

0111 = Last data transfer was by Channel 7

0110 = Last data transfer was by Channel 6 0101 = Last data transfer was by Channel 5

0100 = Last data transfer was by Channel 4

0011 = Last data transfer was by Channel 3

0010 = Last data transfer was by Channel 2 0001 = Last data transfer was by Channel 1

0000 = Last data transfer was by Channel 0

Set to '1111' at Reset. This field is accessible at any time but is primarily intended as a debugging aid.

bit 7 PPST7: Channel 7 Ping-Pong Mode Status Flag bit

1 = DMA7STB register selected0 = DMA7STA register selected

bit 6 PPST6: Channel 6 Ping-Pong Mode Status Flag bit

1 = DMA6STB register selected0 = DMA6STA register selected

bit 5 PPST5: Channel 5 Ping-Pong Mode Status Flag bit

1 = DMA5STB register selected0 = DMA5STA register selected

bit 4 PPST4: Channel 4 Ping-Pong Mode Status Flag bit

1 = DMA4STB register selected 0 = DMA4STA register selected

bit 3 PPST3: Channel 3 Ping-Pong Mode Status Flag bit

1 = DMA3STB register selected 0 = DMA3STA register selected

bit 2 PPST2: Channel 2 Ping-Pong Mode Status Flag bit

1 = DMA2STB register selected 0 = DMA2STA register selected

bit 1 PPST1: Channel 1 Ping-Pong Mode Status Flag bit

1 = DMA1STB register selected0 = DMA1STA register selected

bit 0 PPST0: Channel 0 Ping-Pong Mode Status Flag bit

1 = DMA0STB register selected0 = DMA0STA register selected


Note: This register is read-only.

#### 38.3 DMA BLOCK DIAGRAM

Figure 38-2 illustrates a block diagram that shows how the DMA integrates into the dsPIC33F/PIC24H internal architecture. The CPU communicates with conventional SRAM across the X-bus. It also communicates with Port 1 of the DPSRAM block across the same X-bus. The CPU communicates with the peripherals across a separate peripheral X-bus, which also resides within X data space.

The DMA channels communicate with Port 2 of the DPSRAM and the DMA port of each of the DMA-ready peripherals across a dedicated DMA bus.





Unlike other architectures, the dsPIC33F/PIC24H CPU is capable of a read and a write access within each CPU bus cycle. Similarly, the DMA can complete the transfer of a byte or word every bus cycle across its dedicated bus. This also ensures that all DMA transfers are not interrupted. That is, once the transfer has started, it will complete within the same cycle, irrespective of other channel activity.

The user application can designate any DMA-ready peripheral interrupt to be a DMA request, the term given to an IRQ when it is directed to the DMA. It is assumed, of course, that when a DMA channel is configured to respond to a particular interrupt as a DMA request, the corresponding CPU interrupt is disabled, otherwise a CPU interrupt will also be requested.

Each DMA channel can also be triggered manually through software. Setting the Force DMA Transfer bit (FORCE) in the DMA Channel x IRQ Select register (DMAxREQ) initiates a manual DMA request that is subject to the same arbitration as all interrupt based DMA requests (see 38.8 "DMA Channel Arbitration and Overruns").

### 38.4 DMA DATA TRANSFER

Figure 38-3 illustrates data transfer between a peripheral and DPSRAM.

- A. In Figure 38-3, DMA Channel 5 is configured to operate with DMA-ready Peripheral 1.
- B. When data is ready to be transferred from the peripheral, a DMA request is issued by the peripheral. The DMA request is arbitrated with any other coincident requests. If this channel has the highest priority, the transfer is completed during the next cycle. Otherwise, the DMA request remains pending until it becomes the highest priority.
- C. The DMA channel executes a data read from the designated peripheral address, which is user application defined within the active channel.
- D. The DMA channel writes the data to the designated DPSRAM address.

This example represents Register Indirect mode, where the DPSRAM address is designated within the DMA channel through the DMAxSTA or DMAxSTB registers. In Peripheral Indirect Addressing mode, the DPSRAM address is derived from the peripheral, not the active channel. For more information, refer to 38.6.6 "Peripheral Indirect Addressing Mode".

The entire DMA read and write transfer operation is accomplished uninterrupted in a single instruction cycle. During this entire process, DMA request remains latched in the DMA channel until the data transfer is complete.

The DMA channel concurrently monitors the DMA Channel x Transfer Counter register (DMAxCNT). When the transfer count reaches a user application specified limit, data transfer is considered complete and a CPU interrupt is asserted to alert the CPU to process the newly received data.

During the data transfer cycle, the DMA controller also continues to arbitrate pending or subsequent DMA requests to maximize throughput.

Figure 38-3: **DMA Data Transfer Example** Peripheral 1 configured for DMA Channel 5 **DMA Controller** DMA Ready DMA Ch DMA **DPSRAM** Peripheral 1 **SRAM** PORT 1 PORT 2 DMA SRAM X Bus DMA Data Space Bus CPU CPU Peripheral Data Space Bus Peripheral has data to transfer to DMA Channel 5 **DMA Controller DATA** DMA **SRAM DPSRAM** DMA PORT 1 PORT 2 CPU DMA DMA Request SRAM X Bus CPU DMA Channel 5 reads data from Peripheral 1 **DMA Controller DATA** DMA ರ **SRAM DPSRAM** PORT 1 PORT 2 CPU DMA **Data Read** SRAM X Bus CPU **Peripheral Address** DMA Channel 5 writes data to DPSRAM **DMA Controller** DMA Ready **DATA** DMA ಕ Peripheral 1 **SRAM** DMA PORT 1 PORT 2 DMA Data Write (DMA DS Bus) SRAM X Bus CPU **DPSRAM Address** 

#### 38.5 DMA SET UP

For DMA data transfer to function properly, the DMA channels and peripherals must be appropriately configured:

- DMA channels must be associated with peripherals (see 38.5.1 "DMA Channel to Peripheral Association Setup")
- Peripherals must be properly configured (see 38.5.2 "Peripheral Configuration Setup")
- DPSRAM data start addresses must be initialized (see 38.5.3 "Memory Address Initialization")
- Initializing DMA transfer count must be initialized (see 38.5.4 "DMA Transfer Count Setup")
- Appropriate addressing and operating modes must be selected (see 38.6 "DMA
   Operating Modes")

### 38.5.1 DMA Channel to Peripheral Association Setup

The DMA Channel needs to know which peripheral target address to read from or write to, and when to perform the same. This information is configured in the DMA Channel x Peripheral Address register (DMAxPAD) and DMA Channel x IRQ Select register (DMAxREQ), respectively.

Table 38-1 lists the values to be written to these registers to associate a particular peripheral with a given DMA channel.

Table 38-1: DMA Channel to Peripheral Associations

Peripheral to DMA Association	DMAxREQ Register IRQSEL<6:0> Bits	DMAxPAD Register Values to Read from Peripheral	DMAxPAD Register Values to Write to Peripheral
External Interrupt 0 (INT0)	0000000	_	_
Input Capture 1 (IC1)	0000001	0x0140 (IC1BUF)	_
Input Capture 2 (IC2)	0000101	0x0144 (IC2BUF)	_
Output Compare 1 Data – OC1	0000010	_	0x0182 (OC1R)
Output Compare 1 Secondary Data (OC1)	0000010	_	0x0180 (OC1RS)
Output Compare 2 Data (OC2)	0000110	_	0x0188 (OC2R)
Output Compare 2 Secondary Data (OC2)	0000110	_	0x0186 (OC2RS)
Timer2 (TMR2)	0000111	_	_
Timer3 (TMR3)	0001000	_	_
Transfer Done (SPI1)	0001010	0x0248 (SPI1BUF)	0x0248 (SPI1BUF)
Transfer Done (SPI2)	0100001	0x0268 (SPI2BUF)	0x0268 (SPI2BUF)
UART1 Receiver (UART1RX)	0001011	0x0226 (U1RXREG)	_
UART1 Transmitter (UART1TX)	0001100	_	0x0224 (U1TXREG)
UART2 Receiver (UART2RX)	0011110	0x0236 (U2RXREG)	_
UART2 Transmitter (UART2TX)	0011111	_	0x0234 (U2TXREG)
RX Data Ready (ECAN1)	0100010	0x0440 (C1RXD)	_
TX Data Request (ECAN1)	1000110	_	0x0442 (C1TXD)
CODEC Transfer Done (DCI)	0111100	0x0290 (RXBUF0)	0x0298 (TXBUF0)
ADC1 Convert Done (ADC1)	0001101	0x0300 (ADC1BUF0)	_
PMP Master Data Transfer (PMP)	0101101	0x0608 (PMDIN1)	0x0608 (PMDIN1)
DAC1 Right Data Transfer (DAC1)	1001110	_	0x03F6 (DAC1RDAT)
DAC1 Left Data Transfer (DAC1)	1001111	_	0x03F8 (DAC1LDAT)

# dsPIC33F/PIC24H Family Reference Manual

If two DMA channels select the same peripheral as the source of their DMA request, both channels receive the DMA request simultaneously. However, the highest priority channel executes its transfer first, leaving the other channel pending. This situation is common where a single DMA request is used to move data both to and from a peripheral (for example, SPI). Two DMA channels are used. One DMA channel is allocated for peripheral reads, and the other DMA channel is allocated for peripheral data writes. Both the DMA channels use the same DMA request.

If the DMAxPAD register is initialized to a value not listed in Table 38-1, DMA channel writes to this peripheral address will be ignored. DMA channel reads from this address will result in a read of '0'.

# 38.5.2 Peripheral Configuration Setup

The second step in the DMA setup process is to configure DMA-ready peripherals for DMA operation. Table 38-2 outlines the configuration requirements for DMA-ready peripherals.

Table 38-2: Configuration Considerations for DMA-ready Peripherals

DMA-ready Peripheral	Configuration Considerations
ECAN™ Module	ECAN buffers are allocated in the DMA RAM. The overall size of the CAN buffer area and FIFO in the DMA RAM is specified by the user, and must be defined through the DMA Buffer Size bits (DMABS<2:0>) in the ECAN FIFO Control register (C1FCTRL<15:13>). Sample code is shown in Example 38-9.
DCI	The DCI must be configured to generate an interrupt for every buffered data word by setting the Buffer Length Control bits (BLEN<1:0>) to '00' in the DCI Control 2 register (DCICON2<11:10>). The same DCI interrupt must be used as the request for two DMA channels to support RX and TX data transfers.  If the DCI module is operating as Master and only receiving data, the second DMA channel must be used to send dummy transmit data. Sample code is shown in Example 38-11.
10-bit/12-bit ADC	When the ADC is used with the DMA in Peripheral Indirect mode, the increment rate for the DMA Addresses bits (SMPI<3:0>) in the ADCx Control 2 register (ADCxCON2<5:2>), and the Number of DMA Buffer Locations per Analog Input bits (DMABL<2:0>) in the ADCx Control 4 register (ADCxCON4<2:0>) must be set properly. Also, the DMA Buffer Build mode bit (ADDMABM) in the ADCx Control 1 register (ADxCON1<12>) must be properly set for ADC address generation. For more information, refer to 38.6.6.1 "ADC Support for DMA Address Generation". Sample code is shown in Example 38-5 and Example 38-7.
SPI	If the SPI module is operating as master and only receiving data, the second DMA channel must be allocated and used to send dummy transmit data. Alternatively, a single DMA channel can be used in Null Data Write mode. For more information, refer to 38.6.11 "Null Data Write Mode". Sample code is shown in Example 38-12.
UART	The UART must be configured to generate interrupts for every character received or transmitted. For the UART receiver to generate an RX interrupt for each character received, the Receive Interrupt Mode Selection bits (URXISEL<1:0>) must be set to '00' or '01' in the Status and Control register (UxSTA<7:6>).  For the UART transmitter to generate a TX interrupt for each character transmitted, the Transmission Interrupt Mode Selection bits, UTXISEL0 and UTXISEL1, must be set to '0' in the UxSTA register. Sample code is shown in Example 38-10.
Input Capture	The Input Capture module must be configured to generate an interrupt for each capture event by setting the Number of Captures per Interrupt bits (ICI<1:0>) to '00' in the Input Capture Control register (ICxCON<6:5>). Sample code is shown in Example 38-4.
Output Compare	The Output Compare module requires no special configuration to work with DMA. Typically, however, the timer is used to provide the DMA request, and it needs to be properly configured. Sample code is shown in Example 38-3.

# Table 38-2: Configuration Considerations for DMA-ready Peripherals (Continued)

DMA-ready Peripheral	Configuration Considerations	
External Interrupt and Timers	Only External Interrupt 0, and Timer2 and Timer3 can be selected for DMA request. Although these peripherals do not support DMA transfer themselves, they can be used to trigger DMA transfers for other DMA-supported peripherals. For example, Timer2 can trigger DMA transactions for the Output Compare peripheral in PWM mode. Sample code is shown in Example 38-3.	
PMP	The PMP module must be configured as a master by setting the Parallel Port Mode Select bits (MODE<1:0>) to '10' or '11' in the Parallel Port Mode register (PMMODE<9:8>). Also, interrupts must be generated after each data transfer by setting the Interrupt Request Mode bits, IRQM<1:0> (PMMODE<14:13>) to '01'. For more information, refer to Section 35. "Parallel Master Port (PMP)" (DS70299).	
DAC	The DAC module must be configured to generate an interrupt when the DAC FIFO is empty. This is achieved by setting the Right Channel Type Interrupt bit (RITYPE) to '1', and/or setting the Left Channel Type Interrupt bit (LITYPE) to '1' in the DAC1 Status and Control register (DAC1STAT<10>). For code examples, refer to <b>Section 33. "Digital-to-Analog Converter (DAC)"</b> (DS70298).	

An error condition within a DMA enabled peripheral generally sets a status flag and generates an interrupt (if interrupts are enabled by the user application). When a peripheral is serviced by the CPU, the data interrupt handler is required to check for error flags and, if necessary, take the appropriate action. However, when a peripheral is serviced by the DMA channel, the DMA can only respond to data transfer requests and it is not aware of any subsequent error conditions. All error conditions in DMA compatible peripherals must have an associated interrupt enabled and be serviced by the user-defined Interrupt Service Routine (ISR), if such an interrupt is present in the peripheral.

Section 38. Direct Memory Access (DMA) (Part III)

### 38.5.3 Memory Address Initialization

The third DMA setup requirement is to allocate memory buffers within a specific memory area for DMA access. The location and size of this memory area depends on the dsPIC33F/PIC24H device. Refer to the "**Memory Organization**" chapter in the specific device data sheet for more information. Figure 38-4 illustrates a DMA memory area of 2 KB for dsPIC33F/PIC24H devices with 16 Kbytes of RAM.





Figure 38-4: Data Memory Map for dsPIC33F/PIC24H Devices with 16 Kbytes RAM

To operate properly, the DMA needs to know the DPSRAM address to read from or write to as an offset from the beginning of the DMA memory. This information is configured in the DMAxSTA and DMAxSTB register. Figure 38-5 illustrates an example of how the primary and secondary DMA Channel 4 buffers are set up on the dsPIC33FJ128MC804 device at address 0x4000 and 0x4010, respectively.


Figure 38-5: Primary and Secondary Buffer Allocation in DMA Memory



In Figure 38-5, you must be familiar with the memory layout for the device to hard code this information into the application. Also, you must use pointer arithmetic to access these buffers after the DMA transfer is complete. As a result, this implementation is difficult to port from one processor to another.

The MPLAB® C30 compiler simplifies DMA buffer initialization and access by providing built-in C language primitives for that purpose. For example, the code in Figure 38-6 allocates two buffers in the DMA memory and initializes the DMA channel to point to them.

Figure 38-6: Primary and Secondary DMA Buffer Allocation with MPLAB® IDE



**Note:** MPLAB LINK30 linker allocates the primary and secondary buffers in reverse order starting at the bottom of the DMA memory space.

If the DMAxSTA (and/or DMAxSTB) register is initialized to a value that will result in the DMA channel reading or writing RAM addresses outside of DMA RAM space, DMA channel writes to this memory address are ignored. DMA channel reads from this memory address result in a read of '0'.

# dsPIC33F/PIC24H Family Reference Manual

## 38.5.4 DMA Transfer Count Setup

In the fourth step of the DMA setup process, each DMA channel must be programmed to service N + 1 number of requests before the data block transfer is considered complete. The value 'N' is specified by programming the DMA Channel x Transfer Count register (DMAxCNT). That is, a DMAxCNT value of '0' will transfer one element.

The value of the DMAxCNT register is independent of the transfer data size (byte or word), which is specified in the Data Transfer Size bit, SIZE (DMAxCON<14>).

If the DMAxCNT register is initialized to a value that will result in the DMA channel reading or writing RAM addresses outside of DMA RAM space, DMA channel writes to this memory address are ignored. DMA channel reads from this memory address result in a read of '0'.

### 38.5.5 Operating Mode Setup

The fifth and final DMA setup step is to specify the mode of operation for each DMA channel by configuring the DMAxCON register. For specific setup information, refer to **38.6 "DMA Operating Modes"**.

### 38.6 DMA OPERATING MODES

The DMA channel supports these modes of operation:

- · Word or byte data transfer
- Transfer direction (peripheral to DPSRAM, or DPSRAM to peripheral)
- · Full or half transfer interrupts to CPU
- · Post-Increment or static DPSRAM addressing
- · Peripheral Indirect Addressing
- · One-shot or continuous block transfers
- Auto-switch between two start addresses offsets (DMAxSTA or DMAxSTB) after each transfer complete (Ping-Pong mode)
- · Null Data Write mode

Additionally, DMA supports a manual mode, which forces a single DMA transfer.

### 38.6.1 Word or Byte Data Transfer

Each DMA channel can be configured to transfer data by word or byte. Word data can only be moved to and from aligned (even) addresses. Conversely, Byte data can be moved to or from any (legal) address.

If the SIZE bit (DMAxCON<14>) is clear, word-sized data is transferred. If Register Indirect with Post-Increment Addressing mode is enabled, the address is post-incremented by 2 after every word transfer (see 38.6.5 "Register Indirect without Post-Increment Addressing Mode").

If the SIZE bit (DMAxCON<14>) is set, byte-sized data is transferred. If Register Indirect with Post-Increment Addressing mode is enabled, the address is incremented by 1 after every byte transfer.

#### 38.6.2 Transfer Direction

Each DMA channel can be configured to transfer data from a peripheral to the DPSRAM or from the DPSRAM to a peripheral.

If the Transfer Direction bit (source/destination bus select), DIR (DMAxCON<13>) is clear, data is read from the peripheral (using the peripheral address as provided by DMAxPAD), and the destination write is directed to the DPSRAM DMA memory address offset (using DMAxSTA or DMAxSTB).

If the DIR bit (DMAxCON<13>) is set, data is read from the DPSRAM DMA memory address offset (using DMAxSTA or DMAxSTB), and the destination write is directed to the peripheral (using the peripheral address, as provided by DMAxPAD).

Once configured, each channel is a unidirectional data conduit. That is, should a peripheral require read and write data using the DMA controller, two channels must be assigned – one for read and one for write.

#### 38.6.3 Full or Half Block Transfer Interrupts

Each DMA channel provides an interrupt to the interrupt controller when block data transfer is complete or half complete. This mode is designated by clearing or setting the Block Transfer Interrupt Select bit, HALF (DMAxCON<12>):

- HALF = 0 (initiate interrupt when all of the data has been moved)
- HALF = 1 (initiate interrupt when half of the data has been moved)

When DMA Continuous mode is used, the CPU must be able to process the incoming or outgoing data at least as fast as the DMA is moving it. The half transfer interrupt helps mitigate this problem by generating an interrupt when only half of the data has been transferred. For example, if an ADC is being continuously read by the DMA controller, the half transfer interrupt allows the CPU to process the buffer before it becomes completely full. Provided it never gets ahead of the DMA writes, this scheme can be used to relax the CPU response time requirements. Figure 38-7 illustrates this process.

E\_DMA\_BASE + DMAXSTA

Transfer #1
Transfer #2
Transfer #3

Transfer #1

Transfer #2

Transfer #3

Half Transfer IRQ to CPU

Figure 38-7: Half Block Transfer Mode

In all modes, when the HALF bit (DMAxCON<12>) is set, the DMA issues an interrupt only when the first half of Buffer A and/or B is transferred. No interrupt is issued when Buffer A and/or B is completely transferred. In other words, interrupts are only issued when DMA completes (DMAxCNT + 1)/2 transfers. If (DMAxCNT + 1) is equal to an odd number, interrupts are issued after (DMAxCNT + 2)/2 transfers.

For example, if DMA3 is configured for One-Shot, Ping-Pong buffers (MODE<1:0> = 11), and DMA3CNT = 7, two DMA3 interrupts are issued. One DMA3 interrupt is issued after transferring four elements from Buffer A, and the other DMA3 interrupt is issued after transferring four elements from Buffer B. For more information, refer to 38.6.7 "One-Shot Mode" and 38.6.9 "Ping-Pong Mode".

Even though the DMA channel issues an interrupt on either half or full block transfers, the user application can "trick" the DMA channel into issuing an interrupt on half and full block transfers by toggling the value of the HALF bit (DMAxCON<12>) during each DMA interrupt. For example, if the DMA channel is set up with the HALF bit (DMAxCON<12>) set to '1', an interrupt is issued after each half block transfer. If the user application resets the HALF bit (DMAxCON<12>) to '0' while the interrupt is being serviced, the DMA issues another interrupt when the full block transfer is complete.

To enable these interrupts, the corresponding DMA Interrupt Enable bit (DMAxIE) must be set in the Interrupt Enable Control (IECx) register in the Interrupt Controller module, as shown in Table 38-3.

	-	•	•
DMA Channel	Interrupt Controller Register Name and Bit Number	Corresponding Register Bit Name	C Structure Access Code
0	IEC0<4>	DMA0IE	IECObits.DMA0IE
1	IEC0<14>	DMA1IE	IEC1bits.DMA1IE
2	IEC1<8>	DMA2IE	IEC1bits.DMA2IE
3	IEC2<4>	DMA3IE	IEC2bits.DMA3IE
4	IEC2<14>	DMA4IE	IEC2bits.DMA4IE
5	IEC3<13>	DMA5IE	IEC3bits.DMA5IE
6	IEC4<4>	DMA6IE	IEC4bits.DMA6IE
7	IEC4<5>	DAM7IE	IEC4bits.DMA7IE

Table 38-3: Interrupt Controller Settings for Enabling/Disabling DMA Interrupts

Example 38-1 shows how DMA channel 0 interrupt is enabled.

Example 38-1: Code to Enable DMA Channel 0 Interrupt

IECObits.DMA0IE = 1;

Each DMA channel transfer interrupt sets a corresponding status flag in the interrupt controller, which triggers the ISR. The user application must then clear that status flag to prevent the transfer-complete ISR from re-executing.

Table 38-4 shows the Interrupt Flag Status (IFSx) register and the corresponding bit name, DMAxIF, in the Interrupt Controller module. It also shows the C Structure Access Code that clears the flag.

Table 38-4: Interrupt Controller Settings for Clearing DMA Interrupt Status Flags

DMA Channel	Interrupt Controller Register Name and Bit Number	Corresponding Register Bit Name	C Structure Access Code
0	IFS0<4>	DMA0IF	IFSObits.DMAOIE
1	IFS0<14>	DMA1IF	IFSObits.DMA1IE
2	IFS1<8>	DMA2IF	IFS1bits.DMA2IE
3	IFS2<4>	DMA3IF	IFS2bits.DMA3IE
4	IFS2<14>	DMA4IF	IFS2bits.DMA4IE
5	IFS3<13>	DMA5IF	IFS3bits.DMA5IE
6	IFS4<4>	DMA6IF	IFS4bits.DMA6IE
7	IFS4<5>	DMA7IF	IFS4bits.DMA7IE

As an example, assume DMA channel 0 interrupt is enabled, DMA channel 0 transfer has finished, and the associated interrupt has been issued to the interrupt controller. The following code must be present in the DMA channel 0 ISR to clear the status flag and to prevent a pending interrupt. Example 38-2 shows how DMA channel 0 interrupt is cleared.

#### **Example 38-2:** Code to Clear DMA Channel 0 Interrupt

```
void __attribute__((interrupt, no_auto_psv)) _DMA0Interrupt(void)
{
    . . .

IFSObits.DMA0IF = 0;
}
```

### 38.6.4 Register Indirect with Post-Increment Addressing Mode

Register Indirect with Post-Increment Addressing mode is used to move blocks of data by incrementing the DPSRAM address after each transfer.

The DMA channel defaults to this mode after the DMA controller is reset. This mode is selected by programming the DMA Channel Addressing Mode Select bits, AMODE<1:0> (DMAxCON<5:4>) to '00'. In this mode, the DMAxSTA or DMAxSTB register provides the starting address of DPSRAM buffer.

The user application determines the latest DPSRAM transfer address offset by reading the DPSRAM Start Address Offset register. However, the contents of this register are not modified by the DMA controller.

Figure 38-8 illustrates data transfer in this mode. Example 38-3 demonstrates the code for Register Indirect Post-Increment mode.

Figure 38-8: Data Transfer with Register Indirect with Post-Increment Addressing **DMA Channel 3, First Transfer** & DMA BASE DMA Peripheral Transfer 1 Channel 3 Data 1 & DMA BASE + DMA3STA + 0 Data 2 & DMA BASE + DMA3STA + 1 & DMA BASE + DMA3STA + 2 Data 3 **DMA Channel 3, Second Transfer** & DMA BASE Peripheral DMA Transfer 2 Channel 3 & DMA BASE + DMA3STA + 0 Data 1 Data 2 &\_DMA\_BASE + DMA3STA + 1 Data 3 & DMA BASE + DMA3STA + 4 **DMA Channel 3, Third Transfer** &\_DMA\_BASE DMA Peripheral Transfer 3 Channel 3 Data 1 & DMA BASE + DMA3STA + 0 Data 2 & DMA BASE + DMA3STA + 1 Data 3 &\_DMA\_BASE + DMA3STA + 2

# Example 38-3: Code for Output Compare and DMA with Register Indirect Post-Increment Mode


```
Set up Output Compare 1 module for PWM mode:
OC1CON = 0;
                                // Reset OC module
OC1R = 0x60;
                                // Initialize PWM Duty Cycle
OC1RS = 0x60;
                                // Initialize PWM Duty Cycle Buffer
OC1CONbits.OCM = 6;
                                // Configure OC for the PWM mode
Set up DMA Channel 3 for in Post Increment mode with Timer2 Request Source:
unsigned int BufferA[32] attribute ((space(dma)));
/* Insert code here to initialize BufferA with desired Duty Cycle values */
                               // Configure DMA for Register indirect mode
DMA3CONbits.AMODE = 0;
                                // with post-increment
DMA3PAD = (volatile unsigned int) &OC1RS; // Point DMA to OC1RS
DMA3CNT = 31;
                               // 32 DMA request
DMA3REQ = 7;
                                // Select Timer2 as DMA Request source
DMA3STA = builtin dmaoffset(BufferA);
IFS2bits.DMA3IF = 0;
                                // Clear the DMA interrupt flag bit
IEC2bits.DMA3IE = 1;
                                // Set the DMA interrupt enable bit
                                // Enable DMA
DMA3CONbits.CHEN = 1;
Set up Timer2 for Output Compare PWM mode:
PR2 = 0xRF:
                                // Initialize PWM period
T2CONbits.TON = 1;
                                // Start Timer2
Set up DMA Channel 3 Interrupt Handler:
void attribute ((interrupt, no auto psv)) DMA3Interrupt(void)
   /* Update BufferA with new Duty Cycle values if desired here*/
   IFS2bits.DMA3IF = 0;
                                //Clear the DMA3 Interrupt Flag
```

#### 38.6.5 Register Indirect without Post-Increment Addressing Mode

Register Indirect without Post-Increment Addressing mode is used to move blocks of data without incrementing the starting address of the data buffer after each transfer. In this mode, the DMAxSTA or DMAxSTB register provides offset to the starting address of the DPSRAM buffer. When the DMA data transfer takes place, the DPSRAM Address does not increment to the next location. So, the next DMA data transfer is initiated to the same DPSRAM address. This mode is selected by programming the AMODE<1:0> bits (DMAxCON<5:4>) to '01'.

If the addressing mode is changed to Register Indirect without Post-Increment Addressing mode while the DMA channel is active (that is, after some DMA transfers have occurred), the DMA DPSRAM address will point to the current DPSRAM buffer location (that is, not the contents of the DMAxSTA or DMAxSTB, which by then could differ from the current DPSRAM buffer location). Figure 38-9 illustrates data transfer from the peripheral to the DMA DPSRAM, contrasting the use with and without post-increment addressing. Example 38-4 demonstrates the code for Register Indirect without Post-Increment Addressing.

Figure 38-9: Contrast of Data Transfer with and without Post-Increment Addressing



# Example 38-4: Code for Input Capture and DMA with Register Indirect without Post-Increment Addressing

```
Set up Input Capture 1 module for DMA operation:
IC1CON = 0;
                             // Reset IC module
IC1CONbits.ICTMR = 1;
                             // Select Timer2 contents for capture
IC1CONbits.ICM = 2;
                            // Capture every falling edge
IC1CONbits.ICI = 0;
                            // Generate DMA request on every capture event
Set up Timer2 to be used by Input Capture module:
PR2 = 0xBF:
                              // Initialize count value
T2CONbits.TON = 1;
                              // Start timer
Set up DMA Channel 0 for no Post Increment mode:
unsigned int CaptureValue attribute ((space(dma)));
DMA0CONbits.AMODE = 1;
                             // Configure DMA for Register indirect
                             // without post-increment
DMAOCONbits.MODE = 0; // Configure DMA for Continuous mode
DMAOPAD = (volatile unsigned int)&IC1BUF; // Point DMA to IC1BUF
DMAOCNT = 0;
                            // Interrupt after each transfer
DMAOREQ = 1;
                             // Select Input Capture module as DMA Request source
DMA3STA = builtin dmaoffset(&CaptureValue);
IFSObits.DMAOIF = 0;
                             // Clear the DMA interrupt flag bit
IECObits.DMA0IE = 1;
                             // Set the DMA interrupt enable bit
DMA0CONbits.CHEN = 1;
                             // Enable DMA
Set up DMA Channel 0 Interrupt Handler:
void attribute ((interrupt, no auto psv)) DMA3Interrupt(void)
   /* Process CaptureValue variable here*/
                            //Clear the DMA3 Interrupt Flag
   IFSObits.DMAOIF = 0;
```

### 38.6.6 Peripheral Indirect Addressing Mode

Peripheral Indirect Addressing mode is a special addressing mode where the peripheral, not the DMA channel, provides the variable part of the DPSRAM address. That is, the peripheral generates the Least Significant bits (LSbs) of the DPSRAM address, while the DMA channel provides the fixed buffer base address. However, the DMA channel continues to coordinate the actual data transfer, keeping track of the transfer count, and generating the corresponding CPU interrupts.

Peripheral Indirect Addressing mode can operate bidirectionally, depending upon the peripheral need, so the DMA channel still needs to be configured appropriately to support target peripheral reads or writes.

Peripheral Indirect Addressing mode is selected by programming the AMODE<1:0> bits (DMAxCON<5:4>) to '1x'.

The DMA capability in Peripheral Indirect Addressing mode can be specifically tailored to meet the needs of each peripheral that supports it. The peripheral defines the address sequence for accessing the data within the DPSRAM, allowing it, for example, to sort incoming ADC data into multiple buffers, relieving the CPU of the task.

If Peripheral Indirect Addressing mode is supported by a peripheral, a DMA request interrupt from that peripheral is accompanied by an address that is presented to the DMA channel. If the DMA channel that responds to the request is also enabled for Peripheral Indirect Addressing, it will logically OR the buffer base address with the zero extended incoming Peripheral Indirect Address to create the actual DPSRAM offset address, as illustrated in Figure 38-10.




Figure 38-10: Address Offset Generation in Peripheral Indirect Addressing Mode

The peripheral determines how many Least Significant address bits it will control. The application program must select a base address for the buffer in DPSRAM and ensure that the corresponding number of LSbs of that address offset are zero. As with other modes, when the DMAxSTA or DMAxSTB register is read, it returns a value of the latest DPSRAM transfer address offset, which includes the address offset calculation described above. If the DMA channel is not configured for Peripheral Indirect Addressing, the incoming address is ignored and the data transfer occurs as normal.

Peripheral Indirect Addressing mode is compatible with all other operating modes, and is currently supported by the ADC and ECAN modules.

#### 38.6.6.1 ADC SUPPORT FOR DMA ADDRESS GENERATION

In Peripheral Indirect Addressing mode, the peripheral defines the addressing sequence, which is more tailored to peripheral functionality. For example, if the ADC is configured to continuously convert inputs 0 through 3 in sequence (0, 1, 2, 3, 0, 1, and so on), and it is associated with a DMA channel that is configured for Register Indirect Addressing with Post-Increment, DMA transfer moves this data into a sequential buffer as illustrated in Figure 38-11. Example 38-5 illustrates the code for this configuration.




Figure 38-11: Data Transfer from ADC with Register Indirect Addressing

#### Example 38-5: Code for Data Transfer from ADC with Register Indirect Addressing

```
Set up ADC1 for channel 0-3 sampling:
AD1CON1bits.FORM = 3;
                              // Data Output Format: Signed Fraction (Q15 format)
AD1CON1bits.SSRC = 2;
                              // Sample Clock Source: GP Timer starts conversion
AD1CON1bits.ASAM = 1;
                             // Sampling begins immediately after conversion
AD1CON1bits.AD12B = 0;
                             // 10-bit ADC operation
AD1CON1bits.SIMSAM = 0;
                             // Samples individual channels sequentially
AD1CON2bits.BUFM = 0:
                            // Scan CHO+ Input Selections during Sample A bit
AD1CON2bits.CSCNA = 1;
AD1CON2bits.CHPS = 0;
                              // Converts CH0
AD1CON3bits.ADRC = 0;  // ADC Clock is derived from Systems Clock AD1CON3bits.ADCS = 63;  // ADC Conversion Clock
//AD1CHS0: A/D Input Select Register
AD1CHSObits.CHOSA = 0; // MUXA +ve input selection (AINO) for CHO
AD1CHS0bits.CH0NA = 0;
                              // MUXA -ve input selection (Vref-) for CHO
//AD1CHS123: A/D Input Select Register
AD1CHS123bits.CH123SA = 0; // MUXA +ve input selection (AINO) for CH1
AD1CHS123bits.CH123NA = 0;
                             // MUXA -ve input selection (Vref-) for CH1
//AD1CSSH/AD1CSSL: A/D Input Scan Selection Register
AD1CSSH = 0x0000;
AD1CSSL = 0 \times 0000F;
                              // Scan AINO, AIN1, AIN2, AIN3 inputs
Set up Timer3 to trigger ADC1 conversions:
TMR3 = 0 \times 0.000:
PR3 = 4999;
                              // Trigger ADC1 every 125usec @ 40 MIPS
IFSObits.T3IF = 0;
                              // Clear Timer3 interrupt
IECObits.T3IE = 0;
                              // Disable Timer3 interrupt
                              //Start Timer3
T3CONbits.TON = 1;
Set up DMA Channel 5 for Register Indirect with Post-Increment Addressing:
unsigned int BufferA[32] attribute ((space(dma)));
unsigned int BufferB[32] attribute ((space(dma)));
DMA5CONbits.AMODE = 0;
                              // Configure DMA for Register indirect mode
                              // with post-increment
DMA5CONbits.MODE = 2;
                              // Configure DMA for Continuous Ping-Pong mode
DMA5PAD = (volatile unsigned int) &ADC1BUF0; // Point DMA to ADC1BUF0
DMA5CNT = 31;
                              // 32 DMA request
DMA5REQ = 13;
                              // Select ADC1 as DMA Request source
DMA5STA = __builtin_dmaoffset(BufferA);
DMA5STB = builtin dmaoffset(BufferB);
IFS3bits.DMA5IF = 0;
                            //Clear the DMA interrupt flag bit
IEC3bits.DMA5IE = 1;
                             //Set the DMA interrupt enable bit
DMA5CONbits.CHEN=1;
                              // Enable DMA
Set up DMA channel 5 Interrupt handler:
unsigned int DmaBuffer = 0;
void __attribute__((interrupt, no_auto_psv)) _DMA5Interrupt(void)
   // Switch between Primary and Secondary Ping-Pong buffers
if(DmaBuffer == 0)
```

Example 38-5: Code for Data Transfer from ADC with Register Indirect Addressing (Continued)

```
ProcessADCSamples (BufferA);
   else
   {
       ProcessADCSamples(BufferB);
   DmaBuffer ^= 1;
   IFS3bits.DMA5IF = 0;
                             //Clear the DMA5 Interrupt Flag
Set up ADC1 for DMA operation:
AD1CON1bits.ADDMABM = 0;
                             // Don't Care: ADC address generation is
                             // ignored by DMA
                           // Don't Care
AD1CON2bits.SMPI
AD1CON4bits.DMABL = 3;
                             // Don't Care
                   = 0;
IFSObits.AD1IF
                             // Clear the A/D interrupt flag bit
IECObits.AD1IE
                   = 0;
                            // Do Not Enable A/D interrupt
AD1CON1bits.ADON
                   = 1;
                             // Turn on the A/D converter
```

A typical algorithm would operate on a per ADC data channel basis, requiring it to either sort transferred data or index it by jumping unwanted data. Either of these methods require more code and consume more execution time. ADC Peripheral Indirect Addressing mode defines a special addressing technique where data for each ADC channel is placed into its own buffer. For Example 38-5, if the DMA channel is configured for Peripheral Indirect Addressing mode, the DMA transfer moves ADC data into separate buffers, as illustrated in Figure 38-12.

Peripheral Indirect Address (PIA) & DMA BASE Transfer\_1\_ Data Transfer 5 AN0 Sample 1 & DMA BASE+DMA5STA+PIA (for Transfer 1) AN0 DMA AN0 Sample 2 Channel Transfer 2 AN1 ADC 5 AN0 Sample 3 AN2 AN3 & DMA BASE+DMA5STA+PIA (for Transfer 2) AN1 Sample 1 Transfer 4 Request AN1 Sample 2 AN1 Sample 3 AN2 Sample 1 AN2 Sample 2 AN2 Sample 3 AN3 Sample 1 AN3 Sample 2 AN3 Sample 3 &\_DMA\_BASE+DMA5STA+PIA (for Transfer 12)

Figure 38-12: Data Transfer from ADC with Peripheral Indirect Addressing

To enable this kind of ADC addressing, the DMA Buffer Build Mode bit, ADDMABM (ADxCON1), must be cleared. If the ADDMABM bit (ADxCON1<12>) is set, the ADC generates addresses in the order of conversion (same as DMA Register Indirect Addressing with Post-Increment mode).

As mentioned earlier, user must pay special attention to the number of LSbs that are reserved for the peripheral when the DMAxSTA and DMAxSTB registers are initialized by the user application. For the ADC, the number of bits will depend on the size and number of the ADC buffers.

The number of ADC buffers is initialized with the Increment Rate for the SMPI<3:0> bits (ADCxCON2<5:2>). The size of each ADC buffer is initialized with the DMABL<2:0> bits (ADCxCON4<2:0>). For example, if the SMPI<3:0> bits are initialized to 3 and the DMABL<2:0> bits are initialized to 3, there will be four ADC buffers (SMPI<3:0> + 1), each with eight words ( $2^{DMABL<2:0>}$ ), for the total of 32 words (64 bytes). This means that the address offset that is written into the DMAxSTA and DMAxSTB must have 6 ( $2^{6 \text{ bits}}$  = 64 bytes) LSbs set to zero.

If the MPLAB C30 compiler is used to initialized the DMAxSTA and DMAxSTAB registers, proper data alignment must be specified through data attributes. For the above conditions, the code shown in Example 38-6 will initialize the DMAxSTA and DMAxSTB registers.

# Example 38-6: DMA Buffer Alignment with MPLAB® C30

```
int BufferA[4][8] __attribute__((space(dma),aligned(64)));
int BufferB[4][8] __attribute__((space(dma),aligned(64)));

DMAOSTA = __builtin_dmaoffset(BufferA);
DMAOSTB = __builtin_dmaoffset(BufferB);
```

Example 38-7 illustrates the code for this configuration.

# Example 38-7: Code for ADC and DMA with Peripheral Indirect Addressing

```
Set up ADC1 for channel 0-3 sampling:
AD1CON1bits.FORM = 3;
                               // Data Output Format: Signed Fraction (Q15 format)
AD1CON1bits.SSRC = 2;
                               // Sample Clock Source: GP Timer starts conversion
AD1CON1bits.ASAM = 1;
                              // Sampling begins immediately after
conversion
AD1CON1bits.AD12B = 0;
                               // 10-bit ADC operation
AD1CON1bits.SIMSAM = 0;
                               // Samples multiple channels sequentially
AD1CON2bits.BUFM = 0;
                               // Scan CHO+ Input Selections during Sample A
AD1CON2bits.CSCNA = 1;
bit.
AD1CON2bits.CHPS = 0;
                               // Converts CH0
                               // ADC Clock is derived from Systems Clock
AD1CON3bits.ADRC = 0;
AD1CON3bits.ADCS = 63;
                               // ADC Conversion Clock
//AD1CHS0: A/D Input Select Register
AD1CHSObits.CHOSA = 0; // MUXA +ve input selection (AINO) for CHO
AD1CHS0bits.CH0NA = 0;
                               // MUXA -ve input selection (Vref-) for CHO
//AD1CHS123: A/D Input Select Register
AD1CHS123bits.CH123SA = 0; // MUXA +ve input selection (AINO) for CH1
AD1CHS123bits.CH123NA = 0; // MUXA -ve input selection (Vref-) for CH1
AD1CHS123bits.CH123NA = 0;
//AD1CSSH/AD1CSSL: A/D Input Scan Selection Register
AD1CSSH = 0x0000;
AD1CSSL = 0x000F;
                               // Scan AINO, AIN1, AIN2, AIN3 inputs
Set up Timer3 to trigger ADC1 conversions:
TMR3 = 0x0000;
PR3 = 4999; // Trigger ADC1 every 125usec
IFSObits.T3IF = 0;
                              // Clear Timer3 interrupt
                               // Disable Timer3 interrupt
IECObits.T3IE = 0;
T3CONbits.TON = 1;
                               //Start Timer3
```

#### Example 38-7: Code for ADC and DMA with Peripheral Indirect Addressing (Continued)

```
Set up DMA Channel 5 for Peripheral Indirect Addressing:
int BufferA[4][8]
                   __attribute__((space(dma), aligned(64)));
BufferB[4][8] attribute ((space(dma), aligned(64)));
int
DMA5CONbits.AMODE = 2;  // Configure DMA for Peripheral indirect mode DMA5CONbits.MODE = 2;  // Configure DMA for Continuous Ping-Pong mode
DMA5PAD = (volatile unsigned int) &ADC1BUF0;// Point DMA to ADC1BUF0
                 // 32 DMA request (4 buffers, each with 8 words)
DMA5CNT = 31;
                               // Select ADC1 as DMA Request source
DMA5REO = 13;
DMA5STA = __builtin_dmaoffset(BufferA);
DMA5STB = __builtin_dmaoffset(BufferB);
IFS3bits.DMA5IF = 0;
                               //Clear the DMA interrupt flag bit
IEC3bits.DMA5IE = 1;
                               //Set the DMA interrupt enable bit
DMA5CONbits.CHEN=1;
                              // Enable DMA
Set up DMA Channel 5 Interrupt Handler:
unsigned int DmaBuffer = 0;
void attribute ((interrupt, no auto psv)) DMA5Interrupt(void)
    // Switch between Primary and Secondary Ping-Pong buffers
if(DmaBuffer == 0)
        ProcessADCSamples(&BufferA[0][0]);
        ProcessADCSamples(&BufferA[1][0]);
        ProcessADCSamples(&BufferA[2][0]);
        ProcessADCSamples(&BufferA[3][0]);
    else
        ProcessADCSamples(&BufferB[0][0]);
        ProcessADCSamples(&BufferB[1][0]);
        ProcessADCSamples(&BufferB[2][0]);
        ProcessADCSamples(&BufferB[3][0]);
    DmaBuffer ^= 1;
    IFS3bits.DMA5IF = 0;
                              //Clear the DMA5 Interrupt Flag
Set up ADC1 for DMA operation:
IFSObits.AD1IF = 0;  // Clear the A/D interrupt flag bit
IECObits.AD1IE = 0;  // Do Not Enable A/D interrupt
AD1CON1bits.ADON = 1;
                              // Turn on the A/D converter
```

#### 38.6.6.2 ECAN SUPPORT FOR DMA ADDRESS GENERATION

Peripheral Indirect Addressing can also be used with the ECAN module to let ECAN define more specific addressing functionality. When the dsPIC33F/PIC24H device filters and receives messages through the CAN bus, the messages can be categorized into two groups:

- · Received messages that must be processed
- · Received messages that must be forwarded to other CAN nodes without processing

In the first case, received messages must be reconstructed into buffers of eight words each before they can be processed by the user application. With multiple ECAN buffers located in the DMA RAM, it would be easier to let the ECAN peripheral generate RAM addresses for incoming (or outgoing) data, as illustrated in Figure 38-13. In this figure, Buffer 2 is received first, followed by Buffer 0. The ECAN module generates destination addresses to properly place data in the DMA RAM (Peripheral Indirect Addressing).

Figure 38-13: Data Transfer from ECAN™ with Peripheral Indirect Addressing

As mentioned earlier, you must pay special attention to the number of LSbs that are reserved for the peripheral when the DMAxSTA and DMAxSTB registers are initialized by the user application and the DMA is operating in Peripheral Indirect Addressing mode. For the ECAN module, the number of bits depends on the number of ECAN buffers defined by the DMA Buffer Size bits (DMABS<2:0>) in the ECAN FIFO Control register (CiFCTRL<15:13>).

Buffer 2: SID Buffer 2: EID

For example, if the ECAN module reserves 12 buffers by setting DMABS<2:0> bits to '3', there will be 12 buffers with 8 words each, for a total of 96 words (192 bytes). This means that the address offset that is written into the DMAxSTA and DMAxSTB registers must have 8 LSbs (2<sup>8 bits</sup> = 256 bytes) set to '0'. If the MPLAB C30 compiler is used to initialize the DMAxSTA register, proper data alignment must be specified through data attributes. For this example, the code in Example 38-8 properly initializes the DMAxSTA register.

Example 38-8: DMA Buffer Alignment with MPLAB® C30

```
int BufferA[12][8] __attribute__((space(dma),aligned(256)));

DMAOSTA = __builtin_dmaoffset(&BufferA[0][0]);
```

Buffer 1

Buffer 2


Example 38-9 illustrates the code for this configuration.

However, processing of incoming messages may not always be a requirement. For instance, in some automotive applications, received messages can simply be forwarded to another node rather than being processed by the CPU. In this case, received buffers do not have to be sorted in memory and can be forwarded as they become available.

This mode of data transfer can be achieved with the DMA in Register Indirect Addressing with Post-Increment. Figure 38-14 illustrates this scenario.

Example 38-9: Code for ECAN™ and DMA with Peripheral Indirect Addressing


```
Set up ECAN1 with two filters:
/* Initialize ECAN clock first. See ECAN section for example code */
C1CIRDIDITS.WIN = 1;  // Enable filter window
C1FEN1bits.FLTEN0 = 1;  // Filter 0 is enabled
C1FEN1bits.FLTEN1 = 1;  // Filter 1 is enabled
C1BUFPNT1bits.F1BP = 0;  // Filter 0 points to Bu
                             // Filter 0 points to Buffer0
                              // Filter 1 points to Buffer2
C1RXF0SID = 0xFFEA;
                              // Filter 0 configuration
C1RXF0EID = 0xFFFF;
C1RXF1SID = 0xFFEB;
                             // Filter 1 configuration
C1RXF1EID = 0xFFFF;
C1FMSKSEL1bits.F0MSK = 0; // Mask 0 used for both filters
C1FMSKSEL1bits.F1MSK = 0; // Mask 0 used for both filters
C1RXM0SID = 0xFFEB;
C1RXM0EID = 0xFFFF;
C1FCTRLbits.DMABS = 3; // 12 buffers in DMA RAM
C1FCTRLbits.FSA = 3;
                               // FIFO starts from TX/RX Buffer 3
C1CTRL1bits.WIN = 0;
C1TR01CONbits.TXEN0 = 0;  // Buffer 0 is a receive buffer C1TR23CONbits.TXEN2 = 0;  // Buffer 2 is a receive buffer
C1TR01CONbits.TX0PRI = 0b11;  //High Priority
C1TR01CONbits.TX1PRI = 0b10;  //Intermediate High Priority
C1CTRL1bits.REQOP = 0;// Enable Normal Operation Mode
Set up DMA Channel 0 for Peripheral Indirect Addressing:
unsigned int Ecan1Rx[12][8] attribute ((space(dma)));// 12 buffers, 8
words each
DMAOCONbits.AMODE = 2; // Continuous mode, single buffer
DMA0CONbits.MODE = 0;
                              // Peripheral Indirect Addressing
DMAOPAD = (volatile unsigned int) &C1RXD;
                                              // Point to ECAN1 Rx register
DMAOSTA = builtin dmaoffset(Ecan1Rx);
                                              // Point DMA to ECAN1 buffers
DMAOCNT = 7;
                              // 8 DMA request (1 buffer, each with 8 words)
DMAOREQ = 0x22;
                              // Select ECAN1 Rx as DMA Request source
Set up DMA Interrupt Handlers:
void attribute ((interrupt, no auto psv)) DMA0Interrupt(void)
   IFSObits.DMAOIF = 0;
                             // Clear the DMAO Interrupt Flag;
```



#### 38.6.7 One-Shot Mode

One-Shot mode is used by the application program when repetitive data transfer is not required. One-Shot mode is selected by programming the DMA Channel Operating Mode Select bits, MODE<1:0> (DMAxCON<1:0>) to ' $\times$ 1'. In this mode, when the entire data block is moved (block length as defined by DMAxCNT), the data block end is detected and the channel is automatically disabled (that is, the Channel Enable bit, CHEN (DMAxCON<15>) is cleared by the hardware). Figure 38-15 illustrates One-Shot mode.

Figure 38-15: Data Block Transfer with One-Shot Mode



If the HALF bit (DMAxCON<12>) is set, the DMAxIF bit is set (and the DMA interrupt is generated, if enabled by the application program) when half of the data block transfer is complete and the channel remains enabled. When the full block transfer is complete, no interrupt flag is set and the channel is automatically disabled. For information on how to set up the DMA channel to interrupt on both half and full block transfer, refer to 38.6.3 "Full or Half Block Transfer Interrupts".

If the channel is re-enabled by setting the CHEN bit (DMAxCON<15>) to '1', the block transfer takes place from the start address, as provided by the DMAxSTA and DMAxSTB registers. Example 38-10 illustrates the code for One-Shot operation.

Example 38-10: Code for UART and DMA with One-Shot Mode

```
Set up UART for RX and TX:
#define FCY
                 40000000
#define BAUDRATE 9600
#define BRGVAL ((FCY/BAUDRATE)/16)-1
U2MODEbits.STSEL = 0;
                        // 1-stop bit
U2MODEbits.PDSEL = 0;
                        // No Parity, 8-data bits
U2MODEbits.ABAUD = 0;
                         // Autobaud Disabled
U2BRG = BRGVAL; // BAUD Rate Setting for 9600
U2STAbits.UTXISEL0 = 0:
                        // Interrupt after one Tx character is transmitted
U2STAbits.UTXISEL1 = 0;
U2STAbits.URXISEL = 0;
                         // Interrupt after one RX character is received
U2MODEbits.UARTEN = 1; // Enable UART
U2STAbits.UTXEN
                   = 1; // Enable UART Tx
```

#### Example 38-10: Code for UART and DMA with One-Shot Mode (Continued)

```
Set up DMA Channel 0 to Transmit in One-Shot, Single-Buffer mode:
unsigned int BufferA[8] __attribute__((space(dma)));
unsigned int BufferB[8] attribute ((space(dma)));
DMAOCON = 0x2001; // One-Shot, Post-Increment, RAM-to-Peripheral
DMAOCNT = 7;
                            // 8 DMA requests
DMAOREQ = 0x001F;
                            // Select UART2 Transmitter
DMAOPAD = (volatile unsigned int) &U2TXREG;
DMAOSTA = builtin dmaoffset(BufferA);
IFSObits.DMAOIF = 0;
                            // Clear DMA Interrupt Flag
IECObits.DMA0IE = 1;
                            // Enable DMA interrupt
Set up DMA Channel 1 to Receive in Continuous Ping-Pong mode:
DMA1CON = 0x0002;
                            // Continuous, Ping-Pong, Post-Inc., Periph-RAM
DMA1CNT = 7;
                            // 8 DMA requests
DMA1REQ = 0 \times 001E;
                            // Select UART2 Receiver
DMA1PAD = (volatile unsigned int) &U2RXREG;
DMA1STA = __builtin_dmaoffset(BufferA);
DMA1STB = builtin dmaoffset(BufferB);
// Enable DMA interrupt
// Enable DMA Channel
Set up DMA Interrupt Handlers:
void __attribute__((interrupt, no_auto_psv)) _DMA0Interrupt(void)
  IFSObits.DMA0IF = 0;  // Clear the DMA0 Interrupt Flag;
void attribute ((interrupt, no auto psv)) DMA1Interrupt(void)
  static unsigned int BufferCount = 0;
                                         // Keep record of which buffer
                                           // contains Rx Data
  if(BufferCount == 0)
   DMAOSTA = builtin dmaoffset(BufferA); // Point DMA 0 to data
                                           // to be transmitted
   else
   DMAOSTA = builtin dmaoffset(BufferB); // Point DMA 0 to data
                                           // to be transmitted
  DMA0CONbits.CHEN = 1;  // Enable DMA0 Channel
  DMAOREQbits.FORCE = 1;
                           // Manual mode: Kick-start the 1st transfer
  BufferCount ^= 1;
   IFSObits.DMA1IF = 0;
                           // Clear the DMA1 Interrupt Flag
```

#### 38.6.8 Continuous Mode

Continuous mode is used by the application program when repetitive data transfer is required throughout the life of the program.

This mode is selected by programming the MODE<1:0> bits (DMAxCON<1:0>) to 'x0'. In this mode, when the entire data block is moved (block length as defined by DMAxCNT), the data block end is detected and the channel remains enabled. During the last data transfer, DMA DPSRAM address resets back to (primary) the DMAxSTA register. Figure 38-16 illustrates Continuous mode.

COUNT=0

Transfer #1

Transfer #2

Transfer #3

Transfer #n

Count = DMAxCNT+1

CPU Block Transfer Complete IRQ

Figure 38-16: Repetitive Data Block Transfer with Continuous Mode

If the HALF bit (DMAxCON<12>) is set, the DMAxIF is set (and DMA interrupt is generated, if enabled) when half of the data block transfer is complete. The channel remains enabled. When the full block transfer is complete, no interrupt flag is set and the channel remains enabled. For more information on how to set up the DMA channel to interrupt on both half and full block transfer, refer to 38.6.3 "Full or Half Block Transfer Interrupts".

# 38.6.9 Ping-Pong Mode

Ping-Pong mode allows the CPU to process one buffer while a second buffer operates with the DMA channel. The net result is that the CPU has the entire DMA block transfer time in which to process the buffer currently not being used by the DMA channel. Of course, this transfer mode doubles the amount of DPSRAM needed for a given size of buffer.

In all DMA operating modes, when the DMA channel is enabled, the (primary) DMAxSTA register is selected by default to generate the initial DPSRAM effective address. As each block transfer completes and the DMA channel is reinitialized, the buffer start address is sourced from the same DMAxSTA register.

In Ping-Pong mode, the buffer start address is derived from two registers:

- · Primary DMAxSTA register
- · Secondary DMAxSTB register

DMA uses a secondary buffer for alternate block transfers. As each block transfer completes and the DMA channel is reinitialized, the buffer start address is derived from the alternate register.

Ping-Pong mode is selected by programming the MODE<1:0> bits (DMAxCON<1:0>) to '1x'.

If Continuous mode is selected while the DMA is operating in Ping-Pong mode, DMA responds by reinitializing to point to the secondary buffer after transferring the primary buffer, and then transfers the secondary buffer. Subsequent block transfers alternate between primary and secondary buffers. Interrupts are generated (if enabled by the application program) after each buffer is transferred. Figure 38-17 illustrates Ping-Pong mode with continuous operation. Example 38-11 illustrates the code used for Ping-Pong operation using the DCI module as an example.




Figure 38-17: Repetitive Data Transfer in Ping-Pong Mode

Example 38-11: Code for DCI and DMA with Continuous Ping-Pong Operation


```
Set up DCI for RX and TX:
#define FCY
                40000000
               48000
#define FS
#define FCSCK 64*FS
#define BCGVAL (FCY/(2*FS))-1
DCICON1bits.CSCKD = 0; // Serial Bit Clock (CSCK pin) is output
DCICON1bits.CSCKE = 0; // Data sampled on falling edge of CSCK
DCICON1bits.COFSD = 0; // Frame Sync Signal is output
DCICON1bits.UNFM = 0; // Transmit '0's on a transmit underflow
{\tt DCICON1bits.CSDOM} = 0; // {\tt CSDO} \ {\tt pin} \ {\tt drives} \ {\tt '0's} \ {\tt during} \ {\tt disabled} \ {\tt TX} \ {\tt time} \ {\tt slots}
DCICON1bits.DJST = 0; // TX/RX starts 1 serial clock cycle after frame sync pulse
DCICON1bits.COFSM = 1; // Frame Sync Signal set up for I2S mode
DCICON2bits.BLEN = 0; // One data word will be buffered between interrupts
DCICON2bits.COFSG = 1; // Data frame has 2 words: LEFT & RIGHT samples
DCICON2bits.WS = 15; // Data word size is 16 bits
DCICON3 = BCG VAL; // Set up CSCK Bit Clock Frequency
                        // Transmit on Time Slot 0
TSCONbits.TSE0 = 1:
TSCONbits.TSE1 = 1;
                        // Transmit on Time Slot 1
RSCONbits.RSE0 = 1;
                       // Receive on Time Slot 0
RSCONbits.RSE1 = 1;
                       // Receive on Time Slot 1
Set up DMA Channel 0 for Transmit in Continuous Ping-Pong mode:
unsigned int TxBufferA[16] __attribute__((space(dma)));
unsigned int TxBufferB[16] attribute ((space(dma)));
DMAOCON = 0x2002;
                        // Ping-Pong, Continous, Post-Increment, RAM-to-Peripheral
DMAOCNT = 15;
                        // 15 DMA requests
DMAOREQ = 0 \times 003C;
                      // Select DCI as DMA Request source
```

# Example 38-11: Code for DCI and DMA with Continuous Ping-Pong Operation (Continued)

```
DMAOPAD = (volatile unsigned int) &TXBUFO;
DMAOSTA = __builtin_dmaoffset(TxBufferA);
DMAOSTB = __builtin_dmaoffset(TxBufferB);
IFSObits.DMAOIF = 0;  // Clear DMA Interrupt Flag
IECObits.DMAOIE = 1;  // Enable DMA interrupt
DMAOCONbits.CHEN = 1;  // Enable DMA Channel
Set up DMA Channel 1 for Receive in Continuous Ping-Pong mode:
unsigned int RxBufferA[16] __attribute__((space(dma)));
unsigned int RxBufferB[16] __attribute__((space(dma)));
DMA1CON = 0x0002;
                        // Continuous, Ping-Pong, Post-Inc., Periph-RAM
DMA1CNT = 15;  // 16 DMA requests
DMA1REQ = 0x003C;  // Select DCI as DMA Request source
DMA1PAD = (volatile unsigned int) &RXBUF0;
DMA1STA = __builtin_dmaoffset(RxBufferA);
DMA1STB = __builtin_dmaoffset(RxBufferB);
IFSObits.DMA1IF = 0;// Clear DMA interrupt
IECObits.DMA1IE = 1;// Enable DMA interrupt
DMA1CONbits.CHEN = 1;// Enable DMA Channel
Set up DMA Interrupt Handlers:
void attribute ((interrupt, no auto psv)) DMA0Interrupt(void)
   static unsigned int TxBufferCount = 0; // Keep record of which buffer
                                                // has Rx Data
   if(BufferCount == 0)
    /* Notify application that TxBufferA has been transmitted */
   else
    /* Notify application that TxBufferB has been transmitted */
   BufferCount ^= 1;
   IFSObits.DMA0IF = 0;
                                              // Clear the DMAO Interrupt Flag;
void attribute ((interrupt, no auto psv)) DMA1Interrupt(void)
   static unsigned int RxBufferCount = 0; // Keep record of which buffer
                                                // has Rx Data
   if(BufferCount == 0)
    /* Notify application that RxBufferA has been received */
   }
   else
    /* Notify application that RxBufferB has been received */ }
BufferCount ^= 1;
   IFSObits.DMA1IF = 0;
                                              // Clear the DMA1 Interrupt Flag
Enable DCI:
/\star Force First two words to fill-in Tx buffer/shift register \star/
DMAOREQbits.FORCE = 1;
while (DMAOREQbits.FORCE == 1);
DMAOREQbits.FORCE = 1;
while(DMAOREQbits.FORCE == 1);
DCTCON1bits.DCTEN = 1:
                                              // Enable DCI
```

# Section 38. Direct Memory Access (DMA) (Part III)

If One-Shot mode is selected while the DMA controller is operating in Ping-Pong mode, the DMA responds by reinitializing to point to the secondary buffer after transferring primary buffer and then transfers the secondary buffer. Subsequent block transfers will not occur, however, because the DMA channel disables itself. Figure 38-18 illustrates One-Shot data transfer in Ping-Pong mode.



CPU Block Transfer Complete IRQ

Disable DMA Channel

## 38.6.10 Manual Transfer Mode

For peripherals that are sending data to the DPSRAM using the DMA controller, the DMA data transfer starts automatically after the DMA channel and peripheral are initialized. When the peripheral is ready to move data to the DPSRAM, it issues a DMA request. If data also needs to be sent to the peripheral at this time, the same DMA request can be used to activate another channel to read data from DPSRAM and write it to the peripheral.

Conversely, if the application only needs to send data to a peripheral (from a DPSRAM buffer) an initial (manual) data load into the peripheral may be required to start the process (see 38.7 "Starting DMA Transfer"). This process could be initiated with conventional software. However, a more convenient approach is to simply mimic the channel DMA request by setting a bit within the selected DMA channel. The DMA channel processes the forced request as it would any other request and transfers the first data element to start the sequence. When the peripheral is ready for the next piece of data, it sends a normal DMA request and the DMA sends the next data element. This process is illustrated in Figure 38-19.

A manual DMA request can be created by setting the FORCE bit (DMAxREQ<15>). Once set, the FORCE bit (DMAxREQ<15>) cannot be cleared by the user application. It must be cleared by hardware when the forced DMA transfer is complete. Depending on when the FORCE bit (DMAxREQ<15>) is set, these special conditions apply:

- Setting the FORCE bit (DMAxREQ<15>) while the DMA transfer is in progress has no effect and is ignored.
- Setting the FORCE bit (DMAxREQ<15>) while the channel x is being configured (that is, setting the FORCE bit (DMAxREQ<15>) during the same write that configures DMA channel) can result in unpredictable behavior and should be avoided.
- An attempt to set the FORCE bit (DMAxREQ<15>) while a peripheral IRQ is pending (for this channel) is discarded in favor of the interrupt based request. However, an error condition is generated by setting both the DMA RAM Write Collision Flag bit (XWCOLx) and the Peripheral Write Collision Flag bit (PWCOLx) in the DMA Controller Status 0 register (DMACS0). For more information, refer to 38.10 "Data Write Collisions".

**First Transfer Forced** CPU Write to FORCE Bit &\_DMA BASE Peripheral DMA Transfer 1 Channel 6 1 Data 0 & DMA BASE + DMA3STA Data 1 & DMA BASE + DMA3STA + 1 & DMA BASE + DMA3STA + 2 Data 2 **Subsequent Transfers Requested by Peripheral DMA Request** & DMA BASE Transfer 2 Peripheral DMA Channel 6 Data 0 & DMA BASE + DMA3STA & DMA BASE + DMA3STA + 1 Data 1 & DMA BASE + DMA3STA + 2 Data 2

Figure 38-19: Data Transfer Initiated in Manual Mode

#### 38.6.11 Null Data Write Mode

Null Data Write mode is the most useful in applications in which sequential reception of data is required without any data transmission like SPI.

The SPI is essentially a simple shift register, clocking a bit of data in and out for each clock period. However, an unusual situation arises when the SPI is configured in Master mode (that is, when the SPI is to be the source of the clock) but only received data is of interest. In this case, something must be written to the SPI data register to start the SPI data clock and receive the external data.

It would be possible to allocate two DMA channels, one for data reception and the other to simply feed null, or zero, data into the SPI. However, a more efficient solution is to use a DMA Null Data Write mode that automatically writes a null value to the SPI data register after each data element has been received and transferred by the DMA channel configured for peripheral data reads.

If the Null Data Peripheral Write Mode Select bit, NULLW (DMAxCON<11>) is set, and the DMA channel is configured to read from the peripheral, then the DMA channel also executes a null (all zeros) write to the peripheral address in the same cycle as the peripheral data read. This write occurs across the peripheral bus concurrently with the (data) write to the DPSRAM (across the DPSRAM bus). Figure 38-20 illustrates this mode.

During normal operation in this mode, the Null Data Write can only occur in response to a peripheral DMA request (that is, after data has been received and is available for transfer). An initial CPU write to the peripheral is required to start reception of the first word, after which the DMA takes care of all subsequent peripheral (null) data writes. That is, the CPU null write starts the SPI (master) sending/receiving data which in turn eventually generates a DMA request to move the newly received data.

Alternately, a forced DMA transfer could be used to 'kick start' the process. However, this will also include a redundant peripheral read (data not valid) and an associated DPSRAM pointer adjustment, which must be taken into account. Example 38-12 demonstrates the code SPI and DMA with Null Data Write mode.

Null Data Writes
generated by DMA

Tansfer 1

Data 0

Data 1

Data 1

Data 2

Data 1

Data 2

Data 1

Data 2

Data 1

Data 2

Figure 38-20: Data Transfer with Null Data Write Mode

#### Example 38-12: SPI and DMA with Null Data Write Mode

```
Set up SPI for Master mode:
SPI1CON1bits.MODE16 = 1;
                          //Communication is word-wide (16 bits)
SPI1CON1bits.MSTEN = 1;
                          //Master Mode Enabled
SPI1STATbits.SPIEN = 1;
                          //Enable SPI Module
Set up DMA Channel 1 for Null Data Write mode:
unsigned int BufferA[16] __attribute__((space(dma)));
unsigned int BufferB[16] __attribute__((space(dma)));
DMA1CON = 0 \times 0802;
                            // Null Write, Continuous, Ping-Pong,
                           // Post-Increment, Periph-to-RAM
DMA1CNT = 15;
                           // Transfer 16 words at a time
DMA1REQ = 0x000A;
                          // Select SPI1 as DMA request source
DMA1STA = __builtin_dmaoffset(BufferA);
DMA1STB = __builtin_dmaoffset(BufferB);
DMA1PAD = (volatile unsigned int) &SPI1BUF;
IFSObits.DMA1IF = 0;
DMA1REQbits.FORCE = 1;
                          // Force First word after Enabling SPI
Set up DMA Interrupt Handler:
void attribute ((interrupt, no auto psv)) DMA1Interrupt(void)
  static unsigned int BufferCount = 0; // Keep record of which buffer
                                       // contains Rx Data
  if(BufferCount == 0)
  ProcessRxData(BufferA);
                                      // Process received SPI data in
                                       // DMA RAM Primary buffer
  else
  ProcessRxData(BufferB);
                                      // Process received SPI data in
                                       // DMA RAM Secondary buffer
  BufferCount ^= 1;
  IFSObits.DMA1IF = 0;
                                      // Clear the DMA1 Interrupt Flag
```

# 38.7 STARTING DMA TRANSFER

Before DMA transfers can begin, the DMA channel must be enabled by setting the CHEN bit (DMAxCON<15>) to '1'. When the DMA channel is active, it can be reinitialized by disabling this channel (CHEN = 0), followed by re-enabling it (CHEN = 1). This process resets the DMA transfer count to zero and sets the active DMA buffer to the primary buffer.

When the DMA channel and peripheral are properly initialized, the DMA transfer starts as soon as the peripheral is ready to move data and issues a DMA request. However, some peripherals may not issue a DMA request (and therefore will not start the DMA transfer) until certain conditions exist. In these cases, a combination of different DMA modes and procedures may need to be applied to initiate the DMA transfer, as described in the following sections.

# 38.7.1 Starting DMA with the Serial Peripheral Interface (SPI)

Starting the DMA transfer to/from the SPI peripheral depends upon SPI data direction and Slave or Master mode:

# TX only in Master mode

In this configuration, no DMA request is issued until the first block of SPI data is sent. To initiate DMA transfers, the user application must first send data using the DMA Manual Transfer mode, or it must first write data into the SPI buffer (SPIxBUF) independently of the DMA.

## · RX only in Master mode

In this configuration, no DMA request is issued until the first block of SPI data is received. However, in Master mode, no data is received until SPI transmits first. To initiate DMA transfers, the user application must use DMA Null Data Write mode, and start DMA Manual Transfer mode.

#### RX and TX in Master mode

In this configuration, no DMA request is issued until the first block of SPI data is received. However, in Master mode, no data is received until the SPI transmits it. To initiate DMA transfers, the user application must first send data using the DMA Manual Transfer mode, or it must first write data into the SPIxBUF independently of the DMA.

#### · TX only in Slave mode

In this configuration, no DMA request is issued until the first block of SPI data is received. To initiate DMA transfers, the user application must first send data using the DMA Manual Transfer mode, or it must first write data into the SPIxBUF independently of the DMA.

## RX only in Slave mode

This configuration generates a DMA request as soon as the first SPI data has arrived, so no special steps need to be taken by the user to initiate DMA transfer.

#### RX and TX in Slave mode

In this configuration, no DMA request is issued until the first SPI data block is received. To initiate DMA transfers, the user application must first send data utilizing DMA Manual Transfer mode, or it must first write data into the SPIxBUF independently of the DMA.

# 38.7.2 Starting DMA with the Data Converter Interface (DCI)

Unlike other serial peripherals, the DCI starts transmitting as soon as it is enabled (assuming it is the Master). It constantly feeds synchronous frames of data to the external codec to which it is connected. Before enabling DCI, the user must:

- Configure the DCI as described in 38.5.2 "Peripheral Configuration Setup"
- If connected to a stereo codec, use DMA Manual Transfer mode to initiate the first two data transfers:
  - Set the FORCE bit (DMAxREQ<15>) to transfer the DCI left channel sample
  - Set the FORCE bit (DMAxREQ<15>) for the second time to transfer the DCI right channel sample

After these steps are completed, enable the DCI peripheral (see Example 38-11).

# 38.7.3 Starting DMA with the UART

The UART receiver issues a DMA request as soon as data is received. No special steps need to be taken by the user application to initiate DMA transfer. The UART transmitter issues a DMA request as soon as the UART and transmitter are enabled. This means that the DMA channel and buffers must be initialized and enabled before the UART and transmitter. Ensure that the UART is configured as described in 38.5.2 "Peripheral Configuration Setup" (see Table 38-2).

While configuring for UART reception, the DMA channel word size should be set to 16 bit. This configures the DMA channel to read 16 bits from the UART module when data is available to be read. The lower byte of the data represents the actual data byte received by the UART module. The upper byte of the transferred contains the UART status when the byte was received. Note that reading the UxSTA register when the UART reception is DMA enabled, will not return the status of the Framing Error Status bits, FERR (UxSTA<2>), and Parity Error Status bit, PERR (UxSTA<3>). For more information, refer to **Section 17. "UART"** (DS70188).

Alternately, the UART and UART transmitter can be enabled before the DMA channel is enabled. In this case, the UART transmitter DMA request will be lost, and the user application must issue a DMA request to start DMA transfers by setting the FORCE bit (DMAxREQ <15>).

# 38.8 DMA CHANNEL ARBITRATION AND OVERRUNS

Each DMA channel has a fixed priority. Channel 0 is the highest, and Channel 7 is the lowest. When a DMA transfer is requested by the source, the request is latched by the associated DMA channel. The DMA controller acts as an arbitrator. If no other transfer is underway or pending, the controller grants bus resources to the requesting DMA channel. The DMA controller ensures that the no other DMA channel is granted any resource until the current DMA channel completes its operation.

If multiple DMA requests arrive or are pending, the priority logic within the DMA controller grants resources to the highest priority DMA channel for completing its operation. All other DMA requests remain pending until the selected DMA transfer is complete. If another DMA request arrives while the current DMA transfer is underway, it is also prioritized with any pending DMA requests, ensuring that the highest priority request is always serviced after the current DMA transfer has completed.

Because the DMA channels are prioritized, it is possible that a DMA request will not be immediately serviced and will become pending. The request will remain pending until all higher priority channels have been serviced. If another interrupt arrives before the DMA controller has cleared the original DMA request, and the interrupt is the same type as the pending interrupt, a data overrun will occur.

A data overrun is defined as the condition where new data has arrived in a peripheral data buffer before the DMA could move the prior data. Some DMA-ready peripherals can detect data overruns and issue a CPU interrupt (if the corresponding peripheral error interrupt is enabled), as shown in Table 38-5.

Table 38-5: Overrun Handling by DMA-Ready Peripherals

DMA-Ready Peripheral	Data Overrun Handling
SPI	Data waiting to be moved by the DMA channel is not overwritten by additional incoming data. Subsequent incoming data is lost and the SPI Receive Overflow (SPIROV) bit is set in the SPI Status register (SPIxSTAT<6>). Also the SPIx fault interrupt is generated if the SPI Error Interrupt Enable bit (SPIxEIE) is set in the Interrupt Enable Control register (IECx), in the Interrupt Controller module.
UART	Data waiting to be moved by the DMA channel is not overwritten by additional incoming data. Subsequent incoming data is lost and the Overflow Error bit (OERR) is set in the UART Status register (UxSTA<1>). Also, the UARTX Error interrupt is generated if the UART Error Interrupt Enable bit (UxEIE), is set in the IECx register in the Interrupt Controller module.
DCI	Data waiting to be moved by the DMA channel is overwritten by additional incoming data and the Receive Overflow bit (ROV) is set in the DCI Status register (DCISTAT<1>). Also the DCI fault interrupt is generated if the DCI Error Interrupt Enable bit, DCIEIE (IEC3<11>), is set in the Interrupt Controller module.
10-bit/12-bit ADC	Data waiting to be moved by the DMA channel is overwritten by additional incoming data.  The overrun condition is not detected by the ADC.
Other DMA-Ready Peripherals	No data overrun can occur.

Data overruns are only detectable in hardware when the DMA controller is moving data from a peripheral to DPSRAM. DMA data transfers from DPSRAM to a peripheral (based on, for example, a buffer empty interrupt) will always execute. Any consequential DPSRAM data overruns must be detected using software. The duplicate DMA request is ignored and the pending request remains pending. As usual, the DMA channel clears the DMA request when the transfer is eventually completed. If the CPU does not intervene in the meantime, the data transferred will be the latest (overrun) data, and the prior data will be lost.

The user application can handle an overrun error in different ways, depending on the nature of the data source. Data recovery and resynchronization of the DMAC with its data source/sink is a task that is highly application dependent. For streaming data, such as that from a CODEC (through the DCI peripheral), the application can ignore the lost data. After fixing the source of the problem (if possible), the DMA interrupt handler should attempt to resynchronize the DMAC and DCI so that data is again buffered correctly. The user application should react fast enough to prevent any further overruns occurring.

By the time the peripheral overrun interrupt is entered, the pending DMA request will have already moved the overrun data value to the address where the lost data should have gone. That data can be moved to its correct address, and a null data value inserted into the missing data slot. The DPSRAM address of the channel can then be adjusted accordingly. Subsequent DMA requests to the faulted channel then initiate transfers as normal to the corrected DPSRAM address. For applications where the data cannot be lost, the peripheral overrun interrupt will need to abort the current block transfer, reinitialize the DMA channel and request a data resend before it is lost.

# 38.9 DEBUGGING SUPPORT

To improve user visibility into DMA operation during debugging, the DMA controller includes several status registers that can provide information on which DMA channel executed the Last DMAC Channel Active bits (LSTCH<3:0>) in the DMA Controller Status Register 1 (DMACS1<11:8>), which DPSRAM address offset it was accessing (DSADR<15:0> bits (DSADR<15:0>), and from which buffer (PPSTx bits in the DMACS1 register).

The PPSTx bits will get updated after first byte/word in the new block (new ping-pong half) gets transferred by the DMA controller or when user clears associated DMA interrupt flag.

# 38.10 DATA WRITE COLLISIONS

The CPU and DMA channel may simultaneously read or read/write to any DPSRAM or DMA-ready peripheral data register. The only constraint is that the CPU and DMA channel should not simultaneously write to the same address. Under normal circumstances, this situation should never arise. However, if for some reason it does, then it will be detected and flagged, and a DMA fault trap will be initiated. The CPU write will also be allowed to take priority, though that is mainly to provide predictable behavior and is otherwise of little practical consequence.

It is also permissible for the DMA channel to write to a location during the same bus cycle that the CPU is reading it, and vice versa. However, it should be noted that the resultant reads are of the old data, not the data written during that bus cycle. Also note that this situation is considered normal operation and does not result in any special action being taken.

In the event of a simultaneous write to the same DPSRAM address by the CPU and DMA channel, the XWCOLx bit is set in the DMA Controller Status 0 (DMACS0) register. In the event of a simultaneous write to the same peripheral address by the CPU and DMA channel, the PWCOLx bit is set in the DMA Controller Status 0 (DMACS0) register. All collision status flags are logically ORed together to generate a common DMAC fault trap. The XWCOLx and PWCOLx flags are automatically cleared when the user application clears the DMAC Error Status bit (DMACERR) in the Interrupt Controller register (INTCON1<5>).

Subsequent DMA requests to a channel that has a write collision error are ignored while the XWCOLx or PWCOLx remain set.

Under write collision conditions, either XWCOLx or PWCOLx could be set due to write collision, but not both. Setting both flags is used as a unique means to flag a rare manual trigger event error without adding more status bits (see **38.6.10** "Manual Transfer Mode").

Example 38-13 illustrates DMA controller trap handling with DMA Channel 0 transferring data from the DPSRAM to the peripheral (UART), and DMA Channel 1 transferring data from the peripheral (ADC) to the DPSRAM.

#### Example 38-13: DMA Controller Trap Handling

# 38.11 OPERATION IN POWER-SAVING MODES

# 38.11.1 Sleep Mode

The DMA is disabled during Sleep mode. Prior to entering Sleep mode, it is recommended (though not essential) that all DMA channels either be allowed to complete the block transfer that is currently underway, or be disabled.

#### 38.11.2 Idle Mode

DMA is a second bus master within the system and therefore, can continue to transfer data when the CPU has entered Idle mode. Provided the peripheral being serviced by the DMA channel is configured for operation during Idle mode, data may be transferred to and from the peripheral and DPSRAM. When the block transfer is complete, the DMA channel issues an interrupt (if enabled) and wakes up the CPU. The CPU then runs the interrupt service handler.

Each peripheral includes a Stop in Idle control bit. When set, this control bit disables the peripheral while the CPU is in Idle mode. If the DMAC is being used to transfer data in and/or out of the peripheral, engaging the Stop in Idle feature within the peripheral will, in effect, also disable the DMA channel associated with the peripheral.

#### **REGISTER MAP** 38.12

A summary of the registers associated with the DMA controller is provided in Table 38-6.

Table 38-6: **DMA-Associated Register Map** 

File Name	Bit 15	Bit 14	Bit 13	Bit 12	Bit 11	Bit 10	Bit 9	Bit 8	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0	All Resets	
DMA0CON	CHEN	SIZE	DIR	HALF	NULLW		_	_	_	_	AMODE	-<1·0>	_		MODE	-<1·0>	0000	
DMA0REQ	FORCE	_		_	_		_	_		IRQSEL<6:0>								
DMA0STA	STA<15:0>														0000			
DMA0STB									<15:0>								0000	
DMA0PAD									<15:0>								0000	
DMA0CNT	CNT<9:0>													0000				
DMA1CON	CHEN	SIZE	DIR	HALF	NULLW	_	_	_	_	_	AMODE		_	_	MODE	-<1:0>	0000	
DMA1REQ	FORCE	_	_	_	_	_	_	_	_		702.		QSEL<6:0>				0000	
DMA1STA	STA<15:0>													0000				
DMA1STB	STB<15:0>														0000			
DMA1PAD	PAD<15:0>													0000				
DMA1CNT	CNT<9:0>												0000					
DMA2CON	CHEN	SIZE	DIR	HALF	NULLW		_	_	_	_	AMODE		_	_	MODE	-<1·0>	0000	
DMA2REQ	FORCE			_	_	_	_	_					QSEL<6:0>				0000	
DMA2STA	STA<15:0>													0000				
DMA2STB	STB<15:0>													0000				
DMA2PAD	PAD<15:0>													0000				
DMA2CNT	_	_	_	_	_	_					CNT<9	):0>					0000	
DMA3CON	CHEN	SIZE	DIR	HALF	NULLW	_	_	_	_	_	AMODE		_	_	MODE	E<1:0>	0000	
DMA3REQ	FORCE		_	_	_		_	_	_				QSEL<6:0>				0000	
DMA3STA								STA<	<15:0>	1							0000	
DMA3STB									<15:0>								0000	
DMA3PAD								PAD•	<15:0>								0000	
DMA3CNT	_	_	_	_	_	_					CNT<9	):0>					0000	
DMA4CON	CHEN	SIZE	DIR	HALF	NULLW		_	_	_	_	AMODE	E<1:0>	_	_	MODE	E<1:0>	0000	
DMA4REQ	FORCE	_	_	_	_	_	_	_	_		I.	IR	QSEL<6:0>				0000	
DMA4STA								STA	<15:0>								0000	
DMA4STB								STB	<15:0>								0000	
DMA4PAD								PAD•	<15:0>								0000	
DMA4CNT	_	_	_	_	_	_					CNT<9	):0>					0000	
DMA5CON	CHEN	SIZE	DIR	HALF	NULLW	_	_	_	_	_	AMODE	E<1:0>	_	_	MODE	E<1:0>	0000	
DMA5REQ	FORCE	_	_	_	_	_	_	_	_			IR	QSEL<6:0>				0000	
DMA5STA			•	•				STA	<15:0>								0000	
DMA5STB	İ							STB	<15:0>								0000	
DMA5PAD	PAD<15:0>												0000					
DMA5CNT	_	_	_	_	_	_					CNT<9	):0>					0000	
DMA6CON	CHEN	SIZE	DIR	HALF	NULLW	_	_	_	_	_	AMODE	E<1:0>	_	_	MODE	E<1:0>	0000	
DMA6REQ	FORCE	_	_	_	_	_	_	_	_			IR	QSEL<6:0>				0000	

x = unknown value on Reset, — = unimplemented, read as '0'. Reset values are shown in hexadecimal. Not all bits are available on all devices. Refer to the specific device data sheet for availability. Legend:




Table 38-6: DMA-Associated Register Map (Continued)

File Name	Bit 15	Bit 14	Bit 13	Bit 12	Bit 11	Bit 10	Bit 9	Bit 8	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0	All Resets
DMA6STA	STA<15:0>											I	0000				
DMA6STB	STB<15:0>															0000	
DMA6PAD								PAD<	<15:0>								0000
DMA6CNT		CNT<9:0>														0000	
DMA7CON	CHEN	SIZE	DIR	HALF	NULLW	_	_	AMODE<1:0> MODE<1:0							E<1:0>	0000	
DMA7REQ	FORCE IRQSEL<6:0>												0000				
DMA7STA	STA<15:0>															0000	
DMA7STB	STB<15:0>															0000	
DMA7PAD	PAD<15:0>															0000	
DMA7CNT		I			1	ı					CNT<9	-					0000
DMACS0	PWCOL7	PWCOL6	PWCOL5	PWCOL4	PWCOL3			PWCOL0	XWCOL7	XWCOL6	XWCOL5	XWCOL4	XWCOL3	XWCOL2			0000
DMACS1	_	-	_	_		LSTCH	H<3:0>		PPST7	PPST6	PPST5	PPST4	PPST3	PPST2	PPST1	PPST0	0000
DSADR								DSADF	R<15:0>								0000
INTCON1	NSTDIS	I		_	_		_	_	-	_	DMACERR	-	_		_	_	0000
IFS0		DMA1IF	_		1	ı		_	I	-	_	DMA0IF	_		_	_	0000
IFS1		I			1	ı		DMA2IF	I	-	_	ı	_		_	_	0000
IFS2	_	DMA4IF	_	_	_	-	_	_	ı	_	_	DMA3IF	_	_	_	_	0000
IFS3	_	-	DMA5IF	_	_	_	_	_	-	_	_	_	_	_	_	_	0000
IFS4	_	I	_	_	_	_	_	_	1	_	DMA7IF	DMA6IF	_	_	_	_	0000
IEC0	_	DMA1IE	_	_	_	-	_	_	ı	_	_	DMA0IE	_	_	_	_	0000
IEC1	_	-	_	_	_	_	_	DMA2IE	-	_	_	_	_	_	_	_	0000
IEC2	_	DMA4IE	_	_	_	_	_	_	-	_	_	DMA3IE	_	_	_	_	0000
IEC3	_	ı	DMA5IE	_	_	-	_	_	ı	_	_	-	_	_	_	_	0000
IEC4	_	-	_	_	_	_	_	_	-	_	DMA7IE	DMA6IE	_	_	_	_	0000
IPC1		I			1	ı		_	I	-	_	I	_	DN	//A0IP<2:0	>	4444
IPC3	_	-	_	_	_	D	MA1IP<2:0	)>	-	_	_	_	_	_	_	_	4444
IPC6	_	1	_	_	_	-		_	1	_	_	-	— DMA2IP<2:0>			4444	
IPC9	_	1	_	_	_	-		_	1	- — — — DMA3IP<2:0		>	4444				
IPC11	_	1	_	_	_	D	)MA4IP<2:(	)>	-	_	_	_	_		_	_	4444
IPC15		ı		_	_	-	_	_	ı		DMA5IP<2:0>		_		_	_	4444
IPC17	_	1	_	_	-	-	DMA7IP<2:0> DMA6IP<2:0>							>	4444		

Legend: x = unknown value on Reset, — = unimplemented, read as '0'. Reset values are shown in hexadecimal.

Note: Not all bits are available on all devices. Refer to the specific device data sheet for availability.

# 38.13 RELATED APPLICATION NOTES

This section lists application notes that are related to this section of the manual. These application notes may not be written specifically for the dsPIC33F/PIC24H product family, but the concepts are pertinent and could be used with modification and possible limitations. The current application notes related to the Direct Memory Access (DMA) (Part III) module are:

Title Application Note #

No related application notes at this time.

Note: Please visit the Microchip web site (www.microchip.com) for additional Application Notes and code examples for the dsPIC33F/PIC24H family of devices.

# 38.14 REVISION HISTORY

# **Revision A (October 2007)**

This is the initial released version of the document

# Revision B (February 2008)

Updated DMA Channel to Peripheral Associations table (see Table 38-1). Value was changed to 0x608 in the column with title "DMAxPAD Register Values to Write to Peripheral" for the PMP Master Data Transfer row.

# Revision C (May 2012)

This revision incorporates the following updates:

- · Examples:
  - Updated Example 38-6 and Example 38-7
- · Sections:
  - Updated 38.7.3 "Starting DMA with the UART"
  - Updated 38.9 "Debugging Support"
- · Tables:
  - Removed the Address column in Table 38-1
- · Minor updates to text and formatting were incorporated throughout the document

## Note the following details of the code protection feature on Microchip devices:

- Microchip products meet the specification contained in their particular Microchip Data Sheet.
- Microchip believes that its family of products is one of the most secure families of its kind on the market today, when used in the intended manner and under normal conditions.
- There are dishonest and possibly illegal methods used to breach the code protection feature. All of these methods, to our knowledge, require using the Microchip products in a manner outside the operating specifications contained in Microchip's Data Sheets. Most likely, the person doing so is engaged in theft of intellectual property.
- Microchip is willing to work with the customer who is concerned about the integrity of their code.
- Neither Microchip nor any other semiconductor manufacturer can guarantee the security of their code. Code protection does not mean that we are guaranteeing the product as "unbreakable."

Code protection is constantly evolving. We at Microchip are committed to continuously improving the code protection features of our products. Attempts to break Microchip's code protection feature may be a violation of the Digital Millennium Copyright Act. If such acts allow unauthorized access to your software or other copyrighted work, you may have a right to sue for relief under that Act.

Information contained in this publication regarding device applications and the like is provided only for your convenience and may be superseded by updates. It is your responsibility to ensure that your application meets with your specifications. MICROCHIP MAKES NO REPRESENTATIONS OR WARRANTIES OF ANY KIND WHETHER EXPRESS OR IMPLIED, WRITTEN OR ORAL, STATUTORY OR OTHERWISE, RELATED TO THE INFORMATION, INCLUDING BUT NOT LIMITED TO ITS CONDITION, QUALITY, PERFORMANCE, MERCHANTABILITY OR FITNESS FOR PURPOSE. Microchip disclaims all liability arising from this information and its use. Use of Microchip devices in life support and/or safety applications is entirely at the buyer's risk, and the buyer agrees to defend, indemnify and hold harmless Microchip from any and all damages, claims, suits, or expenses resulting from such use. No licenses are conveyed, implicitly or otherwise, under any Microchip intellectual property rights.

#### **Trademarks**

The Microchip name and logo, the Microchip logo, dsPIC, Keeloq, Keeloq logo, MPLAB, PIC, PICmicro, PICSTART, PIC<sup>32</sup> logo, rfPIC and UNI/O are registered trademarks of Microchip Technology Incorporated in the U.S.A. and other countries.

FilterLab, Hampshire, HI-TECH C, Linear Active Thermistor, MXDEV, MXLAB, SEEVAL and The Embedded Control Solutions Company are registered trademarks of Microchip Technology Incorporated in the U.S.A.

Analog-for-the-Digital Age, Application Maestro, chipKIT, chipKIT logo, CodeGuard, dsPICDEM, dsPICDEM.net, dsPICworks, dsSPEAK, ECAN, ECONOMONITOR, FanSense, HI-TIDE, In-Circuit Serial Programming, ICSP, Mindi, MiWi, MPASM, MPLAB Certified logo, MPLIB, MPLINK, mTouch, Omniscient Code Generation, PICC, PICC-18, PICDEM, PICDEM.net, PICkit, PICtail, REAL ICE, rfLAB, Select Mode, Total Endurance, TSHARC, UniWinDriver, WiperLock and ZENA are trademarks of Microchip Technology Incorporated in the U.S.A. and other countries.

SQTP is a service mark of Microchip Technology Incorporated in the U.S.A.

All other trademarks mentioned herein are property of their respective companies.

© 2007-2012, Microchip Technology Incorporated, Printed in the U.S.A., All Rights Reserved.

Printed on recycled paper.

ISBN: 978-1-62076-274-5

# QUALITY MANAGEMENT SYSTEM CERTIFIED BY DNV = ISO/TS 16949=

Microchip received ISO/TS-16949:2009 certification for its worldwide headquarters, design and wafer fabrication facilities in Chandler and Tempe, Arizona; Gresham, Oregon and design centers in California and India. The Company's quality system processes and procedures are for its PIC® MCUs and dsPIC® DSCs, KEELOQ® code hopping devices, Serial EEPROMs, microperipherals, nonvolatile memory and analog products. In addition, Microchip's quality system for the design and manufacture of development systems is ISO 9001:2000 certified.



# Worldwide Sales and Service

#### **AMERICAS**

Corporate Office 2355 West Chandler Blvd.

Chandler, AZ 85224-6199 Tel: 480-792-7200 Fax: 480-792-7277

Technical Support: http://www.microchip.com/

support

Web Address:

www.microchip.com

Atlanta Duluth, GA

Tel: 678-957-9614 Fax: 678-957-1455

**Boston** 

Westborough, MA Tel: 774-760-0087 Fax: 774-760-0088

Chicago Itasca, IL

Tel: 630-285-0071 Fax: 630-285-0075

Cleveland

Independence, OH Tel: 216-447-0464 Fax: 216-447-0643

**Dallas** 

Addison, TX Tel: 972-818-7423 Fax: 972-818-2924

Detroit

Farmington Hills, MI Tel: 248-538-2250 Fax: 248-538-2260

Indianapolis Noblesville, IN

Tel: 317-773-8323 Fax: 317-773-5453

Los Angeles

Mission Viejo, CA Tel: 949-462-9523 Fax: 949-462-9608

Santa Clara

Santa Clara, CA Tel: 408-961-6444 Fax: 408-961-6445

Toronto

Mississauga, Ontario,

Canada

Tel: 905-673-0699 Fax: 905-673-6509

#### ASIA/PACIFIC

**Asia Pacific Office** 

Suites 3707-14, 37th Floor Tower 6, The Gateway Harbour City, Kowloon Hong Kong

Tel: 852-2401-1200 Fax: 852-2401-3431

**Australia - Sydney** Tel: 61-2-9868-6733 Fax: 61-2-9868-6755

China - Beijing

Tel: 86-10-8569-7000 Fax: 86-10-8528-2104

China - Chengdu Tel: 86-28-8665-5511

Fax: 86-28-8665-7889 China - Chongqing

Tel: 86-23-8980-9588 Fax: 86-23-8980-9500

**China - Hangzhou** Tel: 86-571-2819-3187 Fax: 86-571-2819-3189

China - Hong Kong SAR

Tel: 852-2401-1200 Fax: 852-2401-3431

**China - Nanjing** Tel: 86-25-8473-2460

Fax: 86-25-8473-2470 China - Qingdao

Tel: 86-532-8502-7355 Fax: 86-532-8502-7205

**China - Shanghai** Tel: 86-21-5407-5533 Fax: 86-21-5407-5066

**China - Shenyang** Tel: 86-24-2334-2829

Fax: 86-24-2334-2393 **China - Shenzhen**Tel: 86-755-8203-2660

Fax: 86-755-8203-1760

**China - Wuhan** Tel: 86-27-5980-5300

Fax: 86-27-5980-5118 China - Xian

Tel: 86-29-8833-7252 Fax: 86-29-8833-7256

**China - Xiamen** Tel: 86-592-2388138 Fax: 86-592-2388130

**China - Zhuhai** Tel: 86-756-3210040 Fax: 86-756-3210049

#### ASIA/PACIFIC

India - Bangalore

Tel: 91-80-3090-4444 Fax: 91-80-3090-4123

India - New Delhi

Tel: 91-11-4160-8631 Fax: 91-11-4160-8632

India - Pune

Tel: 91-20-2566-1512 Fax: 91-20-2566-1513

**Japan - Osaka** Tel: 81-66-152-7160

Fax: 81-66-152-9310

Japan - Yokohama

Tel: 81-45-471- 6166 Fax: 81-45-471-6122

**Korea - Daegu** Tel: 82-53-744-4301 Fax: 82-53-744-4302

Korea - Seoul

Tel: 82-2-554-7200 Fax: 82-2-558-5932 or 82-2-558-5934

Malaysia - Kuala Lumpur

Tel: 60-3-6201-9857 Fax: 60-3-6201-9859 Malaysia - Penang

Tel: 60-4-227-8870 Fax: 60-4-227-4068

Philippines - Manila Tel: 63-2-634-9065

Fax: 63-2-634-9069

Singapore

Tel: 65-6334-8870 Fax: 65-6334-8850

Taiwan - Hsin Chu

Tel: 886-3-5778-366 Fax: 886-3-5770-955

**Taiwan - Kaohsiung** Tel: 886-7-536-4818

Fax: 886-7-330-4818

Fax: 886-7-330-9305

Taiwan - Taipei

Tel: 886-2-2500-6610 Fax: 886-2-2508-0102

Thailand - Bangkok Tel: 66-2-694-1351

Fax: 66-2-694-1350

#### **EUROPE**

Austria - Wels

Tel: 43-7242-2244-39 Fax: 43-7242-2244-393

Denmark - Copenhagen

Tel: 45-4450-2828 Fax: 45-4485-2829

France - Paris

Tel: 33-1-69-53-63-20 Fax: 33-1-69-30-90-79

Germany - Munich

Tel: 49-89-627-144-0 Fax: 49-89-627-144-44

Italy - Milan

Tel: 39-0331-742611 Fax: 39-0331-466781

Netherlands - Drunen Tel: 31-416-690399

Fax: 31-416-690340 **Spain - Madrid** 

Tel: 34-91-708-08-90 Fax: 34-91-708-08-91

**UK - Wokingham** Tel: 44-118-921-5869 Fax: 44-118-921-5820

11/29/11