Use of the computers in the Linux lab via remote login

Available computers:

Status27.04.2023			
Computer	Connected board	USB	DA-Wandler
ei-lan-393.othr.de	-		
ei-lan-394.othr.de	MicroZED with Carrierboard	USB0	
ei-lan-395.othr.de	-		
ei-lan-396.othr.de	CORA Z7		-
ei-lan-397.othr.de	CORA Z7		Pmodda2
ei-lan-398.othr.de	CORA Z7		Pmodda2
ei-lan-399.othr.de	CORA Z7		RC-Tiefpass 4,7kW 97nF an JA3_P
ei-lan-400.othr.de	CORA Z7		Pmodda3
ei-lan-401.othr.de	CORA Z7		Pmodda2

Table 1: CAE-Labor Rechner


You can log in to the computers with your university account.

A local home is set up at the first login. The home directories are not shared between the computers and there is no backup.


So it would be a good idea to back up your data to the personal RZ network drive at /srv/hsr/home/abc12345/.

Use of the computers is restricted to members of the AD group EI_CAE Lab Users. This group currently includes the professors, staff and students of the EI faculty.

- 1. VPN-Verbindung mit OTH-Netz herstellen (bei Zugriff von extern!)
- 2. "Remote Desktop" öffnen (noch Windows):



3. Linux Login erscheint, übliche Userdaten wie im OTH-Netz:



Vivado auf den CAE-Labor Rechnern starten

Terminalfenster öffnen:

