Start-up after power cut/pc reboot

Monday, 6 March 2017 11:15

- First figure out the ethernet address of the FC7 sudo tshark -i eth1
- 2) Add ethernet address to /etc/hosts sudo vim /etc/hosts
- 3) Restart RARP daemon

sudo /etc/init.d/rarpd restart

4) ping fc7

```
sudo /etc/init.d/rarpd start
sudo /etc/init.d/controlhub start
sudo a
```

aa:bb:cc:dd:ee:50 icfc7 08:00:30:00:23:72 icfc7

- 1) check that SD card is plugged in and that FC7 is in desktop mode and that FMC is in FMC L8 for K.FW
- 2) sudo /etc/init.d/rarpd restart //start rarp deamon for fc7 ip address assignment
- 3) sudo /etc/init.d/iptables stop //disable firewall for monitoring webpage
- 4) open /etc/ethers with sudo privileges and editor of choice ;-)
- 5) uncomment the line starting with the 08:... mac address and comment the one with aa:bb:...
- 6) ping icfc7 to see if you have connection with the correct mac address (arp -e might also work)
- 7) cd Ph2_ACF
- 8) source setup.sh
- 9) fpgaconfig -c settings/Cbc3HWDescription.xml -l to list the FW images on the SD card
- 10) fpgaconfig -c settings/Cbc3HWDescription.xml -i CBC3TESTV6.bin to load the correct FW image (this will make the mac address change from 08:... to aa:bb:..
- 11) back to /etc/ethers and undo the changes of step 4)
- 12) arp -e to see that the icfc7 host shows the correct aa:bb:... MAC address
- 13) ping icfc7 to see if it responds correctly
- 14) II /dev to see if symlinks for ArduinoNano and HMP4040 exist
- 15) most probably the HMP is not going to be there: in that case $cd \sim Ph2_USBInstDriver/$, sudo ./init_serial.sh, sudo ./init_usbtmc.sh
- 16) check in /dev if you have the symlinks and that the usbtmcX device files exist
- 17) in case of problems unplug HMP4040 usb cable and retry 14)

```
31.07.2017 10:58 ||I| Configuring HW parsed from .xml file:
31.07.2017 10:59 ||I| FW version: 2.6.1
31.07.2017 10:59 ||I| BoardType: CBC3
31.07.2017 10:59 ||II BoardType: CBC3
31.07.2017 10:59 ||II Error: IZC Bus FSM did not go to ready!
31.07.2017 10:59 ||II Fror, did not receive the correct number of *Pings*; expected: 1, received: 1 - or IZC FSM did not go to ready!
31.07.2017 10:59 ||II Successfully configured Board 0
31.07.2017 10:59 ||II Successfully configured Cbc 0
```

I2C FSM not responding fix?

looks like I had not changed the mac address of the fc7 back to aa:.....

loading new firmware onto SD card