

SIM68V Power Saving Mode Application Note

AN_Interface Design_V1.00





Document Title:	SIM68V Power Saving Mode Application Note	
Version:	1.00	
Date:	2013-09-30	
Status:	Released	
Document Control ID:	SIM68V_ Power Saving Mode Application Note_V1.00	

General Notes

SIMCom offers this information as a service to its customers, to support application and engineering efforts that use the products designed by SIMCom. The information provided is based upon requirements specifically provided to SIMCom by the customers. SIMCom has not undertaken any independent search for additional relevant information, including any information that may be in the customer's possession. Furthermore, system validation of this product designed by SIMCom within a larger electronic system remains the responsibility of the customer or the customer's system integrator. All specifications supplied herein are subject to change.

Copyright

This document contains proprietary technical information which is the property of SIMCom Limited., copying of this document and giving it to others and the using or communication of the contents thereof, are forbidden without express authority. Offenders are liable to the payment of damages. All rights reserved in the event of grant of a patent or the registration of a utility model or design. All specification supplied herein are subject to change without notice at any time.

Copyright © Shanghai SIMCom Wireless Solutions Ltd. 2013



Contents

Contents	3
Version history	4
1 Introduction	5
2 Application Circuit	5
3 Hardware Design Note	
4 Power Saving Mode Configuration	6
4.1 Sleep Mode	6
4.2 Backup Mode	7
4.3 Periodic Mode	7
4.4 AlwaysLocate Mode	7



Version history

Date	Version	Description of change	Author
2013-09-30	V1.00	initial	Ma Honggang



1 Introduction

This document aims to guide customer design the battery based products which are sensitive to the consumption, including the hardware design and system configuration, and this document applies to SIM28, SIM68R, SIM68VB and SIM68RB modules.

2 Application Circuit

At the beginning of the design, customer should pay attention to the consumption of the product, for the SIM68V supports power saving mode, so the appropriate design would take great benefits to the customer and the consumption can reach to the best.




Figure 1: Application circuit

3 Hardware Design Note

The main power of the module PIN VCC can be powered by a battery, the voltage is from 2.8V to 4.3V. The key of the power saving mode is V_BACKUP PIN of the module, which is the power interface of the internal RTC circuit, a coin battery or a larger capacitance is suggested as the above figure shows, customer should notice that the module does not support battery charging function, and if a coin battery applied in the design, the charging circuit should be taken into consideration.



4 Power Saving Mode Configuration

SIM68V supports power saving modes for reducing average power consumption like sleep mode, Backup mode, periodic mode and AlwayLocateTM mode. Customers can send PMTK commands to set module enter the modes mentioned above.

Table 0: Classification of power saving mode

Power saving mode	Sleep mode			
	Backup mode			
	Periodic mode	Periodic backup mode		
		Periodic Sleep mode		
	AlwaysLocate mode	AlwayLocateTM Sleep mode		
		AlwayLocateTM backup mode		

4.1 Sleep Mode

In this mode the receiver stays at full on power state. This mode can be waked up by the host by sending the command through the communication interface.

Sleep mode means a low quiescent (340uA type.) power state, non-volatile RTC, and backup RAM block is powered on. Other internal blocks like digital baseband and RF are internally powered off. The power supply input VCC shall be kept active all the time, even during sleep mode.

Waking up from and entering into sleep mode is controlled by UART interface, any byte typing-in will drag SIM68V out of sleep mode.

Table 0: How to enter sleep mode

DataField: PMTK161,Type			
Example: \$PMTK161,0*28 <cr><lf></lf></cr>			
Name	Unit	Default	Description
Type			Sleep type:
			'0' = Stop mode
			'1' = Sleep mode
*Enter any byte the module can be waked up from SLEEP mode.			



4.2 Backup Mode

In this mode the SIM68V must be supplied by the backup battery and it can help to count down the time for backup mode. Software on host side to send the command through the communication interface to into the backup mode. Module in backup mode can reach the lowest consumption of about 14uA.

User can refer to table 3 to config module to backup mode. Set "Type" as "4" to enter perpetual backup mode.

4.3 Periodic Mode

In this mode the SIM68V enters tracking and backup modes according to the interval configured by users in the commands. See table 3 for details.




Figure 2: Periodic mode

4.4 AlwaysLocate Mode

AlwayLocateTM is an intelligent controller of SIM68V periodic mode. Depending on the environment and motion conditions, SIM68V can adaptive adjust the on/off time to achieve balance of positioning accuracy and power consumption.






Figure 3: AlwaysLocate mode

Table 0: How to enter periodic mode and AlwaysLocate Mode

DataField:	PMTK225,	Type, Run time,	Sleep time,	Second run t	ime, Second s	leep time
------------	----------	-----------------	-------------	--------------	---------------	-----------

Example: How to enter Periodic modes

Periodic Backup mode

PMTK225,0

PMTK223,1,25,180000,60000

PMTK225,1,3000,12000,18000,72000

Periodic Sleep mode

PMTK225,0

PMTK223,1,25,180000,60000

PMTK225,2,3000,12000,18000,72000

Example: How to enter AlwaysLocate modes

AlwaysLocate Sleep

PMTK225,0

PMTK225,8

AlwaysLocate Backup

PMTK225,0

PMTK225,9

Name	Unit	Default	Description
Type			Set operation mode of power saving:
			'0': Back to normal mode
			'1' Periodc backup mode
			'2' Periodic Sleep mode
			'4': Perpetual backup mode
			'8': AlwaysLocate Sleep mode



SIM68V Power Saving Mode Application Note

		'9': AlwaysLocate backup mode
Run time	msec	Duration to fix for (or attempt to fix for) before switching from running mode back to a minimum power sleep mode. '0': Disable >= '1000': Enable Range: [1000~518400000]
Sleep time	msec	Interval to come out of a minimum power sleep mode and start running in order to get a new position fix. Range: [1000~518400000]
Second run time	msec	Duration [] to fix for (or attempt to fix for) before switching from running mode back to a minimum power sleep mode. '0': Disable >= '1000': Enable Range: [Second set both 0 or 1000~518400000]
Second sleep time	msec	Interval to come out of a minimum power sleep mode and start running in order to get a new position fix. Range: [Second set both 0 or 1000~518400000]

Contact us:

Shanghai SIMCom Wireless Solutions Ltd

Add: SIM Technology Building A,

No. 633, Jinzhong Road, Shanghai, P. R. China 200335

Tel: +86 21 3252 3300 Fax: +86 21 3252 3301 URL: <u>www.sim.com/wm</u>