


CISCO ROUTER STARTUP PROCEDURE



THE CISCO ROUTER STRUCTURE

RAM			NVRAM	FLASH	INTERFACES
<u>Internetwork IOS</u> Show version			<u>Backup Config File</u> Show startup-config	<u>OS</u> Show Flash	<u>E0.S0.T0</u> Show Interfaces
<u>Programs</u> Show Processes CPU Show Protocols	<u>Dynamic Config Info</u> Show Running-config	<u>Tables & Buffers</u> Show mem Show ip route			