Equipment Model

1 Equipment Model Overview

The equipment model represents the various manageable physical components of the Network Element (circuit packs or field replaceable units or also, fan, fuse panel, power supply, etc.).

The Equipment Holder Class represents an abstraction of Rack, Shelf, Subshelf, Slot and Subslot.

Figure 1 describes the containment and support/supporting relationship of the equipment model. In the solution set (IDL) the Managed Element manager object is a first class IDL object (i.e. an interface) (not shown is this diagram), the Equipment Holder, the Equipment and the Managed Element object classes are also IDL structures.

Note that an equipment is always a leaf in the containment tree. See also examples in Figure 3 and Figure 4 for further explanation of the model.




Figure 1: Equipment Model overview

1.1 Naming Attribute Structure

The naming attribute structure follows the containment hierarchy of the equipment model. When the Equipment Holder object is named by the Managed Element, the Equipment Holder objects are named recursively, (Rack, Shelf, Subshelf, Slot, and Subslot) and the Equipment objects are named by the Equipment Holder object directly containing it. See supporting document objectNaming.pdf for further details and examples on equipment naming.

1.2 Equipment Protection

The modeling of the equipment protection scheme is shown in Figure 2. In the solution set (IDL) the management of the equipment protection is done through the first class IDL object ProtectionMgr_I (i.e. an interface) (not shown is the diagram).




Figure 2: Equipment Protection Model overview

2 Equipment Model Examples

The following diagrams illustrate the model and show how to apply it.

Figure 3 shows a Managed Element with a shelf that is composed of four slots. Slot #2 shows a slot containing a card with sub-slots where only the sub-slot on the top is equipped with circuitry.




Figure 3: Example equipment object model #1




Figure 4: Example explaining object model #2

The interface will allow the NMS to determine for each equipment holder:

- the card that has been physically installed in a holder
- the card that was provisioned (i.e. set as *Expected*) to be in the specific equipment holder.

Note: the term *card* refers to any equipment that may be installed and or provisioned (i.e. set as *Expected*).

Modelling of DSL modems as virtual equipment holders (see also SD1-7 DSLOverview.pdf)

The DSLAM contains a virtual equipment holder (TU-R shelf) that contains virtual equipment holders (slots) each containing a TU-R as virtual equipment. In this case "internal" Topological Links (TLs) are used to represent the DSL lines between the TU-C/O PTPs on PIUs of the main shelf and the TU-R PTPs on PIUs of the TU-R shelf.




Figure 5: Modeling of external equipment as Remote-Units

3 Equipment Holder State Machine

There exists a state machine (see Figure 6) for the values of the holder state:

- i) Empty no equipment is installed and no expected equipment has been identified
- ii) Installed & not expected physically inserted in the ME but not expected
- iii) Expected & not Installed expected but not currently installed
- iv) Installed & Expected expected and currently installed
- v) *Mismatch of Installed & Expected* there is an inconsistency between the expected equipment and the installed equipment

- vi) *Unavailable* –this holder cannot accept the installation or provisioning of equipment (this is typically caused by a double width card installed next to this slot)
- vii) Unknown the EMS does not know the state of the equipment




Figure 6: State Chart Diagram of Equipment Holder State

Revision History

Version	Date	Description of Change
3.0	April 2005	
3.1	March 2006	Figures 1, 2 and 4 updated because of - additional manufacturer attribute in Equipment Holder - additional location attribute in Equipment Holder - additional manufacturerDate attribute in Equipment Holder, Managed Element and Equipment.

Acknowledgements

<firstname></firstname>	<lastname></lastname>	<company></company>

How to comment on the document

Comments and requests for information must be in written form and addressed to the contact identified below:

Keith	Dorking	CIENA	
Phone:	+1 678 867 5007		
Fax:	+1 678 867 5010		
e-mail:	Kdorking@ciena.com		

Please be specific, since your comments will be dealt with by the team evaluating numerous inputs and trying to produce a single text. Thus we appreciate significant specific input. We are looking for more input than wordsmith" items, however editing and structural help are greatly appreciated where better clarity is the result.

8