
LECTURE VII

Timers and Interrupts

This work by the Institute of Electrical and Electronics Engineers, UC Irvine Branch, is licensed under CC BY-NC-SA 4.0

SECTION I **Timers**

Timers



Timers are used by the microcontroller to **control the timing** of program execution or output signals and to **measure time**.

Types of Timers

- Timer types can be distinguished by when the timeout triggers
 - A timeout is an event that occurs after a preset period of time
- A one-shot timer has a single timeout
 - For the timer to be run again, it must be reloaded manually
 - Ex) A countdown timer runs just once, stopping when it reaches zero
- A periodic (or auto-reload) timer has periodic timeouts that occur at a fixed interval
 - The timer reloads automatically
 - Ex) An alarm clock rings once every morning

Timer Use Cases

Pausing/delaying the program

- delay uses a timer to suspend code execution for a specific period of time (Arduino)
- This is considered a blocking timer function since it blocks program execution

Measuring time

- o millis uses a timer to count the number of milliseconds since the program began (Arduino)
- This is a non-blocking timer function since the program continues to execute as the timer runs

Timer Use Cases (Cont'd)


Calling a function upon timeout

- When the timer suspends, we may want specific instructions to occur. In which case, we call a function to *handle* the event
- We'll discuss this use case in the Interrupts section...

Generating a PWM signal

- analogWrite uses a timer to time the rising and falling edges of the PWM waveform (Arduino)
- See more in the Microcontroller Architecture and Arduino lecture...

Arduino Nano Timers




- The Arduino Nano has three general purpose timers (GPTs)
 - These timers are modules in the MCU used for various functions, PWM, and delays


Digital pins are capable of carrying the output of the timer to which they are connected

 A pin used for timer output cannot also be used for a different purpose at the same time

Arduino Nano Timers (Cont'd)



Arduino Nano Timers (Cont'd)



- You only have three timers!Use them wisely
 - If two functions attempt to use the same timer for different purposes... unexpected behavior may occur

Arduino Nano Timers (Cont'd)

- A watchdog timer (WDT) is used to detect and recover from software or hardware errors
 - How it works:
 - The WDT counts down to zero
 - ii. Each time the program's main loop is run, the timer is reset
 - iii. If the WDT reaches zero before its reset, then the WDT resets the entire processor
 - This is **not a perfect solution**! If a program loop takes a long time to execute, the WDT incorrectly assumes a fault, and the program is reset

SECTION II

Arduino Timer Library

Arduino Timer Library

- We will use one of the Arduino's internal timers to measure time
 - To do so, we will enlist the help of the <u>Timer library</u>, which will need to be downloaded and installed to the Arduino IDE
 - O Make sure to use #include <Timer.h>
- If you would like to explore how timers can be used to call other functions, check out the <u>TimerInterrupt</u> library
 - We will not discuss it in this lecture

Arduino Timer Library (Cont'd)

- First, instantiate a Timer object as Timer timer;
 - o Each of the following are member functions that can be called from this object
 - Time is measured in milliseconds by default
 - Alternatively, you can pass MICROS as a single argument to the constructor to measure in microseconds
- timer.start() starts the timer
 - The timer is in the RUNNING state

Arduino Timer Library (Cont'd)

- timer.pause() pauses the timer
 - The timer is in the PAUSED state
 - The time elapsed since timer.start() freezes
- timer.resume() resumes the timer from the PAUSED state
 - The timer is in the RUNNING state
 - The time elapsed since timer.start() resumes counting

Arduino Timer Library (Cont'd)

- timer.stop() stops the timer
 - The timer is in the **STOPPED** state
 - The time elapsed since timer.start() will be the reset the next time the timer.start() is called
- timer.read() returns the time elapsed since timer.start()
 - Measured in milliseconds
- timer.state() returns the state as one of three predefined constants
 - The state can be RUNNING, PAUSED, or STOPPED

SECTION III Interrupts

Interrupts

- An interrupt is a request for the CPU to halt the currently executing code when an event occurs
 - The CPU suspends the current program to handle the event by executing a function called an interrupt handler or interrupt service routine (ISR)
 - When the interrupt handler finishes execution, the CPU returns to the old program

Types of Interrupts

- A software interrupt is triggered by an instruction
 - Also called a trap or exception
 - Often caused by an illegal operation
 - Ex) Dividing by zero, Accessing memory without permission
- A hardware interrupt is triggered by devices external to the CPU
 - Also called an external interrupt
 - Caused when a devices sends an interrupt request (IRQ) signal to the CPU
 - Ex) Timer timeout, button press, power failure

Polling

- Polling is a method of periodically checking the status of a device
 - Ex) A person checking their phone for new messages every 10 minutes
 - Polling loops cost additional CPU time
- Should we use interrupts instead of polling?
 - Interrupts signal when an event occurs whereas polling checks to see if an event occured
 - Ex) A person reading their phone upon receiving a push notification
 - Use interrupts when an event is urgent and/or infrequent

Interrupt Use Cases

Servicing timers

- When a timeout occurs, the programmer may want specific code to be run
 - This is when the timer sends an IRQ and an interrupt handler is called

Handling peripheral device events

- Ex) When a key is pressed, the keyboard sends an IRQ to the computer
 - An interrupt handler then responds to the event

SECTION IV


Interrupts with Arduino

attachInterrupt

- Only Arduino Nano digital pins D2 and D3 can be used for external interrupts
- void attachInterrupt(interrupt, ISR, mode)
 - This function initializes an interrupt
 - interrupt the interrupt number (not a pin number); only one interrupt can be initialized per interrupt number
 - ISR the name of the function to call as the interrupt handler
 - You need to define a function and pass its name as ISR
 - mode configures the timing of the IRQ
 - You will set the mode to one of the following constants...

attachInterrupt (Cont'd)

- The options for mode are...
 - Low when the pin is a LOW voltage
 - **CHANGE** when the pin changes value
 - FALLING when the pin voltage changes from HIGH to LOW
 - RISING when the pin voltage changes from LOW to HIGH



attachInterrupt (Cont'd)

- void digitalPinToInterrupt(pin)
 - This function converts a digital pin number to its corresponding interrupt number
- It is recommended that you call attachInterrupt as follows:
 - o attachInterrupt(digitalPinToInterrupt(pin), ISR, mode)
 - This approach avoids confusion involving digital pin and interrupt numbers

SECTION V

Arduino Interrupt Exercise

Arduino LED Toggle Button



Write a program that satisfies the following requirements:

- You must write a program in which the Arduino board toggles the state of its built-in LED (D13) when a button is pressed
- The state of the LED must toggle only once for each button press
 - Meaning... The LED should not flicker ON and OFF if the button is held down
- This program must be implemented with attachInterrupt
- No loops may be used (that includes the main loop)
- No starter code!

"Ask not what your **interrupt** can do for you; ask what you can do when your **interrupt fires unexpectedly**."

John F. Kennedy (circa 1961)

Famous Misquotes

FAIR USE DISCLAIMER

Copyright Disclaimer under section 107 of the Copyright Act 1976, allowance is made for "fair use" for purposes such as criticism, comment, news reporting, teaching, scholarship, education and research.

Fair use is a use permitted by copyright statute that might otherwise be infringing.

Non-profit, educational or personal use tips the balance in favor of fair use.

CC BY-NC-SA 4.0

This work by the Institute of Electrical and Electronics Engineers, UC Irvine Branch, is licensed under CC BY-NC-SA 4.0