



Project Name	LANCO HILLS RESIDENTIAL PROJECT- LH 10 ,HYDERABAD		
Client	LANCO HILLS TECHNOLOGY PARK PRIVATE LIMITED		
PMC	SAVILLS PROPERTY SERVICES (INDIA) PRIVATE LIMITED		
Main Contractor	BCIM ENGINEERING PVT LIMITED		
REVISION HISTORY			
REV.NO	DATE	DETAILS OF REVISION	
R0	21.05.2026	Initial Issue for review and approval	
PREPARED BY BCIM		REVIEWED BY BCIM	REVIEWED & APPROVED BY PMC/Client

	BCIM ENGINEERING PVT LTD METHOD STATEMENT FOR WATERPROOFING WORKS		

1. TOILET, UTILITY –SUNKEN AREA WATERPROOFING

1. Objective

The Objective of this Method statement is to carryout Waterproofing Treatment for Sunken locations by meeting the contract documents, Technical Data Sheet and Approved Drawings.

2. Scope of Work

Providing and applying waterproofing for sunken areas by surface method. The work comprises two parts:

- **Part 1-** Brushbond RFX coating with Geo Fabric cloth and wall plastering;
- **Part 2-** filling of sunken area with screed.

3. Reference

- Approved Drawings
- Approved Materials

4. Materials Used

S.No	Material/Product	Purpose
1	Fosroc Brushbond RFX	Two Component elastometric Cementitious waterproof coating
2	Conplast 421 IC (Fosroc)	Waterproofing admixture for screed concrete and plaster
3	Geofabric cloth	Geofabric cloth embedded between coats
4	Fosroc Conbextra GP2	Cementitious grout for porous area grouting

5. System Build-Up

- 1st Layer – Mother Slab Concrete (Existing RCC Slab)
- 2nd Layer – Fosroc Brushbond RFC (1st Coat) + Geofabric cloth laying
- 3rd Layer – Fosroc Brushbond RFX (2nd Coat over Geo Fabric)
- 4th Layer – CM 1:3 plaster with Conplast 421 IC on walls
- 5th Layer - Screed Plastering with 12 -15mm thick mortar added with Conplast 421 IC admix

	BCIM ENGINEERING PVT LTD METHOD STATEMENT FOR WATERPROOFING WORKS	
--	--	---

6. Surface Preparation

- Inspect the entire area and identify all cracks, porous zones, construction joints, and defective.
- Clean all concrete surfaces free of laitance, dust, dirt, cavities, and projecting nibs using a wirebrush/grinder
- Remove all flaky materials and weak concrete by wire brushing
- Grout all porous areas, honeycombs, and construction joints with Fosroc Conbextra GP2 cementitious grout and allow to cure
- Fix Weep holes if required and grout all pipe drain/outlet with Conbextra GP2 (Claimed additionally if done)
- Provide coves/fillets of 50 mm × 50 mm at all wall-floor junctions using CM 1:4 mortar admixed with Conplast 421 IC
- Preponding for leakage test to be done for 24 hours.
- Pre-wet the surface with clean water before application. Surface should be Saturated Surface Dry (SSD)

7. Application Procedure Part 1 – Fosroc Brushbond RFX -1st Coat with Geofabris & 2nd Coat

- Mix Brushbond RFX powder and liquid components strictly as per the manufacturer's mixing ratio using a slow-speed drill (max 500 rpm) until lump-free consistency is achieved.
- Apply the FIRST coat of Brushbond RFX uniformly over the prepared surface using a stiff brush ensuring even coverage across the entire area including wall treatment up to 600 mm height. Allow the first coat to become 'green' (tacky but not fully cured).
- While the first coat is still green, lay Geo Fabric cloth over the wet coating ensuring proper overlaps (minimum 100 mm overlap at joints)
- Press the Geo Fabric firmly into the wet coating ensuring full embedment without voids or air pockets
- Immediately apply the SECOND coat of Brushbond RFX in the cross direction to the first coat to achieve uniform waterproof film thickness over the Geofabric ,fully encapsulating the Geofabric cloth.
- Extend coating up to a minimum height of 600 mm on all walls to prevent flashing water ingress.
- Allow the waterproof coating to cure for a minimum of 24–48 hours , Apply 12mm thick CM 1:3 plaster admixed with Conplast 421 IC on the wall coating area.

8. Part 2–Protective Screed Concrete (12–15 mm Thick)

- After curing of the waterproof coating, lay a screed concrete using 12mm metal aggregate using mix ratio of 1:2:4 admixed with Conplast 421 IC filling the sunken area of to a thickness of 60mm.
- Ensure proper line and level as per instructions of the Engineer-in-Charge.
- Conduct Postponding test for 24 hours & Cure the screed for a minimum of 7 days from laying.

	BCIM ENGINEERING PVT LTD METHOD STATEMENT FOR WATERPROOFING WORKS	
--	--	---

Instruments:

- Grinding Machine with accessories
- Hammer and Chisel
- Roller and Paint Brush
- Drilling machine and bits
- Injection Grouting Machine
- Slow Speed Mixer
- Spatula
- Coir Cleaning Brush.

ATTACHMENT

1. Check list for Waterproofing