




Project Name	LANCO HILLS RESIDENTIAL PROJECT- LH 10 ,HYDERABAD		
Client	LANCO HILLS TECHNOLOGY PARK PRIVATE LIMITED		
PMC	SAVILLS PROPERTY SERVICES (INDIA) PRIVATE LIMITED		
Main Contractor	BCIM ENGINEERING PVT LIMITED		
REVISION HISTORY			
REV.NO	DATE	DETAILS OF REVISION	
R0	21.05.2026	Initial Issue for review and approval	
R1	29.05.2026	Pond duration, Coverage, Groove thickness	
PREPARED BY BCIM		REVIEWED BY BCIM	REVIEWED & APPROVED BY PMC/Client

*Bah
Bala Subramaniam
29/05/26*

*Hol
29/05/26*

	BCIM ENGINEERING PVT LTD METHOD STATEMENT FOR WATERPROOFING WORKS	

1. TOILET, UTILITY –SUNKEN AREA WATERPROOFING

1. Objective

The Objective of this Method statement is to carryout Waterproofing Treatment for Sunken locations by meeting the contract documents, Technical Data Sheet and Approved Drawings.

2. Scope of Work

Providing and applying waterproofing for sunken areas by surface method. The work comprises two parts:

- **Part 1-** Brushbond RFX coating with Geo Fabric cloth and wall plastering;
- **Part 2-** filling of sunken area with screed.

3. Reference


- Approved Drawings
- Approved Materials

4. Materials Used

S.No	Material/Product	Purpose
1	Fosroc Brushbond RFX	Two Component elastomeric Cementitious waterproof coating
2	Conplast 421 IC (Fosroc)	Waterproofing admixture for screed concrete and plaster
3	Geofabric cloth	Geofabric cloth embedded between coats
4	Fosroc Conbextra GP2	Cementitious grout for porous area grouting

5. System Build-Up

- 1st Layer – Mother Slab Concrete (Existing RCC Slab)
- 2nd Layer – Fosroc Brushbond RFC (1st Coat) + Geofabric cloth laying
- 3rd Layer – Fosroc Brushbond RFX (2nd Coat over Geo Fabric)
- 4th Layer – CM 1:3 plaster with Conplast 421 IC on walls
- 5th Layer - Screed Concrete mix 1:2:4 added with Conplast 421 IC admix


 Babu Subramaniam
 29/05/26


 Raj
 29/05/26

6. Surface Preparation

- Inspect the entire area and identify all cracks, porous zones, construction joints, and defective.
- Clean all concrete surfaces free of laitance, dust, dirt, cavities, and projecting nibs using a wirebrush/grinder
- Remove all flaky materials and weak concrete by wire brushing
- Grout all porous areas, honeycombs, and construction joints with Fosroc Conbextra GP2 cementitious grout and allow to cure
- Cut a V-groove of 10 mm wide × 10 mm deep along all surface cracks using a grinder/groove cutter. Clean the groove with compressed air, fill with Fosroc Conbextra GP2 mortar flush with the surface, and allow to cure before coating.
- At all wall-floor junctions, cut a 12 mm × 12 mm groove along the junction line before coving. Clean the groove, fill with Fosroc Conbextra GP2, and allow to cure. Then provide coves/fillets of 50 mm × 50 mm using CM 1:4 mortar admixed with Conplast 421 IC over the treated junction.

Pre-Ponding:

- Before applying waterproofing, ensure all drain outlets are sealed/plugged. Conduct a pre-application ponding test for 24 hours to identify any active leaks; repair all identified leaks before proceeding.
- Pre-wet the surface with clean water before application. Surface should be Saturated Surface Dry (SSD)

7. Application Procedure Part 1 – Fosroc Brushbond RFX -1st Coat with Geofabris & 2nd Coat

- Mix Brushbond RFX powder and liquid components strictly as per the manufacturer's mixing ratio using a slow-speed drill (max 500 rpm) until lump-free consistency is achieved. Mixing ratio: Brushbond RFX Powder 15 kg + Brushbond RFX Liquid 5.088 kg + Water 3 litres (Industrial Pack).
- Apply the FIRST coat of Brushbond RFX uniformly over the complete sunken area (floor + 600 mm wall height) using a stiff brush (120–150 mm width).
- While the first coat is still green/tacky, lay Geo Fabric / Fibre Glass cloth of 30–50 GSM over the wet coating ensuring proper overlaps (minimum 100 mm overlap at joints)
- Press the Geo Fabric firmly into the wet coating ensuring full embedment without voids or air pockets
- Immediately apply the SECOND coat of Brushbond RFX over the Geo Fabric, fully encapsulating the reinforcement mesh. Coverage: approximately 12–14 sqm per Industrial Pack (15 kg + 5.088 kg) at 1 mm thickness for 2 coats
- Extend the coating up to 600 mm height on all walls. Apply 12 mm thick CM 1:3 plaster admixed with Conplast 421 IC on the wall portion above the coating.

Sd/-
Sate Sukhmanoh
29/05/26

Hel
29/05/26

- After application, allow air curing only. Water curing or curing compounds shall NOT be applied over Brushbond RFX coating.

1. Part 2–Protective Screed Concrete (60mm Thick)

- After Part 1 curing, fill the sunken area with screed concrete using 12 mm metal aggregate, mix ratio 1:2:4 admixed with Conplast 421 IC of Fosroc as per manufacturer's specification.
 - Total screed thickness: 60 mm.
 - Include all cutouts, openings, and check for water tightness.
- Post-Ponding:**
- After complete curing of the waterproof coating (minimum 48 hours after final coat), conduct a ponding test by flooding the sunken area with minimum 25 mm depth of water for 72 hours. Check for any seepage or dampness. Clear the water only after the test is satisfactorily completed and approved by the Engineer-in-Charge.
 - Cure the completed screed for a minimum of 7 days.

Instruments:

- Grinding Machine with accessories
- Hammer and Chisel
- Roller and Paint Brush
- Drilling machine and bits
- Injection Grouting Machine
- Slow Speed Mixer
- Spatula
- Coir Cleaning Brush.

ATTACHMENT

1. Check list for Waterproofing

Bal
 Bate Subramaniam
 29/05/26

Hel
 29/05/26