




Project Name	LANCO HILLS RESIDENTIAL PROJECT- LH 10 ,HYDERABAD		
Client	LANCO HILLS TECHNOLOGY PARK PRIVATE LIMITED		
PMC	SAVILLS PROPERTY SERVICES (INDIA) PRIVATE LIMITED		
Main Contractor	BCIM ENGINEERING PVT LIMITED		
REVISION HISTORY			
REV.NO	DATE	DETAILS OF REVISION	
R0	21.05.2026	Initial Issue for review and approval	
R1	25.05.2026	Groove thickness	
PREPARED BY BCIM		REVIEWED BY BCIM	REVIEWED & APPROVED BY PMC/Client
			

 Lanco Hills a world within 	BCIM ENGINEERING PVT LTD METHOD STATEMENT FOR WATERPROOFING WORKS	 BCIM

1. OVERHEAD TANK TOP WATERPROOFING

1. Objective

The Objective of this Method statement is to carryout Waterproofing Treatment for OHT cover slab top locations by meeting the contract documents, Technical Data Sheet and Approved Drawings.

2. Scope of Work

Providing and applying waterproofing for OHT Cover slab top areas by surface method. The work comprises treating all cracks, construction joints and surface defects, followed by applying two coats of Fosroc Brushbond Roofguard Premium solar-reflective elastomeric polyurethane waterproof coating over a primer of Nitoproof WB.

3. Reference

- Approved Drawings
- Approved Materials

4. Materials Used

S.No	Material/Product	Purpose
1	Fosroc Brushbond Roofguard Premium	Single Component Acrylic-based modified PU elastomeric solar reflective waterproof coating
2	Fosroc Nitoproof WB	Primer coat (Diluted 1:2 with water)
3	Fosroc Thioflex 600	Polysulphide sealant for expansion joints and crack sealing

5. Surface Preparation & Crack / Joint Treatment

- Inspect the entire area and identify all cracks, porous zones, construction joints, cold joints , hollow /patch and defective areas.
- Treat all cracks: make a U groove of 5 mm wide × 10 mm deep, apply primer coating over the groove, and fill with Fosroc Thioflex 600 sealant. Allow to cure.
- For spider cracks, web cracks or shrinkage cracks (more than 1–2 mm), treat from the negative side using two/one-component PU grouting: drill holes, fix mechanical nipples, and inject with high pressure electric grout pump

Boh
Sate Spikumar
25/05/26

Hal
25/05/26

6. Application Procedure – Fosroc Brushbond Roofguard Premium

- After complete curing of crack/joint repairs, apply primer coat of Fosroc Nitoproof WB diluted with water in ratio 1:2 at a coverage of 8–10 sqm/litre. Allow primer to dry completely
- Apply the FIRST coat of Brushbond Roofguard Premium using roller, brush, squeegee, or airless spray at a wet film thickness (WFT) of 0.5 mm per coat at a coverage of 0.5 litre/sqm. Ensure uniform coverage
- Allow the first coat to dry as per manufacturer's recommendation before applying the second coat
- Apply the SECOND coat of Brushbond Roofguard Premium in the cross direction at the same thickness and coverage
- Extend the coating to the full height of the parapet wall as per manufacturer's specification.
- Allow complete curing for 7 days.

Instruments:

- Grinding Machine with accessories
- Hammer and Chisel
- Roller and Paint Brush
- Drilling machine and bits
- Injection Grouting Machine
- Slow Speed Mixer
- Spatula
- Coir Cleaning Brush.

ATTACHMENT

1. Check list for Waterproofing

Boh
Sate Sukmanah
25/05/26

Hal
25/05/26