

Opt1

Equation

Eqn3 Cf1=A*(real(S[2,2])-real(S[1,1]))^2 Cf2=B*(imag(S[2,2])-imag(S[1,1]))^2

S parameter simulation

SP1
Type=log
Start=1e6
Stop=1.3e9
Points=1501

Simulation Controls





