COMPONENT CODES	COMPONENT TITLES
101	CIGARETTE LIGHTER
103	ALTERNATOR
104	STARTING SWITCH
105	MAIN ELECTROMAGNETIC HORN
107	BATTERY
108	IGNITION COIL
118	ANTI-LOCK BRAKING SYSTEM COMPUTER
119	AUTOMATIC TRANSMISSION COMPUTER
120	INJECTION COMPUTER
123	CENTRAL DOOR LOCKING CONTROL
124	HEATING CONTROL
132	DRIVER'S SIDE ELECTRIC WINDOW CONTROL
133	PASSENGER'S SIDE ELECTRIC WINDOW CONTROL
134	ELECTRIC REAR-VIEW MIRROR CONTROL
140	DRIVER'S DOOR ELECTRIC LOCKING
141	CENTRAL LOCKING FOR PASSENGER DOOR
142	BOOT LID ELECTRIC LOCKING
145	COMBINED WIPER-WASHER
146	PINKING SENSOR 1
147	ATMOSPHERIC PRESSURE SENSOR
149	TDC SENSOR
150	RIGHT REAR WHEEL SENSOR
151	LEFT REAR WHEEL SENSOR
152	RIGHT FRONT WHEEL SENSOR
153	LEFT FRONT WHEEL SENSOR
154	TAILGATE SWITCH
155	REVERSING LIGHTS SWITCH
156	HANDBRAKE SWITCH
160	BRAKE SWITCH
163	STARTER
164	COLD AIR BLOWER
165	LUGGAGE COMPARTMENT LIGHTING
171	AIR CONDITIONING CLUTCH
172	RIGHT REAR LIGHT
173	LEFT REAR LIGHT
176	RIGHT FRONT FOGLIGHT
177	LEFT FRONT FOGLIGHT
180	DRIVER'S RABBET SWITCH
181	PASSENGER'S RABBET SWITCH
184	RIGHT HEADLIGHT
185	LEFT HEADLIGHT
188	COOLING FAN UNIT
191	FRONT RIGHT DOOR SPEAKER
192	FRONT LEFT DOOR SPEAKER
193	INJECTOR 1
194	INJECTOR 2
195	INJECTOR 3
196	INJECTOR 4
200	REAR SCREEN DE-ICING
203	DRIVER'S WINDOW MOTOR
204	PASSENGER ELECTRIC WINDOW MOTOR
205	PRESSURE SWITCH
206	AIR CONDITIONING TRI-FUNCTION PRESSURE SWITCH
200	VIIV COMPILIONING TWI-LONGLIGHT WESSONE SWITCH

COMPONENT CODES	COMPONENT TITLES
207	BRAKE FLUID MIN LEVEL SENSOR
209	MONOLEVER
211	REAR SCREEN WIPER MOTOR
212	WINDSCREEN WIPER MOTOR
213	FRONT COURTESY LIGHT
218	FUEL PUMP
222	THROTTLE POTENTIOMETER
225	DIAGNOSTIC SOCKET
226	RIGHT-HAND HEADLIGHT
227	LEFT-HAND HEADLIGHT
228	IDLE SPEED REGULATOR
230	REAR FOG LIGHTS RELAY
231	FRONT FOG LIGHTS RELAY
232	STARTER RELAY
233	COLD AIR BLOWER RELAY
234	FAN ASSEMBLY RELAY
236	FUEL PUMP RELAY
238	INJECTION LOCKING RELAY
239	DRIVER'S ELECTRIC REAR-VIEW MIRROR
240	PASSENGER ELECTRIC REAR-VIEW MIRROR
242	DOWNSTREAM OXYGEN SENSOR
244	WATER INJECTION TEMPERATURE SENSOR
250	VEHICLE SPEED SENSOR
255	RIGHT FRONT TURN SIGNAL LIGHT
256	LEFT FRONT TURN SIGNAL LIGHT
260	PASSENGER COMPARTMENT FUSE BOX AND RELAY
261	RADIO
262	COOLING FAN AND AIR CONDITIONING
267	RIGHT REPEATER
268	LEFT REPEATER
272	INJECTION AIR TEMPERATURE SENSOR
273	ENGINE SPEED SENSOR
295	WARNING LIGHT UNIT
298	HEATING DEVICE
304	SUNROOF
319	AIR CONDITIONING CONTROL PANEL
321	AIR CONDITIONING FAN ASSEMBLY RESISTOR
333	DRIVER'S SEAT BELT SWITCH
365	RIGHT-HAND TWEETER SPEAKER
366	LEFT-HAND FRONT TWEETER SPEAKER
371	PETROL VAPOUR ABSORBER
411	AIR CONDITIONING PRESSURE SWITCH
462	TAILGATE REGISTRATION PLATE LIGHTING
502	VARIABLE POWER ASSISTED STEERING COMPUTER
532	DRIVER'S CONTROL FOR FRONT PASSENGER WINDOW CLOSER
537	LEFT HEADLIGHT CORRECTOR MOTOR
538	RIGHT HEADLIGHT CORRECTOR MOTOR
540	VARIABLE POWER ASSISTED STEERING MOTOR
562	HEADLIGHT ADJUSTMENT CONTROL
584	AIR CONDITIONING COMPRESSOR CLUTCH RELAY
586	HAZARD WARNING LIGHT CONTROL
597	ENGINE AND RELAY FUSE BOX
620	TWIN THROTTLE POTENTIOMETER
	1

COMPONENT CODES	COMPONENT TITLES
639	RAISED BRAKE LIGHT
645	PASSENGER COMPARTMENT COMPUTER
651	LIQUID CRYSTAL PANEL
674	DOUBLE REAR FOG LIGHT/SCREEN SWITCH
676	ACCELERATOR PEDAL SWITCH
677	FRONT AND REAR BI-DIRECTIONAL WASHER PUMP
679	RADIO INTERFERENCE SUPPRESSOR
724	AUTOMATIC CLUTCH PUMP UNIT
726	ENGAGED GEAR SENSOR
756	AIR BAG/PRETENSIONER COMPUTER
757	DRIVER'S PRETENSIONER
758	PASSENGER'S PRETENSIONER
762	GEARBOX PUMP ASSEMBLY RELAY
763	GEARBOX ALARM BUZZER
774	PRETENSIONER SUPPLY
778	QUADRUPLE IGNITION COIL MODULE
802	ECU ANTI-RETURN DIODE / FUEL PUMP RELAY
809	PASSENGER AIR BAG
850	POWER ASSISTED STEERING TORQUE SENSOR
860	ROTARY SWITCH
887	UPSTREAM OXYGEN SENSOR
899	DRIVER'S AIR BAG
921	ACCELERATOR POTENTIOMETER
927	IMPACT SENSOR (INERTIA SENSOR)
969	3RD IMPOSED SHIFT LOCK ELECTROMAGNET GEAR LEVER
997	LPG COMPUTER
1001	LPG TANK
1003	LPG OR PETROL SELECTOR SWITCH
1026	DRIVER'S SIDE AIR BAG
1027	PASSENGER'S SIDE AIR BAG
1028	DRIVER'S SIDE SATELLITE
1029	PASSENGER SIDE SATELLITE
1033	PROTECTED POSITIVE BATTERY
1040	WINDSCREEN WIPER RELAY
1041	REAR WIPER CONTROL
1042	CENTRAL DOOR LOCKING RELAY
1043	ELECTRIC DOOR LOCKS UNLOCKING RELAY
1050	CLUTCH SOLENOID VALVE
1051	ENGAGEMENT SOLENOID VALVE 1
1052	ENGAGEMENT SOLENOID VALVE 2
1053	SELECTION SOLENOID VALVE 1
1054	SELECTION SOLENOID VALVE 2
1055	ENGAGEMENT POSITION SENSOR
1056	SELECTION POSITION SENSOR
1057	CLUTCH POSITION SENSOR
1058	GEAR SELECTOR SWITCH
1059	SEQUENTIAL GEARBOX PRESSURE SENSOR
1060	GEARBOX INPUT SPEED SENSOR
1076	MOTORISED THROTTLE BODY
1108	FRONT PASSENGER/CHILD SEAT PRESENCE SENSOR
1161	LPG SOLENOID VALVE RELAY
1186	LIQUEFIED PETROLEUM GAS EXPANSION VALVE SOLENOID VALVE.
1195	LPG PRESSURE SENSOR
	1

COMPONENT CODES	COMPONENT TITLES
1196	LPG PETROL PUMP CUT-OFF RELAY
1250	DASHBOARD AIRBAG EARTH
1342	KEYLESS VEHICLE ROOF AERIAL
1414	AIRBAG INHIBITOR KEY SWITCH