TECHNICAL NOTEEDITION ANGLAISE



77 11 299 722 DECEMBER 2000



Type

C

S/Section

Twingo

X06

88

88

FRONT PASSENGER AIR BAG DISABLEMENT KEY

Engine: χχχ

Basic manuals:

Gearbox: xxx
Technical Notes 3428A - 3434A - 3435A

Two types of equipment may be fitted on the cars depending on the date of their manufacture. Only the most recent generation parts are referenced in the spare parts:

• 1st type

Disablement key: automatic return to the OFF position (air bag not activated)

Key disablement system resistance: - OFF position: 400 Ω

- ON position: 100Ω

2nd type

Disablement key: automatic return to the ON position (air bag activated)

Key disablement system resistance: - OFF position: 400 Ω

- ON position: 100Ω

IMPORTANT: the computer must correspond to the correct version of the disablement key for the system to function correctly. If the car is fitted with equipment containing two components from different generations, the **air bag OFF** warning light will light up when the disablement key is turned to the ON position. If this occurs, check the disablement key system resistance:

- if the resistance is incorrect, replace the disablement key,
- if the resistance is correct, replace the computer.