

## Organ Model PT350

## TYPICAL SPECIFICATION

Three Manual Lighted Side-Tab Console

| PEDAL  | GREAT  | SWELL                                     |
|--|--|---|
| 1 Sub Bourdon 32   | 1 Double Diapason 16   | 1 Bourdon 16                              |
|  |  |   |
| 2 Open Wood 16   | 2 Diapason 8   | 2 Geigen Diapason 8                       |
| 3 Principal 16   | 3 Hohl Flute 8   | 3 Lieblich Gedeckt 8                      |
| 4 Sub Bass 16  | 4 Quintadena 8   | 4 Salicional 8                            |
| 5 Octave 8   | 5 Octave 4   | 5 Voix Celeste 8                          |
| 6 Bass Flute 8   | 6 Spire Flute 4  | 6 Principal 4                             |
| 7 Choral Bass 4  | 7 Twelfth 2.2/3  | 7 Lieblich Flute 4                        |
| 8 Mixture IV   | 8 Super Octave 2   | 8 Fifteenth 2                             |
| 9 Contra Posaune 32  | 9 Fourniture IV  | 9 Piccolo 2                               |
|  | 10 Tromba 8  | 10 Mixture IV                             |
|  |  |   |
| 11 Trumpet 8   | 11 Octave Tromba 4   | 11 Contra Fagotto 16                      |
| 12 Clarion 4   | (i) Swell to Great   | 12 Trumpet 8                              |
| (i) Great to Pedal   | (ii) Choir to Great  | 13 Oboe 8                                 |
| (ii) Swell to Pedal  | (iii) Great & Pedal on   | 14 Vox Humana 8                           |
| (iii) Choir to Pedal   | Choir Expression   | 15 Clarion 4                              |
| (iv) Auto Pedal  | (iv) Midi to Great   | (i) Tremulant                             |
| (v) Great & Pedal Pistons  | ()   | (ii) Midi to Swell                        |
| Coupled  | COMBINATION ACTION   | (ii) Wildi to Swell                       |
|  | 6 Thumb pistons to the Swell organ                                       | CHOID                                     |
| (vi) Midi to Pedal   | 6 Thumb pistons to the Great organ                                       | CHOIR                                     |
|  | 6 thumb pistons to the Choir organ                                       | 1 English Diapason 8                      |
| ACCESSORIES  | 8 General thumb pistons  | 2 Spitz Flute 8                           |
| Program Display (LCD)  | 8 General toe pistons<br>8 toe pistons to the Pedal                      | 3 Flute Celeste 8                         |
| Two Specifications (Opt. Third Spec) Expression pedal to the Swell organ | 16 Combination Memories  | 4 Gemshorn 4                              |
| Expression pedal to the Choir organ                                      | To community morres  | 5 Chimney Flute 4                         |
| Programmable Crescendo Pedal   | 1 rev. thumb piston Swell to Great                                       | 6 Nazard 2-2/3                            |
| Multi-program Lexicon MPX110 reverb                                      | 1 rev. thumb piston Swell to Pedal                                       | 7 Block Flute 2                           |
| Reverb level control   | 1 rev. thumb piston Swell to Choir<br>1 rev. thumb piston Great to Pedal | 8 Tierce 1-3/5                            |
| Overall volume control<br>Transposer +3/-3                               | 1 rev. thumb piston Choir to Great                                       |   |
| Fine Tune  | 1 rev. thumb piston Choir to Pedal                                       | 9 Cymbale III                             |
| Capture lock switch  | •  | 10 Corno di Bassetto 8                    |
| Pedal light  | 1 thumb piston General Cancel  | 11 Trompette en Chamade 8                 |
| TECHNICAL DATA   | 1 thumb piston Setter 1 toe piston Swell to great                        | 12 Chimes                                 |
| TECHNICAL DATA   | 1 toe piston Great to Pedal  | (i) Tremulant                             |
| Manuals: 3x61 notes  |  |   |
| Pedals: 32 note ACC  | 1 toe piston Choir to Pedal  | (ii) Swell to Choir                       |
| Pedals: 32 note AGO Audio: 12 x 100 watts                                | 1 toe piston Choir to Pedal<br>3 thumb pistons FN, +,                    | (ii) Swell to Choir<br>(iii)Midi to Choir |

2 channel socket

In, Out, Thru

Input: Midi:

Headphones socket