

Organ Model PT339

TYPICAL SPECIFICATION

Three Manual Lighted Tab Console

PEDAL		GREAT		SWELL	
1 Contra Violor	ne 32	1 Open Diapason	8	1 Geigen Diapason	8
2 Principal	16	2 Chimney Flute	8	2 Claribel Flute	8
3 Bourdon	16	3 Dulciana	8	3 Viola di Gamba	8
4 Dulciana	16	4 Octave	4	4 Voix Celeste	8
5 Octave	8	5 Harmonic Flute	4	5 Principal	4
6 Bass Flute	8	6 Fifteenth	2	6 Lieblich Flute	4
7 Choral Bass	4	7 Fourniture	IV	7 Fifteenth	2
8 Mixture	III	8 Tromba	8	8 Mixture	III
9 Posaune	16	(i) Tremulant		9 Double Trumpet	16
10 Trumpet	8	(ii) Swell to Grea	nt	10 Trumpet	8
(i) Great to Pedal		(iii) Choir to Great		11 Oboe	8
(ii) Swell to Pedal		(iv) Gt & Ped on Choir		12 Clarion	4
(iii) Choir to Pedal		Expression		(i) Tremulant	
(iv) Midi to Pedal		(v) Auto Pedal		(ii) Midi to Swell	
		(vi) Midi to Grea	t		
ACCESSORIES	5			CHOIR	
Program Display (LCD)		COMBINATION ACTION		1 Bourdon	8
Two Specifications Expression pedal to the Swell organ		6 Thumb pistons to the Swell organ		2 Salicional	8
Expression pedal to the Choir organ		6 Thumb pistons to the Great organ		3 Spire Flute	4
Programmable Crescendo Pedal		6 thumb pistons to the Choir organ 8 General thumb pistons		4 Block Flute	2
Multi- program Lexic	on MPX110 reverb	o contrar triumo pri	,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,	5 Cornet	II
Reverb level control		1 rev. thumb piston	1 rev. thumb piston Swell to Great		
Overall volume control Transposer +3/-3		1 rev. thumb piston Swell to Pedal		6 Scharf	III
Fine Tune		1 rev. thumb piston Swell to Choir		7 Clarinet	8
Capture lock switch		1 rev. thumb piston Great to Pedal 1 rev. thumb piston Choir to Great		8 Tuba	8
Pedal light		1 rev. thumb piston Choir to Pedal		9 Chimes	
		1 thumb piston General Cancel 1 thumb piston Setter		(i) Tremulant	
TECHNICAL DATA				(ii) Swell to Choir	
Manuals: 3x61 notes					

3 thumb pistons Program, + and -

Pedals: 32 note AGO

Headphones socket

Input: Midi:

Audio: Yamaha XM6150
Power Amplier-6 x100 watts RMS
Input: 2 channel socket

In, Out, Thru

(iii) Midi to Choir