

## Organ Model PT346

## TYPICAL SPECIFICATION

Three Manual Lighted Tab Console

PEDAL	GREAT	SWELL
1 Contra Violone 32	1 Gemshorn 8	1 Lieblich Diapason 8
2 Open Diapason 16	2 Open Diapason 8	2 Geigen Diapason 8
3 Bourdon 16	3 Clarabella 8	3 Lieblich Flute 8
4 Dulciana 16	4 Quintadena 4	4 Salicional 8
5 Octave 8	5 Octave 4	5 Voix Celeste 8
6 Bass Flute 8	6 Stopped Flute 4	6 Principal 4
7 Choral Bass 4	7 Fifteenth 2	7 Harmonic Flute 4
8 Mixture III	8 Cornet V	8 Fifteenth 2
9 Trombone 8	9 Fourniture III	9 Flautino 2
		10 Mixture III
10 Trumpet 8	10 Trumpet 8	
(i) Great to Pedal	(i) Tremulant	11 Contra Fagotto 16
(ii) Swell to Pedal	(ii) Swell to Great	12 Trompette 8
(iii) Choir to Pedal	(iii) Choir to Great	13 Oboe 8
(iv) Auto Pedal	(iv) Midi to Great	14 Clarion 4
(v) Midi to Pedal		(i) Tremulant
	COMBINATION ACTION	N (ii) Midi to Swell
ACCESSORIES	6 Thumb pistons to the Swell organ	
Program Display (LCD)	6 Thumb pistons to the Great organ 6 thumb pistons to the Choir organ	
Two Specifications (Optional Third Spec) Expression pedal to the Swell organ	8 General thumb pistons	1 Bourdon 8
Expression pedal to the Swen organ  Expression pedal to the Choir organ	8 General toe pistons	2 Dulciana 8
Programmable Crescendo Pedal	6 Toe pistons to the Pedal	3 Unda Maris 8
Multi-program Lexicon MPX110 reverb	16 Combination Memories	4 Prestant 4
Reverb level control Overall volume control	1 rev. thumb piston Swell to Great	
Transposer +3/-3	1 rev. thumb piston Swell to Pedal	6 N. 1 2 2 2/2
Fine Tune	1 rev. thumb piston Swell to Choir	
Capture lock switch	1 rev. thumb piston Great to Pedal 1 rev. thumb piston Choir to Great	7 Block Flute 2
Pedal light	1 rev. thumb piston Choir to Pedal	8 11c1cc 1-3/3
TECHNICAL DATA		9 Scharf III
Manuals: 3x61 notes	1 thumb piston General Cancel	10 Clarinet 8
Pedals: 32 note AGO	1 thumb piston Setter 1 rev. toe piston Swell to great	11 Tuba 8
Audio: 6 x100 watts	1 rev. toe piston Great to Pedal	12 Chimes
2x150 watts Input: 2 channel socket	1 rev. toe piston Choir to Pedal	(i) Tremulant
Midi: In, Out, Thru		(ii) Swell to Choir

(iii) Midi to Choir

Headphones socket