

EXPLORE

SESSION 1- Interface RGB LED Strip, Push Switch to Arduino UNO.




EXPLORE

SESSION 2- Interface Vibration Sensor, Speaker (Alert Tone), Red smd LED to Arduino UNO.




EXPLORE

SESSION 3- Interface LCD Display, Push Switch, 1 Watt LEDs, Speaker (Beep) to Arduino UNO.




EXPLORE

SESSION 4- Interface Ultrasonic Sensor, Servo Motor, LCD Display to Arduino UNO.




EXPLORE

SESSION 6- Interface BO Motor, Motor Driver, Push Switch to Arduino UNO.




EXPLORE

SESSION 6- Interface Submersible Pump, Motor Driver, Push Switch to Arduino UNO.




EXPLORE

SESSION 7- Interface Rain Sensor, Servo Motor, Speaker (Alert Tone) to Arduino UNO.




EXPLORE

SESSION 7- Interface Moisture Sensor, Pump Motor, 1 watt LED, Motor Driver to Arduino UNO.




EXPLORE

SESSION 8- Interface DHT11 Sensor, CD Motor, Speaker (Alert Tone), LCD Display to Arduino UNO.




EXPLORE

SESSION 9- Interface Flame Sensor, CD Motor, Speaker (Alert Tone), 1 Watt LEDs to Arduino UNO.




EXPLORE

SESSION 9- Interface MQ2 Smoke Sensor, LED Strip, CD Motor, Speaker (Alert Tone), 1 Watt LEDs to Arduino UNO.



EXPLORE

SESSION 11- Interface IR Remote, IR Receiver, BO Motor, Motor Driver to Arduino UNO.



EXPLORE

SESSION 12- Interface IR Remote, IR Receiver, BO Motor, Motor Driver to Arduino UNO.

