Install Arduino

Step 1 : Go to the [Arduino website and download the version](#) for your operating system



- **Windows**: run the downloaded file and follow the instructions in the installation guide (for Windows, we recommend the first option).
- **Mac OS X**: copy the downloaded file into your application folder.
- **Linux**: extract the downloaded file, and open the arduino-ide file that will launch the IDE.

Step 1.1 : After installation, go to the download location of your file and double click to run the application


Step 1.2: Accept the license agreement and choose the install location of IDE. Finally click on Install button. This completes your installation for IDE

Step 2: Install ESP32 Add-on in Arduino IDE

To install the ESP32 board in your Arduino IDE, follow these next instructions:

- Open the Boards Manager. You can go to **Tools** > **Board** > **Boards Manager…** or you can simply click the **Boards Manager** icon in the left-side corner.

Search for **ESP32** and press the install button for **esp32 by Espressif Systems version 3.X**




That's it. It should be installed after a few seconds.


Install Driver for Esp32


Download the driver zip file from the link and extract the folder

https://www.silabs.com/documents/public/software/CP210x_Universal_Windows_Driver.zip

After extracting the folder, select the silabser.inf(with the settings Icon), then right click and select install. And finally select open option.


CP210x_Universal_Windows_Driver (1)
Search CP210x_Universal_Windows_Driver (1)
New
Sort
View
Details
Name
Date modified
Type
Size
Today
CP210x_Universal_Windows_Driver_Relea... 23-04-2025 17:26 Text Document 31 KB
silabser 23-04-2025 17:26 Security Catalog 14 KB
silabser 23-04-2025 17:26 Setup Information 14 KB
SLAB_License_Agreement_VCP_Windows 23-04-2025 17:26 Text Document 9 KB
UpdateParam 23-04-2025 17:26 Windows Batch File 1 KB
UpdateParameters 23-04-2025 17:26 Registration Entries 3 KB
x86 23-04-2025 17:26 File folder
arm 23-04-2025 17:26 File folder
arm64 23-04-2025 17:26 File folder
x64 23-04-2025 17:26 File folder
Home
Gallery
nxt - Personal
Desktop
Downloads
Documents
Pictures
Music
Videos
certificatein pdf
Screenshots
pluto_manual_imag
poc_audio
Arduino
This PC
OS (C:)
Network
10 items
Search
ENG
IN
17:30
23-04-2025


CP210x_Universal_Windows_Driver (1)
Search CP210x_Universal_Windows_Driver (1)
Cut
Copy
Rename
Share
Delete
Open Enter
Open with
Share
Install
Add to Favorites
Compress to...
Copy as path Ctrl+Shift+C
Properties Alt+Enter
Edit in Notepad
OneDrive
Show more options



Procedure to Install ArduinoJson Library

- **ArduinoJson**: A powerful library for creating and parsing JSON objects, which are used to format the alert message.
    - We will also be using **WIFI** and **HTTP CLIENT** Library(These are standard libraries for managing Wi-Fi connections and HTTP requests on the ESP32. It's usually pre-installed with the ESP32 board manager.)



Install the above library. That is it for the installation part