

PPAP SUBMISSION LEVEL GUIDE

AIAG PPAP 4th Edition | IATF 16949 Clause 8.3.4.4 | Quality Head Agents © 2024

What Are Submission Levels?

PPAP Submission Levels (1–5) define WHAT documents must be physically submitted to the customer and WHAT must be retained at the supplier. The default level is Level 3 unless the customer specifies otherwise.

Level	Name	What is Submitted	Typical Use
1	PSW Only	Part Submission Warrant only (no documents)	Low-risk, proven process — customer trusts supplier
2	PSW + Limited Samples	PSW + samples + limited supporting data	Moderate-risk parts — customer needs some assurance
3	Full Package	PSW + full documentation + samples (DEFAULT)	All new parts, new suppliers, complex parts — STANDARD
4	PSW + Other	PSW + other requirements defined by customer	Customer-specific requirements (OEM-defined)
5	Full at Supplier	Full package reviewed at supplier location	Complex/critical parts — customer audits at your site

Submission Level Decision Matrix

Situation	Recommended Level
New part — new tooling — new process	Level 3 (default)
Existing part — significant design change	Level 3
Existing part — minor engineering change	Level 2
Bulk material (paint, sealant, etc.)	Level 1 or 2
Customer-specified critical part (CC/SC)	Level 3 or 5
Re-PPAP after process change	Level 3
New supplier for existing part	Level 3
Sub-supplier change (Tier 2)	Level 3
Annual revalidation / periodic approval	Level 1 or 2

R / S / A Notation Explained

Code	Meaning	Action Required
R	Retain	Keep at supplier — available for customer review on request
S	Submit	Must physically send to customer with PSW package
A	As requested	Submit ONLY if customer specifically asks for it
NR	Not Required	Not needed at this submission level

■ Always check Customer Specific Requirements (CSR). Customers like Tata Motors, Maruti, Honda, Mahindra, Hyundai may override the default AIAG level requirements.