

AION LIO IO-Link Adapter - Configuration Parameters

AION Resource Groups

Module	Group	Group ID	Description
AION	Timing	0x00	Measurement cadence and keep-alive uplink interval
AION	IO-Link Telemetry	0x02	Read-only IO-Link device identity and raw process data
AION	Trigger	0x01	Manual measurement trigger executable

Kconfig Options

Kconfig symbol	Type	Default	Description
CONFIG_SENTOS_MODULE_AION	bool	n	Enables the Aion module
CONFIG_SENTOS_AION_INTERFACE_IO_LINK	bool	off	Selects the single-port IO-Link master variant and includes the IO-Link stack
CONFIG_SENTOS_AION_IO_LINK_STARTUP_TIMEOUT_MS	integer	5000 ms	Wait time for the first valid process-data sample; allowed range 1000...30000 ms

Timing - Group 0x00

Resource	ID	Description	Key	Min	Max	Default	Unit	Module key
MEASUREMENT PERIOD	0x00	Regular measurement period	period	1	660	5	min	XXX1
REGULAR SEND INTERVAL	0x01	Keep-alive uplink interval in measurements	every	1	24	1	measurements	XXX1

Trigger - Group 0x01

Resource	ID	Description	Key	Default	Input	Module key
TRIGGER MEASUREMENT	0x01	Triggers an immediate measurement. 0x0001 sends the result to the uplink and connected local app; any other two-byte value performs a local-only measurement.	measure	n/a	2-byte big-endian command value	XXX1