


How to collect Integrated Management Log from iLO2/iLO3

- iLO 3

1. Connect to the iLO 3 with using administrative credentials.
2. Go to **Information** => **System Information**
3. Click **View as CSV**.



4. Copy paste the logs in a excel file or text file and send it to **HP Support**

- iLO 2

1. Connect to the iLO 2 with using administrative credentials.
2. Go to the **System Status Tab** and select **IML**

Integrated Lights-Out 2
HP ProLiant

System Status Remote Console Virtual Media Power Management Administration

Integrated Management Log

Severity	Class	Last Update	Initial Update	Count	Description
Critical	Network	12/04/2011 01:28	12/04/2011 01:12	2	Network Adapter Link Down (Slot 0, Port 3)
Critical	Network	12/04/2011 01:28	12/04/2011 01:12	2	Network Adapter Link Down (Slot 0, Port 4)
Caution	POST Message	12/04/2011 01:11	12/04/2011 01:11	1	POST Error: 1794-Slot X Drive Array - Array Accelerator Battery is charging. The Array Accelerator Cache will be enabled once the battery has been charged. No action is required.
Caution	POST Message	12/04/2011 01:11	12/04/2011 01:11	1	POST Error: 1726-Slot X Drive Array - Cache Memory Size or Battery Presence Has Changed - Array Accelerator configuration has automatically been updated.
Critical	Network	11/30/2011 15:21	11/30/2011 15:21	1	Network Adapter Link Down (Slot 0, Port 3)
Critical	Network	11/30/2011 15:21	11/30/2011 15:21	1	Network Adapter Link Down (Slot 0, Port 4)
Critical	Network	11/29/2011 18:08	11/29/2011 18:08	1	Network Adapter Link Down (Slot 0, Port 3)
Critical	Network	11/29/2011 18:08	11/29/2011 18:08	1	Network Adapter Link Down (Slot 0, Port 4)
Critical	Network	11/29/2011 17:53	11/29/2011 17:02	3	Network Adapter Link Down (Slot 0, Port 3)
Critical	Network	11/29/2011 17:53	11/29/2011 17:02	3	Network Adapter Link Down (Slot 0, Port 4)
Critical	Network	11/29/2011 17:53	11/29/2011 17:02	1	Network Adapter Link Down (Slot 0, Port 3)

3. Copy paste the logs in a excel file or text file and send it to **HP Support**

Permanent link to the instruction:

ftp://iss_tool:{IU7yy+Q@ftp.usa.hp.com/IML.pdf