# Tokamak grid generator in IDL

# B.D.Dudson†, M.V.Umansky§ $\dagger \mathrm{Department}$ of Physics, University of York, York YO10 5DD, UK §Lawrence Livermore National Laboratory, CA 94550, USA



June 8, 2010

# Contents

1	Introduction	2
2	Using the Hypnotoad	2
3	Using the grid generator	12
4	DCT	13
5	Finding critical points	13
6	Region numbering	13
7	Separatrices	13
8	Differential geometry         8.1 Toroidal coordinates	
	8.3 Parallel current	16
	8.5 Curvature of single line	

1. Introduction 2

8.7	$\psi$ derivative of $B$ field	19
8.8	Magnetic shear from $J \times B$	20
8.9	Magnetic shear	20

#### 1 Introduction

Generation of field-aligned grids is non-trivial for edge tokamak simulations due to magnetic x-points and material surfaces. This grid generator has the following features:

- Written entirely in IDL. Although some might call this a bug, it does mean that nothing needs to be compiled, and (in theory) this code should work everywhere that IDL is installed.
- Automatically adjusts settings when needed. The grid produced can be customised, but the minimum number of inputs is very small (number of grid points and a psi range). The psi range asked for is adjusted to fit within the boundary.
- Can handle an arbitrary number of x-points. Whilst not of obvious benefit since tokamak equilibria are at most double-null, this means the code is quite generalised and can cope with "strange" configurations. Hopefully this will help make the code more resilient.

For a more complicated grid generator which can produce grids conforming to boundaries, see the CARRE grid generator<sup>1</sup> which produces input files for B2, or UEDGE<sup>2</sup> which can also be used to produce input to BOUT/BOUT++.

# 2 Using the Hypnotoad

The easiest way to generate grids is using the GUI called "Hypnotoad" (yes, it is named after the creature from Futurama, for no particularly good reason). Start IDL then run:

#### IDL> hypnotoad

This should produce a window which looks like Figure 1. The appearance will vary between operating systems, and the screenshots are from IDL running on Linux.

<sup>&</sup>lt;sup>1</sup> "CARRE: a quasi-orthogonal mesh generator for 2D edge plasma modelling" by R. Marchand and M. Dumberry. Comp. Phys. Comm. 96 (1996) pp 232-246

<sup>&</sup>lt;sup>2</sup>Rognlien et al 1992 J. Nucl. Mater. 196198 347




Figure 1: Hypnotoad when started. On the left are a buttons to perform processing steps and change some settings, and on the right is the drawing area which will display the grid (white here, but might be black). At the top is a status area which will display text like error messages.

First load the equilibrium file, which must be a G-EQDSK format file (as output by EFIT). Click on the top button "Read G-EQDSK" which will then ask for the file name as shown in Figure 2.




Figure 2: Open a G-EQDSK formatted file. For this example we'll be using the MAST equilibrium file **g014220.00200** as shown, which is included in the BOUT++ repository (in the **gridgen/efit/** directory)

If the file reading is successful then the grid will be displayed as shown in Figure 3. Flux-surfaces of  $\psi$  are shown in black, but these are just arbitrarily chosen: there is






Figure 3: If an equilibrium is read successfully then some psi contours are plotted in black, and if a boundary is defined then this is plotted as a thick red line. This equilibrium has a (slightly) lower double null (LDN) configuration.

no attempt to identify separatrices at this point. In red is the boundary from the G-EQDSK file. Some G-EQDSK files don't specify a boundary, and whilst it's possible to generate grids without one, the result is usually not very good. If this is the case then no boundary will appear, and the status box will contain a warning about missing boundary. To read the boundary from a different G-EQDSK file, click on the second button down labelled "Read boundary".

Once you've got an equilibrium and boundary, enter the number of radial and poloidal points you'd like in the final mesh into the boxes on the left, along with the maximum range of normalised psi (0 = magnetic axis, 1 = innermost separatrix). If this range is too large then it will be reduced automatically.

Clicking on "Generate mesh" runs the grid generator (in **create\_grid.pro**) the detailed of which are given in more detail in the following chapters. Initially the x-points are located, and those which are inside the boundary and the range of psi specified are selected. These are then refined and analysed to determine the directions corresponding to the divertor legs and the core separatrices. Constant psi surfaces are followed to the target plates. Figure 4(a) shows these lines and the initial attempt at meshing the lower left divertor leg. Note that this meshing won't always start at the lower left: Meshing starts from the innermost x-point (i.e. the one with normalised  $\psi = 1$ ) and proceeds clockwise around the domain. For an Upper Double Null (UDN) configuration the meshing therefore starts at the top right (outer upper divertor leg). You can adjust the settings





- (a) Initial steps in generating the grid. X-points are found and the legs traced to the boundary. Regions are meshed and intersections with the boundary found (where blue lines are drawn to the origin)
- (a) Initial steps in generating the grid. X-points (b) Finished mesh with regions colored (black=1, are found and the legs traced to the boundary. red=2, green=3, blue=4, turquoise=5, purple=6)

Figure 4: Generating a mesh

and re-generate the mesh if needed. The switch called "Strict boundaries" determines whether grid points are allowed to cross the boundary. If this is switched off, the divertor legs will still end at the boundary, but the radial mesh is allowed to cross the boundary.

Once you're happy with the mesh, click on "Output mesh" to create a grid file for input to BOUT/BOUT++. This will prompt for a file to write, and if you're overwriting a file it will ask you to confirm.




Figure 5: Choosing name of output grid file

Whereas mesh generation is automatic, turning a mesh into something which can be used for simulations usually requires some user intervention. This is mainly about checking that the equilibrium is reasonably good and that the pressure and current profiles look sensible. If these are not good then the simulation could have numerical problems, or just produce results which are not correct. Firstly the pressure gradient is calculated using

$$\mu_0 h_\theta \frac{\partial P}{\partial x} = -B_\theta \frac{\partial}{\partial x} \left( B_\theta h_\theta \right) - B_\zeta h_\theta \frac{\partial B_\zeta}{\partial x} - \frac{B_\zeta^2 h_\theta}{R} \frac{\partial R}{\partial x}$$

(see 8.2) for derivation.  $h_{\theta}$  is calculated by measuring the geometric distance between points,  $B_{\zeta}$  from the  $f(\psi)$  profile, and  $B_{\theta}$  from derivatives of  $\psi$  (done in **create\_mesh.pro** using DCTs). This calculated pressure is compared to the pressure profile from the G-EQDSK file as shown in Figure 6.




Figure 6: Calculating pressure from force balance




Figure 7: Calculating  $f = RB_{\zeta}$  from force balance




Figure 8: Calculating poloidal arc length  $h_{\theta}$  from force balance




Figure 9: Calculating  $J_{||}$  from  $f\left(\psi\right)$  and  $p\left(\psi\right)$  (top), and from  $\mathbf{B}$  field (bottom)

```
Generating plasma profiles:
  1. Flat temperature profile
  2. Flat density profile
  3. Te proportional to density
% Compiled module: GET_INTEGER.
Profile option:1
Setting flat temperature profile
% Compiled module: GET_FLOAT.
Temperature (eV):10
Maximum density (10^20 m^-3):
                                   0.216518
Is this ok?y
Setting rmag =
                     1.46673
Setting bmag =
                     1.79263
Writing grid to file /hwdisks/home/bd512/bout/trunk/tokamak_grids/gridgen/bout.grd.nc
% Compiled module: FILE_OPEN.
% Compiled module: NCDF_EXISTS.
% Compiled module: FILE_WRITE.
% Compiled module: REVERSE_INDS.
% Compiled module: FILE_CLOSE.
DONE
```

## 3 Using the grid generator

The function create\_grid takes a 2D array of  $\psi$  values, and produces an orthogonal mesh aligned with the flux-surfaces.

Settings to control the resulting mesh are:

- psi\_inner, the normalised  $\psi$  of the innermost flux surface. This can be either a scalar or an array:
  - scalar: This value is used for the core and all PF regions
  - array[0]: The inner normalised  $\psi$  for the core
  - array[1..n\_xpoint]: Inner  $\psi$  to use for each PF region (see section 6)
- psi\_outer, normalised  $\psi$  of outermost surface. Can also be either a scalar or array:
  - scalar: This value is used for the core and all PF regions
  - array[0..(n\_xpoint-1)]: Outer normalised  $\psi$  for each SOL region (one per x-point)
- nrad Number of radial grid points

4. DCT 13

 scalar: Total number of radial grid points. Automatically divides this between regions.

- array[0]: Number of radial grid points in the core
- array[1..(n\_xpoint-1)]: Radial grid points between separatrices (going outwards from core to edge)
- array[n\_xpoint]: Radial grid points outside last separatrix
- npol Number of poloidal grid points.
  - scalar: Total number of points. Divides between regions based on poloidal arc lengths
  - array[0..(3\*n\_xpoint-1)]: Number of points in each poloidal region. See section 6 for numbering scheme.
- rad\_peaking
- pol\_peaking

#### 4 DCT

DCT of 2D NxM f(x,y)

$$F\left(u,v\right) = \sqrt{\frac{2}{N}}\sqrt{\frac{2}{M}}\Lambda\left(u\right)\Lambda\left(v\right)\sum_{i=0}^{N-1}\sum_{j=0}^{M-1}f\left(i,j\right)\cos\left[\frac{\pi u}{2N}\left(2i+1\right)\right]\cos\left[\frac{\pi v}{2M}\left(2j+1\right)\right]$$

where  $\Lambda(i) = 1/\sqrt{2}$  for i = 0, and  $\Lambda(i) = 1$  otherwise

# 5 Finding critical points

To find x- and o-points,

### 6 Region numbering

### 7 Separatrices

Having found the x-point locations, the separatrices need to be found. First step is to calculate the lines going through the x-point:

Close to an x-point, approximate the change in  $\psi$  by

$$\delta \psi = \frac{1}{2} \psi_{xx} x^2 + \frac{1}{2} \psi_{yy} y^2 + \psi_{xy} xy$$

The two lines through the x-point are then given by where this is zero:

$$\frac{1}{2}\psi_{yy}y^2 + \psi_{xy}xy + \frac{1}{2}\psi_{xx}x^2 = 0$$

Which has the solution

$$y = \frac{-\psi_{xy}x \pm \sqrt{\psi_{xy}^2 x^2 - \psi_{yy}\psi_{xx}x^2}}{\psi_{yy}}$$

i.e.

$$y = \frac{1}{\psi_{yy}} \left( -\psi_{xy} \pm \sqrt{\psi_{xy}^2 - \psi_{yy}\psi_{xx}} \right) x$$

Note that if  $\psi_{yy} = 0$  then the solutions are x = 0 and  $y = -\frac{\psi_{xx}}{2\psi_{xy}}x$ 

### 8 Differential geometry

This section contains derivations of useful quantities or expressions (like force balance) in flux and field-aligned coordinate systems.

#### 8.1 Toroidal coordinates

Orthogonal toroidal coordinate system  $(\psi, \theta, \zeta)$ , where  $\psi$  is the poloidal flux,  $\theta$  the poloidal angle (from 0 to  $2\pi$ ), and  $\zeta$  the toroidal angle (also 0 to  $2\pi$ ). The magnitudes of the unit vectors are

$$|\mathbf{e}_{\psi}| = \frac{1}{R |B_n|} \qquad |\mathbf{e}_{\theta}| = h_{\theta} \qquad |\mathbf{e}_{\zeta}| = R$$
 (1)

The coordinate system is right handed, so  $\hat{\mathbf{e}}_{\psi} \times \hat{\mathbf{e}}_{\theta} = \hat{\mathbf{e}}_{\zeta}$ ,  $\hat{\mathbf{e}}_{\psi} \times \hat{\mathbf{e}}_{\zeta} = -\hat{\mathbf{e}}_{\theta}$  and  $\hat{\mathbf{e}}_{\theta} \times \hat{\mathbf{e}}_{\zeta} = \hat{\mathbf{e}}_{\psi}$ . The metric coefficients are

$$g_{\psi\psi} = \frac{1}{(R|B_p|)^2}$$
  $g_{\theta\theta} = h_{\theta}^2$   $g_{\zeta\zeta} = R^2$  (2)

and the magnitudes of the reciprocal vectors are therefore

$$|\nabla \psi| = R |B_p| \qquad |\nabla \theta| = \frac{1}{h_\theta} \qquad |\nabla \zeta| = \frac{1}{R}$$
 (3)

Because the coordinate system is orthogonal,  $g^{ii} = 1/g_{ii}$  and so the cross-products can be calculated as

$$\nabla \psi \times \nabla \theta = \mathbf{e}^{\psi} \times \mathbf{e}^{\theta} = g^{\psi \psi} \mathbf{e}_{\psi} \times g^{\theta \theta} \mathbf{e}_{\theta}$$

$$= g^{\psi \psi} g^{\theta \theta} h_{\psi} h_{\theta} \hat{\mathbf{e}}_{\psi} \times \hat{\mathbf{e}}_{\theta}$$

$$= \frac{1}{h_{\psi} h_{\theta}} \hat{\mathbf{e}}_{\zeta} = \frac{R|B_{p}|}{h_{\theta}} \hat{\mathbf{e}}_{\zeta}$$

Similarly,

$$\nabla \psi \times \nabla \zeta = -|B_p| \,\hat{\mathbf{e}}_{\theta} \qquad \nabla \theta \times \nabla \zeta = \frac{R}{h_{\theta}} \hat{\mathbf{e}}_{\psi}$$

#### 8.2 $J \times B$ in field-aligned coordinates

Components of the magnetic field in field-aligned coordinates:

$$B^y = \frac{B_\theta}{h_\theta} \qquad B^x = B^z = 0$$

and

$$B_x = B_{\zeta} I R$$
  $B_y = \frac{B^2 h_{\theta}}{B_{\theta}}$   $B_z = B_{\zeta} R$ 

Calculate current  $\mathbf{J} = \frac{1}{\mu} \nabla \times \mathbf{B}$ 

$$(\nabla \times \mathbf{B})^x = \frac{1}{J} \left( \frac{\partial B_z}{\partial y} - \frac{\partial B_y}{\partial z} \right) = 0$$

since  $B_{\zeta}R$  is a flux-surface quantity, and **B** is axisymmetric.

$$(\nabla \times \mathbf{B})^{y} = -\frac{B_{\theta}}{h_{\theta}} \frac{\partial}{\partial x} (B_{\zeta} R)$$
$$(\nabla \times \mathbf{B})^{z} = \frac{B_{\theta}}{h_{\theta}} \left[ \frac{\partial}{\partial x} \left( \frac{B^{2} h_{\theta}}{B_{\theta}} \right) - \frac{\partial}{\partial y} (B_{\zeta} I R) \right]$$

The second term can be simplified, again using  $B_{\zeta}R$  constant on flux-surfaces:

$$\frac{\partial}{\partial y} (B_{\zeta} IR) = B_{\zeta} R \frac{\partial \nu}{\partial x} \qquad \nu = \frac{h_{\theta} B_{\zeta}}{R B_{\theta}}$$

From these, calculate covariant components:

$$(\nabla \times \mathbf{B})_{x} = -B_{\zeta} I R \frac{\partial}{\partial x} (B_{\zeta} R) + \frac{I R^{2} B_{\theta}}{h_{\theta}} \left[ \frac{\partial}{\partial x} \left( \frac{B^{2} h_{\theta}}{B_{\theta}} \right) - B_{\zeta} R \frac{\partial \nu}{\partial x} \right]$$

$$(\nabla \times \mathbf{B})_{y} = -\frac{B^{2} h_{\theta}}{B_{\theta}} \frac{\partial}{\partial x} (B_{\zeta} R) + B_{\zeta} R \left[ \frac{\partial}{\partial x} \left( \frac{B^{2} h_{\theta}}{B_{\theta}} \right) - B_{\zeta} R \frac{\partial \nu}{\partial x} \right]$$

$$(\nabla \times \mathbf{B})_{z} = -B_{\zeta} R \frac{\partial}{\partial x} (B_{\zeta} R) + \frac{R^{2} B_{\theta}}{h_{\theta}} \left[ \frac{\partial}{\partial x} \left( \frac{B^{2} h_{\theta}}{B_{\theta}} \right) - B_{\zeta} R \frac{\partial \nu}{\partial x} \right]$$

$$(4)$$

Calculate  $\mathbf{J} \times \mathbf{B}$ :

$$\mu_0 \left( \mathbf{J} \times \mathbf{B} \right)^x = -\frac{B_\theta^3 R^2}{h_\theta} \left[ \frac{\partial}{\partial x} \left( \frac{B^2 h_\theta}{B_\theta} \right) - B_\zeta R \frac{\partial \nu}{\partial x} \right]$$

Covariant components of  $\nabla P$ :

$$(\nabla P)_x = \frac{\partial P}{\partial x}$$
  $(\nabla P)_y = (\nabla P)_z = 0$ 

8.3 Parallel current 16

and contravariant:

$$(\nabla P)^x = (RB_\theta)^2 \frac{\partial P}{\partial x} \qquad (\nabla P)^y = 0 \qquad (\nabla P)^z = -I(RB_\theta)^2 \frac{\partial P}{\partial x}$$

Hence equating contravariant x components of  $\mathbf{J} \times \mathbf{B} = \nabla P$ ,

$$\frac{\partial}{\partial x} \left( \frac{B^2 h_{\theta}}{B_{\theta}} \right) - B_{\zeta} R \frac{\partial}{\partial x} \left( \frac{B_{\zeta} h_{\theta}}{R B_{\theta}} \right) + \frac{\mu_0 h_{\theta}}{B_{\theta}} \frac{\partial P}{\partial x} = 0 \tag{5}$$

Use this to calculate  $h_{\theta}$  profiles (need to fix  $h_{\theta}$  at one radial location).

Close to x-points, the above expression becomes singular, so a better way to write it is:

$$\frac{\partial}{\partial x} \left( B^2 h_{\theta} \right) - h_{\theta} B_{\theta} \frac{\partial B_{\theta}}{\partial x} - B_{\zeta} R \frac{\partial}{\partial x} \left( \frac{B_{\zeta} h_{\theta}}{R} \right) + \mu_0 h_{\theta} \frac{\partial P}{\partial x} = 0$$

For solving force-balance by adjusting P and f profiles, the form used is

$$B_{\zeta}h_{\theta}\frac{\partial B_{\zeta}}{\partial x} + \frac{B_{\zeta}^{2}h_{\theta}}{R}\frac{\partial R}{\partial x} + \mu_{0}h_{\theta}\frac{\partial P}{\partial x} = -B_{\theta}\frac{\partial}{\partial x}\left(B_{\theta}h_{\theta}\right)$$

A quick way to calculate f is to rearrange this to:

$$\frac{\partial B_{\zeta}}{\partial x} = B_{\zeta} \left[ -\frac{1}{R} \frac{\partial R}{\partial x} \right] + \frac{1}{B_{\zeta}} \left[ -\mu_0 \frac{\partial P}{\partial x} - \frac{\partial B_{\theta}}{\partial h_{\theta}} \frac{\partial}{\partial x} \left( B_{\theta} h_{\theta} \right) \right]$$

and then integrate this using LSODE. This is done in the solve\_f function in process\_grid.pro

#### 8.3 Parallel current

$$J_{||} = \mathbf{b} \cdot \mathbf{J} \qquad b^y = \frac{B_{\theta}}{Bh_{\theta}}$$

and from equation 4:

$$J_{y} = \frac{1}{\mu_{0}} \left\{ -\frac{B^{2}h_{\theta}}{B_{\theta}} \frac{\partial}{\partial x} \left( B_{\zeta} R \right) + B_{\zeta} R \left[ \frac{\partial}{\partial x} \left( \frac{B^{2}h_{\theta}}{B_{\theta}} \right) - B_{\zeta} R \frac{\partial \nu}{\partial x} \right] \right\}$$

since  $J_{||} = b^y J_y$ ,

$$\mu_0 J_{||} = \frac{B_{\theta} B_{\zeta} R}{B h_{\theta}} \left[ \frac{\partial}{\partial x} \left( \frac{B^2 h_{\theta}}{B_{\theta}} \right) - B_{\zeta} R \frac{\partial \nu}{\partial x} \right] - B \frac{\partial}{\partial x} \left( B_{\zeta} R \right)$$

8.4 Curvature 17

#### 8.4 Curvature

For reduced MHD, need to calculate curvature term  $\mathbf{b} \times \kappa$ , where  $\kappa = -\mathbf{b} \times (\nabla \times \mathbf{b})$ . Re-arranging, this becomes:

$$\mathbf{b} \times \kappa = \nabla \times \mathbf{b} - \mathbf{b} (\mathbf{b} \cdot (\nabla \times \mathbf{b}))$$

Components of  $\nabla \times \mathbf{b}$  are:

$$(\nabla \times \mathbf{b})^{x} = \frac{B_{\theta}}{h_{\theta}} \frac{\partial}{\partial y} \left( \frac{B_{\zeta}R}{B} \right)$$

$$(\nabla \times \mathbf{b})^{y} = -\frac{B_{\theta}}{h_{\theta}} \frac{\partial}{\partial x} \left( \frac{B_{\zeta}R}{B} \right)$$

$$(\nabla \times \mathbf{b})^{z} = \frac{B_{\theta}}{h_{\theta}} \frac{\partial}{\partial x} \left( \frac{Bh_{\theta}}{B_{\theta}} \right) - \frac{B_{\theta}B_{\zeta}R}{h_{\theta}B} \frac{\partial \nu}{\partial x} - I \frac{B_{\theta}}{h_{\theta}} \frac{\partial}{\partial y} \left( \frac{B_{\zeta}R}{B} \right)$$

$$\mathbf{b} \cdot (\nabla \times \mathbf{b}) = -B \frac{\partial}{\partial x} \left( \frac{B_{\zeta} R}{B} \right) + \frac{B_{\zeta} B_{\theta} R}{B h_{\theta}} \frac{\partial}{\partial x} \left( \frac{B h_{\theta}}{B_{\theta}} \right) - \frac{B_{\theta} B_{\zeta}^{2} R^{2}}{h_{\theta} B^{2}} \frac{\partial \nu}{\partial x}$$

therefore,

$$(\mathbf{b} \times \kappa)^{x} = \frac{B_{\theta}}{h_{\theta}} \frac{\partial}{\partial y} \left( \frac{B_{\zeta}R}{B} \right) = -\frac{B_{\theta}B_{\zeta}R}{h_{\theta}B^{2}} \frac{\partial B}{\partial y}$$

$$(\mathbf{b} \times \kappa)^{y} = \frac{B_{\theta}^{2}B_{\zeta}^{2}R^{2}}{B^{3}h_{\theta}^{2}} \frac{\partial \nu}{\partial x} - \frac{B_{\theta}^{2}B_{\zeta}R}{B^{2}h_{\theta}^{2}} \frac{\partial}{\partial x} \left( \frac{Bh_{\theta}}{B_{\theta}} \right)$$

$$(\mathbf{b} \times \kappa)^{z} = \frac{B_{\theta}}{h_{\theta}} \frac{\partial}{\partial x} \left( \frac{Bh_{\theta}}{B_{\theta}} \right) - \frac{B_{\theta}B_{\zeta}R}{h_{\theta}B} \frac{\partial \nu}{\partial x} - I(\mathbf{b} \times \kappa)^{x}$$

Using equation 5:

$$B\frac{\partial}{\partial x}\left(\frac{Bh_{\theta}}{B_{\theta}}\right) + \frac{Bh_{\theta}}{B_{\theta}}\frac{\partial B}{\partial x} - B_{\zeta}R\frac{\partial}{\partial x}\left(\frac{B_{\zeta}h_{\theta}}{RB_{\theta}}\right) + \frac{\mu_{0}h_{\theta}}{B_{\theta}}\frac{\partial P}{\partial x} = 0$$

we can re-write the above components as:

$$(\mathbf{b} \times \kappa)^{y} = \frac{B_{\theta} B_{\zeta} R}{B^{2} h_{\theta}} \left[ \frac{\mu_{0}}{B} \frac{\partial P}{\partial x} + \frac{\partial B}{\partial x} \right]$$
$$(\mathbf{b} \times \kappa)^{z} = -\frac{\mu_{0}}{B} \frac{\partial P}{\partial x} - \frac{\partial B}{\partial x} - I (\mathbf{b} \times \kappa)^{x}$$

#### 8.5 Curvature of single line

The curvature vector can be calculated from the field-line toroidal coordinates  $(R, Z, \phi)$  as follows. The line element is given by

$$d\mathbf{r} = dR\hat{\mathbf{R}} + dZ\hat{\mathbf{Z}} + Rd\phi\hat{\phi}$$

Hence the tangent vector is

$$\hat{\mathbf{T}} \equiv \frac{d\mathbf{r}}{ds} = \frac{dR}{ds}\hat{\mathbf{R}} + \frac{dZ}{ds}\hat{\mathbf{Z}} + R\frac{d\phi}{ds}\hat{\phi}$$

where s is the distance along the field-line. From this, the curvature vector is given by

$$\kappa \equiv \frac{d\mathbf{T}}{ds} = \frac{d^2R}{ds^2}\hat{\mathbf{R}} + \frac{dR}{ds}\frac{d\phi}{ds}\hat{\phi} + \frac{d^2Z}{ds^2}\hat{\mathbf{Z}} + \frac{dR}{ds}\frac{d\phi}{ds}\hat{\phi} + R\frac{d^2\phi}{ds^2}\hat{\phi} - R\left(\frac{d\phi}{ds}\right)^2\hat{\mathbf{R}}$$

i.e.

$$\kappa = \left[ \frac{d^2 R}{ds^2} - R \left( \frac{d\phi}{ds} \right)^2 \right] \hat{\mathbf{R}} + \frac{d^2 Z}{ds^2} \hat{\mathbf{Z}} + \left[ 2 \frac{dR}{ds} + R \frac{d^2 \phi}{ds^2} \right] \hat{\phi}$$
 (6)

Want the components of  $\mathbf{b} \times \kappa$ , and since the vector  $\mathbf{b}$  is just the tangent vector  $\mathbf{T}$  above, this can be written using the cross-products

$$\hat{\mathbf{R}} \times \hat{\mathbf{Z}} = -\hat{\phi}$$
  $\hat{\phi} \times \hat{\mathbf{Z}} = \hat{\mathbf{R}}$   $\hat{\mathbf{R}} \times \hat{\phi} = \hat{\mathbf{Z}}$ 

This vector must then be dotted with  $\nabla \psi$ ,  $\nabla \theta$ , and  $\nabla \phi$ . This is done by writing these vectors in cylindrical coordinates:

$$\nabla \psi = \frac{\partial \psi}{\partial R} \hat{\mathbf{R}} + \frac{\partial \psi}{\partial Z} \hat{\mathbf{Z}}$$

$$\nabla \theta = \frac{1}{B_{\theta} h_{\theta}} \nabla \phi \times \nabla \psi = \frac{1}{R B_{\theta} h_{\theta}} \left( \frac{\partial \psi}{\partial Z} \hat{\mathbf{R}} - \frac{\partial \psi}{\partial R} \hat{\mathbf{Z}} \right)$$

#### 8.6 Curvature in toroidal coordinates

In toroidal coordinates  $(\psi, \theta, \phi)$ , the **b** vector is

$$\mathbf{b} = \frac{B_{\theta}}{B}\hat{\mathbf{e}}_{\theta} + \frac{B_{\zeta}}{B}\hat{\mathbf{e}}_{\phi}$$
$$= \frac{B_{\theta}h_{\theta}}{B}\nabla\theta + \frac{RB_{\zeta}}{B}\nabla\phi$$

The curl of this vector is

$$(\nabla \times \mathbf{b})^{\psi} = \frac{1}{\sqrt{g}} \left( \frac{\partial b_{\phi}}{\partial \theta} - \frac{\partial b_{\theta}}{\partial \phi} \right)$$
$$(\nabla \times \mathbf{b})^{\theta} = \frac{1}{\sqrt{g}} \left( \frac{\partial b_{\psi}}{\partial \phi} - \frac{\partial b_{\phi}}{\partial \psi} \right)$$
$$(\nabla \times \mathbf{b})^{\phi} = \frac{1}{\sqrt{g}} \left( \frac{\partial b_{\theta}}{\partial \psi} - \frac{\partial b_{\psi}}{\partial \theta} \right)$$

where  $1/\sqrt{g} = B_{\theta}/h_{\theta}$ . Therefore, in terms of unit vectors:

$$\nabla \times \mathbf{b} = \frac{1}{Rh_{\theta}} \frac{\partial}{\partial \theta} \left( \frac{RB_{\zeta}}{B} \right) \hat{\mathbf{e}}_{\psi} - B_{\theta} \frac{\partial}{\partial \psi} \left( \frac{RB_{\zeta}}{B} \right) \hat{\mathbf{e}}_{\theta} + \frac{B_{\theta}R}{h_{\theta}} \frac{\partial}{\partial \psi} \left( \frac{h_{\theta}B_{\theta}}{B} \right) \hat{\mathbf{e}}_{\phi}$$

### 8.7 $\psi$ derivative of B field

Needed to calculate magnetic shear, and one way to get the curvature. The simplest way is to use finite differencing, but there is another way using local derivatives (implemented using DCT).

$$B_{\theta} = \frac{|\nabla \psi|}{R} = \frac{1}{R} \sqrt{\left(\frac{\partial \psi}{\partial R}\right)^2 + \left(\frac{\partial \psi}{\partial R}\right)^2}$$

Using

$$\nabla B_{\theta} = \frac{\partial B_{\theta}}{\partial \psi} \nabla \psi + \frac{\partial B_{\theta}}{\partial \theta} \nabla \theta + \frac{\partial B_{\theta}}{\partial \phi} \nabla \phi$$

we get

$$\nabla B_{\theta} \cdot \nabla \psi = \frac{\partial B_{\theta}}{\partial \psi} \left| \nabla \psi \right|^2$$

and so

$$\frac{\partial B_{\theta}}{\partial \psi} = \nabla B_{\theta} \cdot \nabla \psi / \left( R B_{\theta} \right)^{2}$$

The derivatives of  $B_{\theta}$  in R and Z are:

$$\begin{array}{lll} \frac{\partial B_{\theta}}{\partial R} & = & -\frac{B_{\theta}}{R} + \frac{1}{B_{\theta}R^2} \left[ \frac{\partial \psi}{\partial R} \frac{\partial^2 \psi}{\partial R^2} + \frac{\partial \psi}{\partial Z} \frac{\partial^2 \psi}{\partial R \partial Z} \right] \\ \frac{\partial B_{\theta}}{\partial Z} & = & \frac{1}{B_{\theta}R^2} \left[ \frac{\partial \psi}{\partial Z} \frac{\partial^2 \psi}{\partial Z^2} + \frac{\partial \psi}{\partial R} \frac{\partial^2 \psi}{\partial R \partial Z} \right] \end{array}$$

For the toroidal field,  $B_{\zeta} = f/R$ 

$$\frac{\partial B_{\zeta}}{\partial \psi} = \frac{1}{R} \frac{\partial f}{\partial \psi} - \frac{f}{R^2} \frac{\partial R}{\partial \psi}$$

As above,  $\frac{\partial R}{\partial \psi} = \nabla R \cdot \nabla \psi / (RB_{\theta})^2$ , and since  $\nabla R \cdot \nabla R = 1$ ,

$$\frac{\partial R}{\partial \psi} = \frac{\partial \psi}{\partial R} / \left( R B_{\theta} \right)^2$$

similarly,

$$\frac{\partial Z}{\partial \psi} = \frac{\partial \psi}{\partial Z} / \left( RB_{\theta} \right)^2$$

and so the variation of toroidal field with  $\psi$  is

$$\frac{\partial B_{\zeta}}{\partial \psi} = \frac{1}{R} \frac{\partial f}{\partial \psi} - \frac{B_{\zeta}}{R^3 B_{\theta}^2} \frac{\partial \psi}{\partial R}$$

From the definition  $B = \sqrt{B_{\zeta}^2 + B_{\theta}^2}$ ,

$$\frac{\partial B}{\partial \psi} = \frac{1}{B} \left( B_{\zeta} \frac{\partial B_{\zeta}}{\partial \psi} + B_{\theta} \frac{\partial B_{\theta}}{\partial \psi} \right)$$

#### 8.8 Magnetic shear from $J \times B$

Re-arranging the radial force balance equation 5 gives

$$\frac{B_{\theta}^{2}R}{B_{\zeta}}\frac{\partial\nu}{\partial\psi} + \nu\left(\frac{2RB}{B_{\zeta}}\frac{\partial B}{\partial\psi} + \frac{B^{2}}{B_{\zeta}}\frac{\partial R}{\partial\psi} - \frac{B^{2}R}{B_{\zeta}^{2}}\frac{\partial B_{\zeta}}{\partial\psi}\right) + \frac{\mu_{0}h_{\theta}}{B_{\theta}}\frac{\partial P}{\partial\psi} = 0$$

# 8.9 Magnetic shear

The field-line pitch is given by

$$\nu = \frac{h_{\theta} B_{\zeta}}{B_{\theta} R}$$

and so

$$\frac{\partial \nu}{\partial \psi} = \frac{\nu}{h_{\theta}} \frac{\partial h_{\theta}}{\partial \psi} + \frac{\nu}{B_{\zeta}} \frac{\partial B_{\zeta}}{\partial \psi} - \frac{\nu}{B_{\theta}} \frac{\partial B_{\theta}}{\partial \psi} - \frac{\nu}{R} \frac{\partial R}{\partial \psi}$$

The last three terms are given in the previous section, but  $\partial h_{\theta}/\partial \psi$  needs to be evaluated