



BSV Training

Lec_Interop_C



BSV interoperates with V, SV, VHDL, SystemC, and C/C++





V (Verilog), SV (SystemVerilog), VHDL, or SystemC (event-driven)

BSV

C, C++



Plugging C/C++ into BSV



Motivations for importing C/C++

- Many applications begin life as C/C++ models:
 - When you are creating a HW accelerator for an existing SW program
 - When you are trying to choose the best algorithm before going to HW implementation

As you incrementally develop your BSV implementation, you may wish to reuse C/C++ components temporarily (or even permanently, for the testbench)

- When you add a new "primitive" to BSV by importing Verilog, you may also want to import a corresponding C model for running in Bluesim
 - In fact, all BSV "primitives" are imported this way—the knowledge is not built into the compiler



Importing C

- You declare a BSV function prototype (i.e., just the types) which is then implemented in C
- Example:

```
// BSV code
                                                    // C code
import "BDPI" rand32 =
                                                    #include <stdio.h>
  function ActionValue #(Bit#(32)) bsv rand32();
                                                    #include <stdlib.h>
module test(Empty);
                                                    unsigned int rand32()
 FIFO#(Bit#(32)) myFIFO <- mkSizedFIFO(9);
                                                      return (unsigned int) rand();
 rule fill;
   let x < -bsv rand32;
   myFIFO.eng(x);
 endrule
 rule empty;
   myFIFO.deq;
   $display("Number %d", myFIFO.first);
 endrule
endmodule
```

Importing C: arguments and results

- There is a 1-to-1 correspondence between the arguments and result in the BSV prototype and in the C function.
- Allowed arguments types
 - any type that is in the Bits#() typeclass
 - String
 - polymorphic types
- Allowed result types:
 - any type that is in the Bits#() typeclass
 - Action
 - ActionValue#(t) where t is in the Bits#() typeclass
 - polymorphic types (and polymorphic ActionValue #(t) types)
- For "small" types (<= 64b), the corresponding C argument or result is the nearest C scalar integer type adequate to contain it (char, short, long, long long)
- For "larger" types and polymorphic types, the C function receives a "void *" pointer to the storage for that value
 - This storage contains the "raw bits" of the BSV representation
 - For return types that are passed using "void *" like this, the "void *" pointer is passed as the first argument of the C function, not returned as the C function value
- Details and examples in the Reference Guide, Sec. 16



Recommendation: arguments and results

- Although the 'import C' arguments and results can be of arbitrary type, it's usually too much effort, and too error-prone, and too non-portable to exploit this capability
 - The representation of C types varies across C compilers and across target architectures (insertion of padding for word alignment, little- and big-endianness, etc.

Recommendation:

- a) Stick to just a few standard, highly portable types: 32b and 64b scalars, and arrays/vectors thereof.
 - In the C code, use standard types declared in <stdint.h>: uint32_t, int32_t, uint64_t, int64_t, and arrays of those types
 - In the BSV code, correspondingly, use UInt#(32), Int#(32), UInt#(64), Int#(64), and Vector#(n,...) of those types
- b) In both the C code and the BSV code, write functions to convert from "native" types (enums, structs, unions) to standard types (a) and back.
 - Being purely in C and BSV, such conversion functions are easy to write and very predictable and reliable
 - E.g., convert a struct to and array of uint32_t or uint64_t
 - E.g., convert a C pointer to a uint64_t (pointers may not fit in uint32_t)
- c) In both the C code and the BSV code, use these functions on arguments and results so that only these standard types (a) are passed between C and BSV



Linking in the imported C function(s)

• Compilation of an "import BDPI" produces intermediate ".ba" files

```
# bsc -u -sim DUT.bsv
checking package dependencies
compiling DUT.bsv
Foreign import file created: compute_vector.ba
code generation for mkDUT starts
Elaborated Bluesim module file created: mkDUT.ba
code generation for mkTB starts
Elaborated Bluesim module file created: mkTB.ba
```

• In the link stage (for Bluesim or Verilog sim, you supply these .ba files and the C file

```
# bsc -sim -e mkTB -o bsim mkTB.ba mkDUT.ba compute_vector.ba vectors.c
Bluesim object created: mkTB.{h,o}
Bluesim object created: mkDUT.{h,o}
Bluesim object created: schedule.{h,o}
User object created: vectors.o
Bluesim binary file created: bsim
```

When you compile for Verilog sim, bsc generates the appropriate "VPI"-like linkage files that allows your Verilog simulator to import the C code (for most popular simulators like VCS, NCSim, Modelsim, iVerilog, CVC, etc.)



Importing C++ (as opposed to C)

The BSV "import BDPI" mechanism can only directly invoke C functions (it assumes function linkage conventions for C, and C++ typically has different linkage conventions).

C++ has an 'extern "C" construct that tells the C++ compiler to compile a function with C linkage instead of C++ linkage. That function, in turn, can freely call C++ functions.

Thus, the following example illustrates the idiom for calling C++ from BSV:

- We using "import BDPI" to invoke a function myMainC function() which has C linkage
- This, in turn, calls the desired C++ function myMainCPP_function():

```
// File foo.cpp (C++)

// This is the C++ function we would like to invoke from BSV
int myMainCPP_function(int a, int b) {
    ... C++ code ...
}

extern "C" { // This is the function imported into BSV
    void myMainC_function (int a, int b)
    {
        return myMainCPP_function (a, b);
    }
}
```



Plugging BSV into SystemC



Plugging BSV into SystemC


The *bsc* compiler directly supports, via a command-line flag, the creation of a "plug-in" into a SystemC program (User Guide Sec. 4.3.2)

```
// File mkFoo_systemc.h (SystemC)

SC_MODULE (mkFoo)
{
   public:
    sc_in<...> ...;
    sc_out<...> ...;
   ...
public:
   SC_CTOR (mkFoo) ...
   ~mkFoo() ...
}
```

```
// File mkFoo_systemc.cxx
// C++ code (not SystemC)
// implementing the declarations
// in the .h file
```


(Bluespec tests this facility with the standard OSCI SystemC simulator, but expects it to work with any SystemC simulator)



The .h file is standard SystemC. It declares mkFoo as a SystemC SC_MODULE. The sc_in and sc_out ports are SystemC signal declarations, corresponding exactly to what you would have got if you had compiled the BSV code to Verilog.

You should "#include" this .h file in your SystemC program, which can then invoke the constructor mkFoo to instantiate the module, and use the sc_in and sc_out ports to communicate with it, in the usual SystemC way.


The .cxx file is compiled with your C++ compiler as usual, and linked in with the rest of your SystemC program's object files, to create the SystemC executable.



Plugging BSV into SystemC


Note: Only the .h file is intended for human readability.

Although the .cxx file is C++ source code, it is a complex translation of the cycle-level behavior of the source BSV module and does not try to mirror the BSV source structure in any recognizable way.



```
// File mkFoo_systemc.cxx
// C++ code (not SystemC)
// implementing the declarations
// in the .h file
...
```

The .cxx file is compiled with your C++ compiler as usual, and linked in with the rest of your SystemC program's object files, to create the SystemC executable.





End

