

## PS4 differences:

- AREF pulse = active low instead of high. Does not power a hall effect sensor, reading is taken immediately (no power-up delay like XB1)
- Voltage reference for analog sticks = 3.3v instead of 1.8v
- Analog trigger voltage reference = 3.3v instead of AREF pulse
- AREF pulse still goes through comparator and to Teensy, but is not used as a voltage reference for the digital potentiometer playback

## Added Mux #1: Analog Stick and Trigger Mod




## Added Mux #2: L3 R3 LB RB pull-up mod to handle inversed logic



Connect SENSE/CONTROL to Pin 1 (DIR) of any nearby TS3A5018 quad switch IC. Note this control signal is being used differently on this quad switch versus the other ones. (as chip enable not select)

Mod points for the digital potentiometer section (Mux 1)



## Mod points for the inversed digital button section (Mux 2)

