

# Mount Depth Reference

Minimum inside-mount depth by line, how the depth is measured, and the outside-mount threshold.

FOR SPECIFIERS AND INSTALLERS

## MOUNTING

# Minimum inside-mount depth

The depth each line needs to sit inside the opening, and what to do when the opening is shallower than that.

## By product group

| MINIMUM DEPTH | APPLIES TO                |
|---------------|---------------------------|
| 3/4"          | Cellular                  |
| 2"            | Roller, solar & faux wood |
| 2 1/2"        | Roman & sheer             |
| Framed        | Shutters                  |
| Outside mount | Under 3/4"                |

## By line, as published

| LINE                  | PUBLISHED MOUNT NOTE                     | HEADRAIL / TRACK                |
|-----------------------|------------------------------------------|---------------------------------|
| Cellular Shades       | Inside or outside · 3/4" minimum depth   | ClearFit™ 1 1/2" · low-profile  |
| Roller & Solar Shades |                                          | —                               |
| Roman Shades          | Inside or outside · 2 1/2" minimum depth | Fabric-wrapped 2" · ClearFit™   |
| Faux Wood Blinds      | Inside or outside · 2" minimum depth     | —                               |
| Shutters              | Inside opening with frame                | L-frame, deco frame, Z-frame    |
| Sheer Shades          | Inside or outside · 2 1/2" minimum depth | ClearFit™ 2 1/2" fabric-wrapped |
| DualDrape™            | Ceiling or wall mount                    | Low-profile 2 3/4" track        |
| Vertical Blinds       | Ceiling or wall mount                    | Low-profile 2 3/4"              |

## How the depth is measured

- 1 Measure from the face of the glass stop, or the innermost obstruction, to the front edge of the opening.
- 2 Take the measurement at the head of the opening, where the headrail will sit.

- 3 Deduct nothing. The figures above are net depths for the product, not for the opening.
- 4 Where a crank, handle, alarm contact or trim projects into the opening, measure to the projection rather than to the stop.
- 5 If the available depth is under the published minimum, specify an outside mount.

#### SHALLOW OPENINGS

An outside mount is a specification choice, not a fallback. It covers the trim as well as the glass, which closes the side light gap that an inside mount leaves. Products are not modified to fit a shallow opening.

## Light gap

An inside-mounted shade leaves a light gap of about 1/4" on each side with a ClearFit™ headrail cut to the opening. Where a room has to be genuinely dark, specify SmartPrivacy® side channels on a blackout fabric, or move to an outside mount. Veneta does not describe any configuration as total blackout.

Full measuring method at [venetawindowfashions.com/how-to-measure](https://venetawindowfashions.com/how-to-measure).