




Construction Manual



Welcome to the FABI

Construction Manual

This manual covers detailed step-by-step instructions for building the FABI alternative input system.

As additional tools you will need:

- a soldering iron with a fine tip
- sharp side-cutting pliers
- a slotted screwdriver
- optionally a PCB holder

The required materials are:

- tin-solder (small diameter)
- adhesive tape (Scotch tape)

Legend



Solder / do not solder



Clip / do not clip with pliers



Fix / do not fix with tape



Attention: orientation of this part is important!




This part is done in this step



Part number for this step
(see part overview on page 3)

Part Overview - Basic Parts



Part Overview - Case


14




16



15



17




18




BT - AddOn



1




6

1x 200/180R



7

**5x 10k**











8

2x 18k







3








11

12




180°


10



13





180°




180°



9







17




optional







10





optional





Copyright 2021, AsTeRICS Foundation, CC-BY-SA 3.0
office@asterics-foundation.org

Acknowledgements:

Futura fonts by www.onlinewebfonts.com (CC BY 3.0)

Exclamation mark icon made by Pixel Buddha from
www.flaticon.com

Illustrations based on work of Moritz Schwarzl
(moritz.schwarzl@gmx.at)
and Fritzing parts.