




Construction Manual



Welcome to the FABI

Construction Manual

This manual covers detailed step-by-step instructions for building the FABI alternative input system.

As additional tools you will need:

- a soldering iron with a fine tip
- sharp side-cutting pliers
- a slotted screwdriver
- optionally a PCB holder

The required materials are:

- tin-solder (small diameter)
- adhesive tape (Scotch tape)

Legend



Solder / do not solder



Clip / do not clip with pliers



Fix / do not fix with tape



Attention: orientation of this part is important!




This part is done in this step



Part number for this step
(see part overview on page 3)

Part Overview - Electronic Parts


1



2



4



8x




5



8x

6 220R

12



7

2x 18k



14




8

5x 10k



13



11



Part Overview - Case Parts


14




16




15




1





2




3




5




4






8x





5





8x




6




7




8





5x





9



optional








10








11

12







13



14



optional



14

15

Case
zusammenbau
en

16

M3
schrauben

Copyright 2021, AsTeRICS Foundation, CC-BY-SA 3.0
office@asterics-foundation.org

Acknowledgements:

Futura fonts by www.onlinewebfonts.com (CC BY 3.0)

Exclamation mark icon made by Pixel Buddha from www.flaticon.com

Illustrations based on work of Moritz Schwarzl (moritz.schwarzl@gmx.at)
and Fritzing parts.