

AIRPORT DIAGRAM

AL-282 (FAA)

NASHVILLE INTL (BNA)
NASHVILLE, TENNESSEE

CAUTION: BE ALERT TO RUNWAY CROSSING CLEARANCES.
READBACK OF ALL RUNWAY HOLDING INSTRUCTIONS IS REQUIRED.

SAID in use. Operate transponders with altitude reporting mode and ADS-B (if equipped) enabled on all airport surfaces.

D-ATIS 135.1
NASHVILLE TOWER 118.6 257.8
GND CON 121.9 348.6
CLNC DEL 126.05
CPDLC
PDC
D

SE-1, 01 OCT 2026 to 29 OCT 2026

SE-1, 01 OCT 2026 to 29 OCT 2026

