

LOC/DME I-CAE <u>110.3</u> Chan 40	APP CRS 112°	Rwy Ldg 8601 TDZE 236 Apt Elev 236
--	------------------------	---

ILS or LOC RWY 11
COLUMBIA METRO (CAE)

DME or RADAR required.

T For inop ALS, increase S-ILS 11 Cat E visibility to RVR 4000, S-LOC 11 Cats C/D/E visibility to $1\frac{3}{8}$ SM, and BEHRN minimums S-LOC 11 Cats C/D/E visibility to $1\frac{3}{8}$ SM.

ALSF-2



MISSED APPROACH: Climb to 1100 then climbing right turn to 2300 direct CAE VORTAC and hold, continue climb-in-hold to 2300. (TACAN aircraft continue on CAE VORTAC R-140 to ADCOM INT/CAE VORTAC 10 DME and hold NW, right turn, 140° inbound).

ATIS 120.15	COLUMBIA APP CON		COLUMBIA TOWER		GND CON	
	124.15	338.2 (110°-289°)	119.5	257.8	121.9	348.6
	133.4	285.6 (290°-109°)				