#### **Lecture 2: Classical Control Theory & Design**

**Textbook Sections 2.1-2.6** 

Dr. Jordan D. Larson



Model-based design: use dynamical systems theory to model real-world processes

#### Introduction

- Model-based design: use dynamical systems theory to model real-world processes
- Simplest model: single input, single output (SISO) and linear, time-invariant (LTI)
  - System to be designed: controller, K
  - System to be controlled: plant, G

#### Introduction

- Model-based design: use dynamical systems theory to model real-world processes
- Simplest model: single input, single output (SISO) and linear, time-invariant (LTI)
  - System to be designed: controller, K
  - System to be controlled: plant, G
- Dvnamical systems: many varieties
  - Flight dynamics: MIMO, nonlinear, time-varying
  - Flight control design: MIMO, linear, time-invariant with robustness to model uncertainty
  - Classical control applies SISO LTI theory and design to multiple loops for aerospace vehicles

#### Introduction

- Model-based design: use dynamical systems theory to model real-world processes
- Simplest model: single input, single output (SISO) and linear, time-invariant (LTI)
  - System to be designed: controller, K
  - System to be controlled: plant, G
- Dynamical systems: many varieties
  - Flight dynamics: MIMO, nonlinear, time-varying
  - Flight control design: MIMO, linear, time-invariant with robustness to model uncertainty
  - Classical control applies SISO LTI theory and design to multiple loops for aerospace vehicles
- Open- and closed-loop control laws
  - A.k.a. feedforward and feedback, respectively
  - Feedback accounts for disturbances/uncertainties to plant model

# **Open-Loop Control**


Simplest types of control laws: open-loop control strategies, a.k.a. feedforward control

## Open-Loop Control

- Simplest types of control laws: open-loop control strategies, a.k.a. feedforward control
- In general, logic flow:
  - 1 User specifies commanded output  $y_c$
  - 2 Control law sets input *u* as function of commanded output
  - 3 Dynamically changes output y(t)

#### **Open-Loop Control**

- Simplest types of control laws: open-loop control strategies, a.k.a. feedforward control
- In general, logic flow:
  - 1 User specifies commanded output  $y_c$
  - **2** Control law sets input *u* as function of commanded output
  - **3** Dynamically changes output y(t)
- Open-loop control of SISO LTI systems block diagram:



#### **Open-Loop Control: Actuation System**


• For real systems, *u* will undergo some dynamics itself, i.e. plant input won't instantaneously reach electric controller's computed *u* 

## **Open-Loop Control: Actuation System**

- For real systems, u will undergo some dynamics itself, i.e. plant input won't instantaneously reach electric controller's computed u
- Truly actuated using some electro-mechanical interface: represent by actuation system, a.k.a. **actuator**

## **Open-Loop Control: Actuation System**

- For real systems, *u* will undergo some dynamics itself, i.e. plant input won't instantaneously reach electric controller's computed *u*
- Truly actuated using some electro-mechanical interface: represent by actuation system, a.k.a. actuator
- Additional consideration results in following block diagram for SISO LTI systems



## **Open-Loop Control Actuation System (continued)**

• Using dynamical systems theory, one can typically model actuation systems, A(s), as first- or second-order LTI systems, e.g.

$$A(s) = \frac{\omega_a}{s + \omega_a} \tag{1}$$

## **Open-Loop Control Actuation System (continued)**

• Using dynamical systems theory, one can typically model actuation systems, A(s), as first- or second-order LTI systems, e.g.

$$A(s) = \frac{\omega_a}{s + \omega_a} \tag{1}$$

$$A(s) = \frac{\omega_a^2}{s^2 + 2\zeta_a\omega_a s + \omega_a^2}$$
 (2)

- $\omega_a$ : bandwidth of actuator
- $\zeta_a$ : damping

# **Open-Loop Control Actuation System (continued)**

• Using dynamical systems theory, one can typically model actuation systems, A(s), as first- or second-order LTI systems, e.g.


$$A(s) = \frac{\omega_a}{s + \omega_a} \tag{1}$$

$$A(s) = \frac{\omega_a^2}{s^2 + 2\zeta_a\omega_a s + \omega_a^2}$$
 (2)


- $\omega_a$ : bandwidth of actuator
- $\zeta_a$ : damping
- Actuators also typically have hard limits on minimum and maximum output as well as hard rate limits

- For real systems will have additional disturbances to plant model
  - Modeled as additive disturbance signal, w, to control input, u, which results in a as

- For real systems will have additional disturbances to plant model
  - Modeled as additive disturbance signal, w, to control input, u, which results in a as
- Block diagram for SISO LTI systems:




- For real systems will have additional disturbances to plant model
  - Modeled as additive disturbance signal, w, to control input, u, which results in a as
- Block diagram for SISO LTI systems:



- If no explicit knowledge of disturbances: may not guarantee control system satisfies design requirements using only open-loop control
  - · Strategy does not gather any information about disturbances as they occur


- For real systems will have additional disturbances to plant model
  - Modeled as additive disturbance signal, w, to control input, u, which results in a as
- Block diagram for SISO LTI systems:




- If no explicit knowledge of disturbances: may not guarantee control system satisfies design requirements using only open-loop control
  - Strategy does not gather any information about disturbances as they occur
- To reject these disturbances and account for system uncertainties: use alternative control strategies

- Closed-loop control, a.k.a. feedback control:
  - Feed plant output signal back to control law

- Closed-loop control, a.k.a. feedback control:
  - Feed plant output signal back to control law
- Block diagram for SISO LTI systems:




- Closed-loop control, a.k.a. feedback control:
  - Feed plant output signal back to control law
- Block diagram for SISO LTI systems:



• Use output of plant, y(t), to compute tracking error, e(t), directly affects control input to plant, u(t), in turn, affects plant output and so on, as time continues

- Closed-loop control, a.k.a. feedback control:
  - Feed plant output signal back to control law
- Block diagram for SISO LTI systems:




- Use output of plant, y(t), to compute tracking error, e(t), directly affects control input to plant, u(t), in turn, affects plant output and so on, as time continues
- For real systems, output signal measured by sensor system, or sensor:
  - Measures output of system using physical phenomena converted into a measured signal
  - · Similar to input signal being actuated in real systems

#### **Closed-Loop Control: Sensor System**

• No sensor provides perfect information: consider additive noise signal, v, to output, y


## **Closed-Loop Control: Sensor System**

- No sensor provides perfect information: consider additive noise signal, v, to output, y
- Block diagram for SISO LTI systems:



## **Open- and Closed-Loop Control**

Feedforward and feedback control combined as block diagram:




#### **Stability Augmentation Systems**

- Special type of feedback control system: stability augmentation system (SAS)
  - Plant controlled by external operator, e.g. pilot, but inherent response characteristics, e.g. modal stability or damping, not within design specifications
  - SAS used to "augment" plant dynamics to achieve certain dynamic responses, typically stability or excessive damping

## **Stability Augmentation Systems**

- Special type of feedback control system: stability augmentation system (SAS)
  - Plant controlled by external operator, e.g. pilot, but inherent response characteristics, e.g. modal stability or damping, not within design specifications
  - SAS used to "augment" plant dynamics to achieve certain dynamic responses, typically stability or excessive damping
- SAS for SISO LTI systems as block diagram:





#### **Proportional Stability Augmentation System**


 Classical stability augmentation system design method: root locus method as proportional SAS (P-SAS):

$$K_{P-SAS}(s) = \frac{u_k(s)}{y(s)} = k \tag{3}$$


k > 0: negative feedback gain









• G(s): actuator-plant-sensor combination




- *G*(*s*): actuator-plant-sensor combination
- K(s): controller




- *G*(*s*): actuator-plant-sensor combination
- K(s): controller
- y<sub>c</sub>: desired output signal




- *G*(*s*): actuator-plant-sensor combination
- *K*(*s*): controller
- y<sub>c</sub>: desired output signal
- e: tracking error signal



- *G*(*s*): actuator-plant-sensor combination
- *K*(*s*): controller
- y<sub>c</sub>: desired output signal
- e: tracking error signal
- *u*: control input signal




- G(s): actuator-plant-sensor combination
- K(s): controller
- y<sub>c</sub>: desired output signal
- e: tracking error signal
- u: control input signal
- w: noise signal to dynamic system input, e.g. disturbance




- *G*(*s*): actuator-plant-sensor combination
- K(s): controller
- y<sub>c</sub>: desired output signal
- e: tracking error signal
- u: control input signal
- w: noise signal to dynamic system input, e.g. disturbance
- y: system output signal

## Classical Feedback Control System Model



- G(s): actuator-plant-sensor combination
- K(s): controller
- $y_c$ : desired output signal
- e: tracking error signal
- u: control input signal
- w: noise signal to dynamic system input, e.g. disturbance
- y: system output signal
- v: noise signal on dynamic system output, e.g. sensor noise

## **Classical Feedback Control System Model**



- *G*(*s*): actuator-plant-sensor combination
- K(s): controller
- y<sub>c</sub>: desired output signal
- e: tracking error signal
- *u*: control input signal
- w: noise signal to dynamic system input, e.g. disturbance
- y: system output signal
- v: noise signal on dynamic system output, e.g. sensor noise
- v<sub>m</sub>: measured output signal

$$L(s) = G(s)K(s) \tag{4}$$

- Plays large role in analysis of SISO LTI control system
- Note: *L(s)* control system transfer function if open-loop control design

$$L(s) = G(s)K(s) \tag{4}$$

- Plays large role in analysis of SISO LTI control system
- Note: *L(s)* control system transfer function if open-loop control design
- 3 input signals (external/independent):  $y_c, w, v$

$$L(s) = G(s)K(s) \tag{4}$$

- Plays large role in analysis of SISO LTI control system
- Note: *L(s)* control system transfer function if open-loop control design
- 3 input signals (external/independent):  $y_c, w, v$
- 4 output signals (internal/dependent): e, u, y, y<sub>m</sub>

$$L(s) = G(s)K(s) \tag{4}$$

- Plays large role in analysis of SISO LTI control system
- Note: *L(s)* control system transfer function if open-loop control design
- 3 input signals (external/independent):  $v_c$ , w, v
- 4 output signals (internal/dependent): e, u, v, v<sub>m</sub>
- Input-output pairs have associated transfer function, 12 total:

$$\begin{bmatrix} y(s) \\ y_m(s) \\ e(s) \\ u(s) \end{bmatrix} = \begin{bmatrix} \frac{GK}{1+GK} & \frac{G}{1+GK} & -\frac{GK}{1+GK} \\ \frac{GK}{1+GK} & \frac{G}{1+GK} & \frac{1}{1+GK} \\ \frac{1}{1+GK} & -\frac{G}{1+GK} & -\frac{1}{1+GK} \\ \frac{K}{1+GK} & -\frac{GK}{1+GK} & -\frac{K}{1+GK} \end{bmatrix} \begin{bmatrix} y_c(s) \\ w(s) \\ v(s) \end{bmatrix}$$
(5)

• Four fundamental transfer functions (ignoring sign)

$$\frac{1}{1+G(s)K(s)}, \frac{G(s)K(s)}{1+G(s)K(s)}, \frac{G(s)}{1+G(s)K(s)}, \frac{K(s)}{1+G(s)K(s)}$$
(6)

Four fundamental transfer functions (ignoring sign)

$$\frac{1}{1+G(s)K(s)}, \frac{G(s)K(s)}{1+G(s)K(s))}, \frac{G(s)}{1+G(s)K(s)}, \frac{K(s)}{1+G(s)K(s)}$$
(6)

- Selecting K(s) affects four fundamental transfer functions
  - Study of fundamental transfer functions: key to classical control systems theory

• Four fundamental transfer functions (ignoring sign)

$$\frac{1}{1+G(s)K(s)}, \frac{G(s)K(s)}{1+G(s)K(s))}, \frac{G(s)}{1+G(s)K(s)}, \frac{K(s)}{1+G(s)K(s)}$$
(6)

- Selecting K(s) affects four fundamental transfer functions
  - Study of fundamental transfer functions: key to classical control systems theory
- Error transfer function:

$$S(s) = \frac{e(s)}{y_c(s)} = \frac{1}{1 + G(s)K(s)} = \frac{1}{1 + L(s)}$$
 (7)

• Four fundamental transfer functions (ignoring sign)

$$\frac{1}{1+G(s)K(s)}, \frac{G(s)K(s)}{1+G(s)K(s)}, \frac{G(s)}{1+G(s)K(s)}, \frac{K(s)}{1+G(s)K(s)}$$
(6)

- Selecting K(s) affects four fundamental transfer functions
  - Study of fundamental transfer functions: key to classical control systems theory
- Error transfer function:

$$S(s) = \frac{e(s)}{y_c(s)} = \frac{1}{1 + G(s)K(s)} = \frac{1}{1 + L(s)}$$
(7)

Closed-loop transfer function:

$$T(s) = \frac{y(s)}{y_c(s)} = \frac{G(s)K(s)}{1 + G(s)K(s)} = \frac{L(s)}{1 + L(s)}$$
(8)

# Sensitivity Transfer Function

• S(s) a.k.a. sensitivity transfer function

# **Sensitivity Transfer Function**

- S(s) a.k.a. sensitivity transfer function
- T(s) a.k.a. complementary sensitivity transfer function:

$$S(s) + T(s) = \frac{1}{1 + G(s)K(s)} + \frac{G(s)K(s)}{1 + G(s)K(s)}$$
(9)

$$S(s) + T(s) = 1 \quad \forall \ s \in \mathbb{C}$$
 (10)

### **Aside: P-SAS Root Locus**

• P-SAS produces overall system transfer function:

$$y(s) = \left[\frac{G(s)}{1 + kG(s)}\right] u_c(s) \tag{11}$$

### **Aside: P-SAS Root Locus**

• P-SAS produces overall system transfer function:

$$y(s) = \left[\frac{G(s)}{1 + kG(s)}\right] u_c(s) \tag{11}$$

Closed-loop system poles:

$$d_G(s) + kn_G(s) = 0 (12)$$

- $n_G(s)$ : numerator polynomial of G(s)
- $d_G(s)$ : denominator polynomial of G(s)

### **Aside: P-SAS Root Locus**

• P-SAS produces overall system transfer function:

$$y(s) = \left[\frac{G(s)}{1 + kG(s)}\right] u_c(s) \tag{11}$$

Closed-loop system poles:

$$d_G(s) + kn_G(s) = 0 (12)$$

- $n_G(s)$ : numerator polynomial of G(s)
- $d_G(s)$ : denominator polynomial of G(s)
- Sweeping through values of k from 0 to  $\infty$ , alter system poles from  $d_G(s)$  to  $n_G(s)$  and/or  $\pm\infty$ 
  - Depends on number of zeros relative to number of poles
  - Behavior: **root locus plot** of system poles and zeros as k varies from 0 to  $\infty$

Control system design, at minimum, requires stability

- Control system design, at minimum, requires stability
- For classical feedback control system model: if and only if all transfer functions stable

- Control system design, at minimum, requires stability
- For classical feedback control system model: if and only if all transfer functions stable
- Simplify by considering numerator-denominator of G(s) and K(s)

$$G(s) = \frac{n_G(s)}{d_G(s)} \tag{13}$$

$$K(s) = \frac{n_K(s)}{d_K(s)} \tag{14}$$

- Control system design, at minimum, requires stability
- For classical feedback control system model: if and only if all transfer functions stable
- Simplify by considering numerator-denominator of G(s) and K(s)

$$G(s) = \frac{n_G(s)}{d_G(s)} \tag{13}$$

$$K(s) = \frac{n_K(s)}{d_K(s)} \tag{14}$$

•  $d_G d_K + n_G n_K$  denominator for each fundamental transfer function: SISO feedback control system characteristic polynomial

SISO feedback control system characteristic equation:

$$d_G(s)d_K(s) + n_G(s)n_K(s) = 0$$
 (15)

SISO feedback control system characteristic equation:

$$d_G(s)d_K(s) + n_G(s)n_K(s) = 0$$
(15)

- Roots/poles in left half of complex plane → feedback system stable
  - True even if pole-zero cancellations

SISO feedback control system characteristic equation:

$$d_G(s)d_K(s) + n_G(s)n_K(s) = 0$$
(15)

- Roots/poles in left half of complex plane → feedback system stable
  - True even if pole-zero cancellations
- Note: 1 + L = 1 + GK appears in denominator of each fundamental transfer function

$$1 + L(s) = 1 + G(s)K(s) = 1 + \frac{n_G n_K}{d_G d_K} = \frac{d_G(s)d_K(s) + n_G(s)n_K(s)}{d_G(s)d_K(s)}$$
(16)

• Numerator of 1 + L(s): SISO LTI feedback characteristic polynomial

SISO feedback control system characteristic equation:

$$d_{G}(s)d_{K}(s) + n_{G}(s)n_{K}(s) = 0$$
(15)


- Roots/poles in left half of complex plane → feedback system stable
  - True even if pole-zero cancellations
- Note: 1 + L = 1 + GK appears in denominator of each fundamental transfer function

$$1 + L(s) = 1 + G(s)K(s) = 1 + \frac{n_G n_K}{d_G d_K} = \frac{d_G(s)d_K(s) + n_G(s)n_K(s)}{d_G(s)d_K(s)}$$
(16)

- Numerator of 1 + L(s): SISO LTI feedback characteristic polynomial
- As 1 + L(s) still affected by pole-zero cancellations: stable feedback control system if and only if
  - **1** No RHP pole-zero cancellations when forming L(s)
  - 2 1 + L(s) no zeros in RHP

### **Critical Gain Model**


• Consider scaling perturbation to *G*(*s*):



• *g* > 0: some scalar constant

#### **Critical Gain Model**


• Consider scaling perturbation to *G*(*s*):



- *g* > 0: some scalar constant
- Define perturbed open-loop transfer function as gL(s)

#### **Critical Gain Model**

• Consider scaling perturbation to *G*(*s*):



- *g* > 0: some scalar constant
- Define perturbed open-loop transfer function as gL(s)
- Gain margin determined by assessing for what critical values of g feedback control system goes unstable

## **Critical Gain Computation**

- Recall feedback control system stable if
  - 1. No pole-zero cancellations
  - **2.** Zeros of 1 + L(s) = 0 only in LHP

## **Critical Gain Computation**

- Recall feedback control system stable if
  - 1. No pole-zero cancellations
  - **2.** Zeros of 1 + L(s) = 0 only in LHP
- Critical gain,  $g_0$ , occurs when zeros of  $1 + g_0L(j\omega_0)$  on imaginary axis for some critical frequency  $\omega_0$ , i.e.

$$1 + g_0 L(j\omega_0) = 0 \tag{17}$$

## **Critical Gain Computation**

- · Recall feedback control system stable if
  - 1. No pole-zero cancellations
  - **2.** Zeros of 1 + L(s) = 0 only in LHP
- Critical gain,  $g_0$ , occurs when zeros of  $1 + g_0 L(j\omega_0)$  on imaginary axis for some critical frequency  $\omega_0$ , i.e.

$$1 + g_0 L(j\omega_0) = 0 \tag{17}$$

Rewriting:

$$L(j\omega_0) = -\frac{1}{q_0} \tag{18}$$

## **Critical Gain Computation (continued)**

• Polar form (i.e. gain and phase):

$$|L(j\omega_0)|e^{j\angle L(j\omega_0)} = -\frac{1}{g_0} \tag{19}$$

## **Critical Gain Computation (continued)**

• Polar form (i.e. gain and phase):

$$|L(j\omega_0)|e^{j\angle L(j\omega_0)} = -\frac{1}{q_0} \tag{19}$$

• Magnitude/gain and phase:

$$g_0 = \frac{1}{|L(j\omega_0)|} \tag{20}$$

$$\angle L(j\omega_0) = \pm 180^{\circ} \tag{21}$$

Identify gain margins by:

- Identify gain margins by:
  - **1.** Identify all  $\omega_{0,i}$  where  $\angle L(j\omega_{0,i}) = \pm 180^{\circ}$

- Identify gain margins by:
  - **1.** Identify all  $\omega_{0,i}$  where  $\angle L(j\omega_{0,i}) = \pm 180^{\circ}$
  - **2.** Calculate all "candidate"  $g_{0,i}$  using inverse of gain at  $\omega_{0,i}$ , i.e.

$$g_{0,i} = \frac{1}{|L(j\omega_{0,i})|} \tag{22}$$

- Identify gain margins by:
  - **1.** Identify all  $\omega_{0,i}$  where  $\angle L(j\omega_{0,i}) = \pm 180^{\circ}$
  - **2.** Calculate all "candidate"  $g_{0,i}$  using inverse of gain at  $\omega_{0,i}$ , i.e.

$$g_{0,i} = \frac{1}{|L(j\omega_{0,i})|} \tag{22}$$

- 3. Upper gain margin:  $\bar{g} = \min_i g_{0,i} > 1$
- **4.** Lower gain margin:  $\underline{g} = \max_{i} g_{0,i} < 1$

- Identify gain margins by:
  - **1.** Identify all  $\omega_{0,i}$  where  $\angle L(j\omega_{0,i}) = \pm 180^{\circ}$
  - **2.** Calculate all "candidate"  $g_{0,i}$  using inverse of gain at  $\omega_{0,i}$ , i.e.

$$g_{0,i} = \frac{1}{|L(j\omega_{0,i})|} \tag{22}$$

- 3. Upper gain margin:  $\bar{g} = \min_i g_{0,i} > 1$
- **4.** Lower gain margin:  $\underline{g} = \max_{i} g_{0,i} < 1$
- Feedback control system stable:

$$\underline{g} \le g \le \bar{g}$$
 (23)

Note: not all systems have upper and lower gain margins

# **Gain Margin Computation**

- Identify gain margins by:
  - **1.** Identify all  $\omega_{0,i}$  where  $\angle L(j\omega_{0,i}) = \pm 180^{\circ}$
  - **2.** Calculate all "candidate"  $g_{0,i}$  using inverse of gain at  $\omega_{0,i}$ , i.e.

$$g_{0,i} = \frac{1}{|L(j\omega_{0,i})|} \tag{22}$$


- **3.** Upper gain margin:  $\bar{g} = \min g_{0,i} > 1$
- **4.** Lower gain margin:  $g = \max_{i} g_{0,i} < 1$
- Feedback control system stable:

$$g \le g \le \bar{g}$$
 (23)

- Note: not all systems have upper and lower gain margins
- FDC: feedback control system typically sufficiently robust if  $\underline{g} \leq$  0.5 and  $\bar{g} \geq$  2 for gain margin
  - I.e.  $g \le -6$  dB and  $\bar{g} \ge 6$  dB


#### **Critical Phase Model**

• Consider phase perturbation to *G*(*s*)



#### **Critical Phase Model**


• Consider phase perturbation to *G*(*s*)



• Define perturbed open-loop transfer function as  $e^{-j\theta}L(s)$ 

#### **Critical Phase Model**

• Consider phase perturbation to *G*(*s*)



- Define perturbed open-loop transfer function as  $e^{-j\theta}L(s)$
- $\bullet$  Phase margin determined by assessing for what critical values of  $\theta$  feedback control system goes unstable

# **Critical Phase Computation**

- Recall feedback control system stable if
  - 1. No pole-zero cancellations
  - **2.** Zeros of 1 + L(s) = 0 only in LHP

# **Critical Phase Computation**

- Recall feedback control system stable if
  - 1. No pole-zero cancellations
  - **2.** Zeros of 1 + L(s) = 0 only in LHP
- Critical phase,  $\theta_0$ , occurs when zeros of  $1 + e^{-j\theta}L(j\omega_0)$  on imaginary axis for some critical frequency  $\omega_0$ , i.e.

$$1 + e^{-j\theta_0}L(j\omega_0) = 0 \tag{24}$$

### **Critical Phase Computation**

- · Recall feedback control system stable if
  - 1. No pole-zero cancellations
  - **2.** Zeros of 1 + L(s) = 0 only in LHP
- Critical phase,  $\theta_0$ , occurs when zeros of  $1 + e^{-j\theta}L(j\omega_0)$  on imaginary axis for some critical frequency  $\omega_0$ , i.e.

$$1 + e^{-j\theta_0}L(j\omega_0) = 0 \tag{24}$$

Rewriting:

$$L(j\omega_0) = -e^{j\theta_0} \tag{25}$$

• Polar form (i.e. gain and phase):

$$|L(j\omega_0)|e^{j\angle L(j\omega_0)} = -e^{j\theta_0}$$
(26)

• Polar form (i.e. gain and phase):

$$|L(j\omega_0)|e^{j\angle L(j\omega_0)} = -e^{j\theta_0} \tag{26}$$

Magnitude/gain and phase:

$$|L(j\omega_0)|=1 \tag{27}$$

$$\theta_0 = \pm 180^\circ + \angle L(j\omega_0) \tag{28}$$

• Polar form (i.e. gain and phase):

$$|L(j\omega_0)|e^{j\angle L(j\omega_0)} = -e^{j\theta_0} \tag{26}$$

Magnitude/gain and phase:

$$|L(j\omega_0)|=1 \tag{27}$$

$$\theta_0 = \pm 180^\circ + \angle L(j\omega_0) \tag{28}$$

•  $\theta_0$  typically represented as positive number

• Polar form (i.e. gain and phase):

$$|L(j\omega_0)|e^{j\angle L(j\omega_0)} = -e^{j\theta_0} \tag{26}$$

Magnitude/gain and phase:

$$|L(j\omega_0)|=1 \tag{27}$$

$$\theta_0 = \pm 180^\circ + \angle L(j\omega_0) \tag{28}$$

- $\theta_0$  typically represented as positive number
- ullet Phase margin referenced to either  $\pm 180$  and symmetric for positive and negative heta

Identify phase margin by:

- Identify phase margin by:
  - **1.** Identify  $\omega_{0,i}$  where  $|L(j\omega_{0,i})| = 1$

- Identify phase margin by:
  - **1.** Identify  $\omega_{0,i}$  where  $|L(j\omega_{0,i})| = 1$
  - **2.** Calculate "candidate"  $\theta_{0,i}$  using distance from 180°, i.e.

$$\theta_{0,i} = \pm 180^{\circ} + \angle L(j\omega_0) \tag{29}$$

- Identify phase margin by:
  - **1.** Identify  $\omega_{0,i}$  where  $|L(j\omega_{0,i})| = 1$
  - **2.** Calculate "candidate"  $\theta_{0,i}$  using distance from 180°, i.e.

$$\theta_{0,i} = \pm 180^{\circ} + \angle L(j\omega_0) \tag{29}$$

**3.** Phase margin,  $\bar{\theta} = \min_{i} |\theta_{0,i}|$ 

- Identify phase margin by:
  - **1.** Identify  $\omega_{0,i}$  where  $|L(j\omega_{0,i})| = 1$
  - **2.** Calculate "candidate"  $\theta_{0,i}$  using distance from 180°, i.e.

$$\theta_{0,i} = \pm 180^{\circ} + \angle L(j\omega_0) \tag{29}$$

- **3.** Phase margin,  $\bar{\theta} = \min_{i} |\theta_{0,i}|$
- Feedback control system stable:

$$-\bar{\theta} \le \theta \le \bar{\theta} \tag{30}$$

- Identify phase margin by:
  - **1.** Identify  $\omega_{0,i}$  where  $|L(j\omega_{0,i})| = 1$
  - **2.** Calculate "candidate"  $\theta_{0,i}$  using distance from 180°, i.e.


$$\theta_{0,i} = \pm 180^{\circ} + \angle L(j\omega_0) \tag{29}$$

- **3.** Phase margin,  $\bar{\theta} = \min_{i} |\theta_{0,i}|$
- Feedback control system stable:


$$-\bar{\theta} \le \theta \le \bar{\theta} \tag{30}$$

• FDC: feedback control system typically sufficiently robust if  $\bar{\theta} \geq$  45° for phase margin

### **Feedback Control System**




### **Feedback Control System**



- Synthesize K(s) to achieve design requirements:
  - 1 Stable with good stability margins

### **Feedback Control System**



- Synthesize K(s) to achieve design requirements:
  - 1 Stable with good stability margins
  - **2** Good tracking, i.e. transfer function from  $y_c \rightarrow e$  small
  - **3** Disturbance rejection, i.e. transfer function from  $w \rightarrow y$  small
  - **4** Sensor noise filtering, i.e. transfer function from  $v \rightarrow e$  small
  - **5** Control effort realistic, i.e. |u| not too large
- Performance requirements: 2-5

### **Loop-Shaping to Satisfy Requirements**

- **Loop-shaping** control design for synthesizing K(s) for SISO systems:
  - "Shape" SISO open-loop transfer function, L(s) = G(s)K(s), to have certain frequency response characteristics

# **Loop-Shaping to Satisfy Requirements**

- **Loop-shaping** control design for synthesizing K(s) for SISO systems:
  - "Shape" SISO open-loop transfer function, L(s) = G(s)K(s), to have certain frequency response characteristics
- Primary aspect of loop-shaping: K(s) has additive effect on magnitude subplot of Bode plot when considered in decibels:

$$20\log_{10}|L(j\omega)| = 20\log_{10}|G(j\omega)K(j\omega)| = 20\log_{10}|G(j\omega)| + 20\log_{10}|K(j\omega)|$$
(31)

# **Loop-Shaping to Satisfy Requirements**

- **Loop-shaping** control design for synthesizing K(s) for SISO systems:
  - "Shape" SISO open-loop transfer function, L(s) = G(s)K(s), to have certain frequency response characteristics
- Primary aspect of loop-shaping: K(s) has additive effect on magnitude subplot of Bode plot when considered in decibels:

$$20\log_{10}|L(j\omega)| = 20\log_{10}|G(j\omega)K(j\omega)| = 20\log_{10}|G(j\omega)| + 20\log_{10}|K(j\omega)|$$
(31)

- To form suitable L(s), use multiple **control stages** for different regions of Bode plot using this additive property for shaping L(s)
- Multiplying each stage together, i.e. using each stage *in series*: provides full controller transfer function K(s)

# L(s) for Stability Requirement

- If open-loop transfer function, L(s), satisfies following:
  - 1 No poles or zeros in RHP
  - 2 |L(0)| > 0
  - **3** Single gain crossover frequency  $\omega_c$
  - 4  $|L(j\omega)|_{\mathrm{dB}}/\mathrm{decade} \geq -30$  dB/decade for  $\frac{\omega_c}{\sqrt{10}} < \omega < \sqrt{10}\omega_c$
  - **5**  $|L|_{dB} \geq 6$  dB for  $\omega \leq \frac{\omega_c}{\sqrt{10}}$
  - **6**  $|L|_{dB} \leq -6$  dB for  $\omega \geq \sqrt{10}\omega_c$

Then, confidently claim feedback control system achieves stability requirements

• Recall S + T = 1: one cannot simultaneously satisfy all design requirements


- Recall S + T = 1: one cannot simultaneously satisfy all design requirements
- Key idea in frequency domain control design: output commands designed to be low frequency signals relative to any high frequency noise signals on actual output

- Recall S + T = 1: one cannot simultaneously satisfy all design requirements
- Key idea in frequency domain control design: output commands designed to be low frequency signals relative to any high frequency noise signals on actual output
- Requires feedback control system satisfies:
  - **1**  $|S(j\omega)|$  ≪ 1 at low  $\omega$
  - $2 |T(j\omega)| \ll 1$  at high  $\omega$

- Recall S + T = 1: one cannot simultaneously satisfy all design requirements
- Key idea in frequency domain control design: output commands designed to be low frequency signals relative to any high frequency noise signals on actual output
- Requires feedback control system satisfies:
  - $|S(j\omega)| \ll 1$  at low  $\omega$
  - $2 |T(j\omega)| \ll 1$  at high  $\omega$
- Translating 1 and 2 to open-loop transfer function,  $L(j\omega)$ , provides equivalent loop-shaping performance requirements:
  - 1  $|L(j\omega)| \gg 1$  at low  $\omega$
  - **2**  $|L(j\omega)| \ll 1$  at high  $\omega$
  - $3 \left| \frac{K(j\omega)}{1 + L(j\omega)} \right| \ll 1 \ \forall \ \omega$


### **Loop-Shaping Visualization**

• Analyzed visually using magnitude subplot of Bode plot of  $L(j\omega)$ 



### **Loop-Shaping Visualization**

• Analyzed visually using magnitude subplot of Bode plot of  $L(j\omega)$ 



- For control effort requirement: analyze Bode plot of  $K(j\omega)S(j\omega)$  in parallel with loop-shaping of L(s)
  - Typically design  $K(j\omega)$  not too large where  $G(j\omega)$  small
  - Similar to high frequency requirement for sensor noise filtering

 Loop-shaping uses multiple N control stages to shape different frequency regions of L(s)

- Loop-shaping uses multiple N control stages to shape different frequency regions of L(s)
- Design controllers in series form:

$$K(s) = K_1(s) \cdots K_N(s) \tag{32}$$

- Additive in Bode plot: primary analysis tool
- Each stage in series  $\rightarrow$  multiplying each together provides full controller, K(s)

- Loop-shaping uses multiple N control stages to shape different frequency regions of L(s)
- Design controllers in series form:

$$K(s) = K_1(s) \cdots K_N(s) \tag{32}$$

- Additive in Bode plot: primary analysis tool
- Each stage in series  $\rightarrow$  multiplying each together provides full controller, K(s)
- Four typical control stages:
  - Proportional
  - 2 Integral
  - 3 Lead
  - 4 Low-Pass Filter

- Loop-shaping uses multiple N control stages to shape different frequency regions of L(s)
- Design controllers in series form:

$$K(s) = K_1(s) \cdots K_N(s) \tag{32}$$

- Additive in Bode plot: primary analysis tool
- Each stage in series  $\rightarrow$  multiplying each together provides full controller, K(s)
- Four typical control stages:
  - 1 Proportional
  - 2 Integral
  - 3 Lead
  - 4 Low-Pass Filter
- Typically least number of stages, i.e., less complexity, preferred by control designers

### General SISO Loop-Shaping Design

 Consider following iterative procedure for loop-shaping design of K(s) until all design requirements satisfied

### General SISO Loop-Shaping Design

- Consider following iterative procedure for loop-shaping design of K(s) until all design requirements satisfied
  - 1 Use proportional gain control stage to set loop bandwidth,  $\omega_c$ 
    - May need to obtain requirements on  $\omega_c$  from  $t_s$

- Consider following iterative procedure for loop-shaping design of K(s) until all design requirements satisfied
  - 1 Use proportional gain control stage to set loop bandwidth,  $\omega_c$ 
    - May need to obtain requirements on  $\omega_c$  from  $t_s$
  - **2** Use lead control stage(s) to reduce  $|L(j\omega)|$  slope about  $\omega_c$  to >-30 dB/10 $\omega$  for stability and robustness

- Consider following iterative procedure for loop-shaping design of K(s) until all design requirements satisfied
  - 1 Use proportional gain control stage to set loop bandwidth,  $\omega_c$ 
    - May need to obtain requirements on  $\omega_c$  from  $t_s$
  - 2 Use lead control stage(s) to reduce  $|L(j\omega)|$  slope about  $\omega_c$  to >-30 dB/10 $\omega$  for stability and robustness
  - **3** Use integral control stage(s) to increase  $|L(j\omega)|$  at low  $\omega$ , i.e. good tracking
    - May need to obtain requirements on  $L(j\omega)$  from  $S(j\omega)$  or  $e_{ss}$

- Consider following iterative procedure for loop-shaping design of K(s) until all design requirements satisfied
  - 1 Use proportional gain control stage to set loop bandwidth,  $\omega_c$ 
    - May need to obtain requirements on  $\omega_c$  from  $t_s$
  - 2 Use lead control stage(s) to reduce  $|L(j\omega)|$  slope about  $\omega_c$  to >-30 dB/10 $\omega$  for stability and robustness
  - **3** Use integral control stage(s) to increase  $|L(j\omega)|$  at low  $\omega$ , i.e. good tracking
    - May need to obtain requirements on  $L(j\omega)$  from  $S(j\omega)$  or  $e_{ss}$
  - **4** Use low-pass filter stage(s) to decrease  $|L(j\omega)|$  at high  $\omega$ , i.e. good noise filtering
    - May need to obtain requirements on  $L(j\omega)$  from  $T(j\omega)$

- Consider following iterative procedure for loop-shaping design of K(s) until all design requirements satisfied
  - 1 Use proportional gain control stage to set loop bandwidth,  $\omega_c$ 
    - May need to obtain requirements on  $\omega_c$  from  $t_s$
  - 2 Use lead control stage(s) to reduce  $|L(j\omega)|$  slope about  $\omega_c$  to >-30 dB/10 $\omega$  for stability and robustness
  - **3** Use integral control stage(s) to increase  $|L(j\omega)|$  at low  $\omega$ , i.e. good tracking
    - May need to obtain requirements on  $L(j\omega)$  from  $S(j\omega)$  or  $e_{ss}$
  - **4** Use low-pass filter stage(s) to decrease  $|L(j\omega)|$  at high  $\omega$ , i.e. good noise filtering
    - May need to obtain requirements on  $L(j\omega)$  from  $T(j\omega)$
  - 5 Potentially iterate:
    - Integral and filter stages may slightly affect  $\omega_c$

 Most common classical control design method: proportional-integral-derivative (PID) control law defined in parallel form:

$$K_{PID}(s) = \frac{u(s)}{e(s)} = K_p + \frac{K_i}{s} + K_d s$$
 (33)

- $K_p$ : proportional gain
- K<sub>i</sub>: integral gain
- $K_d$ : derivative gain

PID Control

 Most common classical control design method: proportional-integral-derivative (PID) control law defined in parallel form:

$$K_{PID}(s) = \frac{u(s)}{e(s)} = K_p + \frac{K_i}{s} + K_d s$$
 (33)

- $K_p$ : proportional gain
- K<sub>i</sub>: integral gain
- $K_d$ : derivative gain
- If  $K_d = 0$ : proportional-integral (PI) controller

 Most common classical control design method: proportional-integral-derivative (PID) control law defined in parallel form:

$$K_{PID}(s) = \frac{u(s)}{e(s)} = K_p + \frac{K_i}{s} + K_d s$$
 (33)

- $K_p$ : proportional gain
- K<sub>i</sub>: integral gain
- $K_d$ : derivative gain
- If  $K_d = 0$ : proportional-integral (PI) controller
- If  $K_i = 0$ : proportional-derivative (PD) controller

 Most common classical control design method: proportional-integral-derivative (PID) control law defined in parallel form:

$$K_{PID}(s) = \frac{u(s)}{e(s)} = K_p + \frac{K_i}{s} + K_d s$$
 (33)

- $K_p$ : proportional gain
- K<sub>i</sub>: integral gain
- $K_d$ : derivative gain
- If  $K_d = 0$ : proportional-integral (PI) controller
- If  $K_i = 0$ : proportional-derivative (PD) controller
- If  $K_d = K_i = 0$ : simple proportional (P) controller

### **Alternative Forms of PID Controller**

For PID control design via loop-shaping: series form, a.k.a. interacting form, of PID controller

$$K_{PID}(s) = k \left(\frac{s + \omega_i}{s}\right) \left(\frac{1}{\omega_d}s + 1\right)$$
 (34)

- k: overall gain
- $\omega_i$ : integral frequency
- $\omega_d$ : derivative frequency

PID Control

- Noting derivative boost stage: derivative term increases asymptotic slope of open-loop transfer function, L(s)
  - Amplifies any high frequency sensor noise in  $y_m$  in classical feedback control system

- Noting derivative boost stage: derivative term increases asymptotic slope of open-loop transfer function, L(s)
- ullet Amplifies any high frequency sensor noise in  $y_m$  in classical feedback control system
- To overcome unfavorable outcome, often derivative term in PID control alternatively implemented using filtered derivative

- Noting derivative boost stage: derivative term increases asymptotic slope of open-loop transfer function, L(s)
  - Amplifies any high frequency sensor noise in  $y_m$  in classical feedback control system
- To overcome unfavorable outcome, often derivative term in PID control alternatively implemented using filtered derivative
- PID filtered parallel form:

$$K_{PID'}(s) = K_p + \frac{K_i}{s} + K_d \frac{\omega_{\infty}}{1 + \omega_{\infty} \frac{1}{s}} = K_p + \frac{K_i}{s} + K_d \frac{s}{\frac{1}{\omega_{\infty}} s + 1}$$
(35)

- Noting derivative boost stage: derivative term increases asymptotic slope of open-loop transfer function, L(s)
  - Amplifies any high frequency sensor noise in  $y_m$  in classical feedback control system
- To overcome unfavorable outcome, often derivative term in PID control alternatively implemented using filtered derivative
- PID filtered parallel form:

$$K_{PID'}(s) = K_p + \frac{K_i}{s} + K_d \frac{\omega_{\infty}}{1 + \omega_{\infty} \frac{1}{s}} = K_p + \frac{K_i}{s} + K_d \frac{s}{\frac{1}{\omega_{\infty}} s + 1}$$
(35)

PID filtered series form:

$$K_{PID'}(s) = k \left(\frac{s + \omega_i}{s}\right) \left(\frac{\beta^2 s + \omega_\infty}{s + \omega_\infty}\right)$$
 (36)

## PID Control via Loop-shaping Control Stages

• Equivalently, by substitutions  $\omega_{\infty} = \beta \omega_c$ :

$$K_{PID'}(s) = k\beta \left(\frac{s + \omega_i}{s}\right) \left(\frac{\beta s + \omega_c}{s + \beta \omega_c}\right)$$
 (37)

## PID Control via Loop-shaping Control Stages

• Equivalently, by substitutions  $\omega_{\infty} = \beta \omega_{c}$ :

$$K_{PID'}(s) = k\beta \left(\frac{s + \omega_i}{s}\right) \left(\frac{\beta s + \omega_c}{s + \beta \omega_c}\right)$$
 (37)

- Demonstrates filtered PID control has particular loop-shaping controller employing three control stages:
  - Proportional gain of  $k\beta$
  - Integral boost at  $\omega_i$
  - Lead stage at  $\beta$  and  $\omega_{c}=\frac{\omega_{\infty}}{\beta}$

## PID Control via Loop-shaping Control Stages

• Equivalently, by substitutions  $\omega_{\infty} = \beta \omega_{c}$ :

$$K_{PID'}(s) = k\beta \left(\frac{s + \omega_i}{s}\right) \left(\frac{\beta s + \omega_c}{s + \beta \omega_c}\right)$$
 (37)


- Demonstrates filtered PID control has particular loop-shaping controller employing three control stages:
  - Proportional gain of  $k\beta$
  - Integral boost at  $\omega_i$
  - Lead stage at  $\beta$  and  $\omega_{c} = \frac{\omega_{\infty}}{\beta}$
- Thus, stages allow loop-shaping design procedure to iterate on values to affect low frequency and crossover regions of the  $L(j\omega)$ 
  - Also implement as classical parallel PID control gains

## **PID Control with Filter Subsystem**

- Note: PID controller does not inherently use any low-pass filter stages
  - Many need to use low-pass filter stage in addition to PID controller


## **PID Control with Filter Subsystem**

- Note: PID controller does not inherently use any low-pass filter stages
  - · Many need to use low-pass filter stage in addition to PID controller
  - Often part of filter subsystem for y<sub>m</sub>



## **PID Control with Filter Subsystem**

- Note: PID controller does not inherently use any low-pass filter stages
  - Many need to use low-pass filter stage in addition to PID controller
  - Often part of filter subsystem for y<sub>m</sub>




 Digital system typically limits update rate, i.e. frequency, of y<sub>c</sub> upstream of control system

PID Control


 Another alternative: measure output derivative directly instead of computing derivative of tracking error signal

- Another alternative: measure output derivative directly instead of computing derivative of tracking error signal
- Derivative term in PID control alternatively implemented **rate feedback control**: derivative of output, i.e. "rate," fed back

- Another alternative: measure output derivative directly instead of computing derivative of tracking error signal
- Derivative term in PID control alternatively implemented rate feedback control: derivative of output, i.e. "rate," fed back
- PI control with rate feedback block diagram:




- Another alternative: measure output derivative directly instead of computing derivative of tracking error signal
- Derivative term in PID control alternatively implemented rate feedback control: derivative of output, i.e. "rate," fed back
- PI control with rate feedback block diagram:



Considered SIMO feedback control system: two separate outputs fed back to controller: error and output rate

- Another alternative: measure output derivative directly instead of computing derivative of tracking error signal
- Derivative term in PID control alternatively implemented rate feedback control: derivative of output, i.e. "rate," fed back
- PI control with rate feedback block diagram:



- Considered SIMO feedback control system: two separate outputs fed back to controller: error and output rate
- Also considered stability augmentation system (SAS) using rate, second closed-loop PI controller using output error

- SISO LTI "Classical" Feedback Control System
  - Negative feedback to cascaded controller, K, and plant, G
  - Characterized by four fundmental transfer functions
  - Open-loop transfer function: L = GK

- SISO LTI "Classical" Feedback Control System
  - Negative feedback to cascaded controller, K, and plant, G
  - Characterized by four fundmental transfer functions
  - Open-loop transfer function: L = GK
- SISO LTI System: Stability and Robustness
  - Numerator of 1 + L(s): SISO LTI feedback characteristic polynomial
  - Classical margins: gain or phase when 1 + L(s) zeros  $\rightarrow \mathsf{RHP}$

- SISO LTI "Classical" Feedback Control System
  - Negative feedback to cascaded controller, K, and plant, G
  - Characterized by four fundmental transfer functions
  - Open-loop transfer function: L = GK
- SISO LTI System: Stability and Robustness
  - Numerator of 1 + L(s): SISO LTI feedback characteristic polynomial
  - Classical margins: gain or phase when 1 + L(s) zeros  $\rightarrow RHP$
- Loop-Shaping Control Design
  - Output commands: low frequency signals & output noise signals: high frequency
  - Shape low frequency tracking, stability margins, high frequency suppression
  - Stages: Proportional Gain, Lead, Integral/Low Frequency Boost, Rolloff

- SISO LTI "Classical" Feedback Control System
  - Negative feedback to cascaded controller, K, and plant, G
  - Characterized by four fundmental transfer functions
  - Open-loop transfer function: L = GK
- SISO LTI System: Stability and Robustness
  - Numerator of 1 + L(s): SISO LTI feedback characteristic polynomial
  - Classical margins: gain or phase when 1 + L(s) zeros  $\rightarrow RHP$
- Loop-Shaping Control Design
  - Output commands: low frequency signals & output noise signals: high frequency
  - Shape low frequency tracking, stability margins, high frequency suppression
  - Stages: Proportional Gain, Lead, Integral/Low Frequency Boost, Rolloff
- PID Control Design
  - Uses 3-stages in parallel or series
  - Tuning using time- or frequency-domain techniques