Built-In Refrigerator Design Guide

Frameless (European) Cabinetry

---

1. Integration Levels

There are two distinct ways to integrate a refrigerator into frameless cabinetry. The choice determines enclosure depth, panel construction, hinge requirements, and final appearance.

Overlay (Panel-Ready)

Custom 3/4" panels attach to the appliance doors. The paneled doors **protrude 1–2" proud** of the adjacent cabinet doors. The compressor vents through a grille at the top of the unit. This is the most common configuration and the simplest to execute. The enclosure depth matches standard 24" frameless cabinets.

Brands defaulting to overlay: Sub-Zero Classic, KitchenAid, Fisher & Paykel (standard models), Viking.

Flush Inset (Integrated)

The refrigerator doors sit **on the same plane as the surrounding cabinet doors**. When closed, the refrigerator is virtually indistinguishable from adjacent tall cabinets. This requires deeper enclosures (typically 25–27"), recessed hinges engineered into the appliance, and tighter construction tolerances. This is the true European integrated look.

Brands engineered for flush inset: Sub-Zero Designer/Integrated series, Thermador Freedom, Gaggenau Vario, Bosch Benchmark, Miele, Liebherr.

Critical distinction: "Panel-ready" does not mean "flush." Unless the model is specifically labeled integrated or flush inset with recessed hinges, the paneled doors will protrude past the cabinet line.

---

2. Enclosure Anatomy

A frameless refrigerator enclosure consists of four elements. There is no face frame — the panel edges and cabinet door faces define the visual plane.

Side Panels

- **Material:** 3/4" (19mm) furniture-grade plywood. Preferred over MDF for moisture resistance and screw-holding strength. Never use particleboard.

- **Depth – Overlay installation:** 24" (610mm), matching standard frameless cabinet depth. The appliance doors and panels will protrude past the panel front edge.
- **Depth – Flush inset installation:** 25–27" depending on manufacturer. Sub-Zero specifies 26-3/16" for flush. Gaggenau specifies 24" cutout depth for frameless with a standard 3/4" panel (the appliance body is designed at 24" depth, and the panel brings the face flush with adjacent 24" cabinet doors). Always confirm with the specific model's installation guide.
- **Height:** Full height from finished floor to the underside of the overhead cabinet or ceiling soffit. Plan the opening for **74–78" minimum** to accommodate current and future models (refrigerator heights vary from 68–73").
- **Front edge treatment:** Apply matching edge banding or laminate to the front edge. In frameless construction, this exposed edge IS the finished face – there is no stile or face frame to cover it. The edge finish must match the cabinet door material exactly.
- **Panel depth beyond adjacent cabinets:** Best practice is to make tall side panels **slightly deeper than adjacent cabinets** (even 1/4–1/2") so the front edge of the panel sits flush with the face of adjacent cabinet doors. This creates a fully encapsulated appearance and ensures countertop ends butt cleanly against the panel with no visible cut edge.
- **Attachment:** Secure to adjacent cabinets with 1-1/4" cabinet screws through connection points. Anchor to wall studs through the rear using long screws. Use concealed connector bolts where panels meet adjacent cabinet sides.

Overhead Cabinet

- Spans the opening between the two side panels above the refrigerator.
- **Shallow depth (12–15") is strongly recommended** over full depth. Items stored in a full-depth overhead cabinet above a refrigerator are nearly impossible to retrieve.
- Construct from 3/4" plywood as a standard frameless cabinet box.
- **Finish the bottom of the overhead cabinet.** When the refrigerator door is open, the underside of this cabinet is fully visible. Raw plywood or exposed fasteners are unacceptable.
- Position the cabinet bottom to maintain the required ventilation clearance above the refrigerator (see Section 4).
- Filler strips may be needed between the overhead cabinet and the side panels to achieve the correct opening width.

Cleats / Nailers

- Horizontal 1x3 or 1x4 cleats bridge the two side panels at 2–3 points along the rear of the enclosure.
- Pre-drill with pocket holes for quick attachment during on-site assembly.
- Secure at least one cleat directly into wall studs for structural integrity.
- These prevent the side panels from racking and tie the enclosure together as a rigid unit.

- Position cleats so they do not interfere with the refrigerator sliding into place or obstruct rear ventilation airflow.

No Back Panel

Frameless refrigerator enclosures should NOT have a back panel. A back panel pushes the refrigerator forward and restricts critical rear ventilation. The wall behind the refrigerator serves as the back of the enclosure. Recess electrical outlets and water supply lines into the wall so they do not add depth behind the unit.

---

3. Critical Dimensions

Opening Width

Standard built-in refrigerator widths for frameless installations: **18", 24", 30", 36", 42", 48"** (column and full-size models).

- The cabinet opening should match the manufacturer's specified cutout width exactly.
- **Sub-Zero** specifies a minimum 3-1/2" (89mm) finished return on all sides. This is the visible finished surface of the side panel that frames the appliance – it must match the cabinetry.

- **Gaggenau** specifies the cutout is formed by two tall cupboards (left and right) with appropriate upper molding. For a single 30" column, the cutout width matches the appliance width.
- For general planning without a specific model selected, allow **37" minimum** for a 36" unit (1/2" clearance per side).

Opening Height

- **Minimum 74"**, ideally **78"** for future replacement flexibility.
- The gap between the top of the refrigerator and the overhead cabinet is covered by a grille panel.
- Sub-Zero offers configurations for 84" overall height (appliance + grille).

Opening Depth

Installation Type	Cutout Depth	Notes
Overlay (standard)	24" (610mm)	Doors/panels protrude past cabinet face
Flush inset – Gaggenau	24" (610mm)	Appliance body is 24"; 3/4" panel brings face flush with 24" cabinet doors

Flush inset – Sub-Zero	26-3/16"	Appliance recesses deeper so paneled door aligns with cabinet face
Flush inset – Thermador Freedom	Per model spec	Freedom hinge allows fully flush installation

Always account for panel thickness when calculating finished depth. The 3/4" panel is additive to the appliance door depth.

Panel Thickness

The universal standard is **3/4" (19mm).**

- **Sub-Zero:** All dimensions assume 3/4" panel. Minimum allowable is 5/8" (16mm). Thickness can increase provided it does not exceed the maximum panel weight listed in specs.
- **Thermador:** Recommends 3/4". Users have installed 7/8" shaker panels successfully, but this is outside documented specs.
- **Gaggenau (frameless):** 3/4" panel thickness. For frameless cabinetry, the panel is simply a slab or profiled door matching adjacent cabinet doors – no face frame emulation needed.
- **Bosch / U-Line:** 3/4" overlay panel, no additional kits required.

Panel weight is the real constraint. Check the manufacturer's maximum panel weight – heavy hardwoods or thick profiled panels can exceed hinge capacity and cause sagging over time.

Door Swing & Clearance

- Doors must open **minimum 90°**, ideally **110–120°** for full access to interior shelves, crispers, and drawers.
- Side panels must not block the door swing. For overlay installations, paneled doors are wider than the cabinet opening and swing past the panels.
- For flush inset, **Sub-Zero recommends 1/2" reveal** around the entire appliance for door clearance and air circulation. Some installers use 1/4", but 1/2" is the safe standard.
- **Countertop interference:** If the enclosure side panel is deeper than the adjacent countertop, verify the door handle clears the countertop edge when swinging open. An extended filler between the enclosure and adjacent base cabinet may be needed.

---

4. Ventilation

Inadequate ventilation is the number one cause of premature compressor failure in built-in installations. The enclosure cannot be a sealed box.

Airflow Path

Most built-in refrigerators pull cool air in from the bottom, route it up the back of the unit past the condenser and compressor, and exhaust warm air at the top. The enclosure must allow this convective loop to function unobstructed.

Some models (especially undercounter units) ventilate through a front-mounted grille at the toe kick. A few models have condenser coils integrated into the side walls – these require significantly more side clearance and are generally unsuitable for tight frameless enclosures.

Minimum Clearances

Location	Minimum Clearance	Notes
Top	1" (25mm) minimum	Many models need 6–10" for compressor housing + grille
Sides	1/2" (13mm) per side	More for models with side-wall condensers
Rear	1" (25mm) minimum	No back panel – leave open to wall
Bottom	Per manufacturer spec	Toe kick area often serves as air intake

European integrated appliances frequently require a minimum of **200 cm² (~31 sq in) of ventilation area** at both the top and bottom of the enclosure to sustain convective airflow.

Grille Panel Options

The space between the refrigerator top and the overhead cabinet is covered by:

- **Manufacturer's louvered grille:** Vented metal grille allowing airflow. Sub-Zero offers pro louvered grilles and dual-width grilles for side-by-side column installations.

- **Custom panel with ventilation:** A decorative panel matching cabinetry, mounted with small perimeter gaps (typically 1/4" around edges) to allow air exchange.
- **Solid decorative panel:** Some manufacturers state the dead airspace is sufficient with a solid panel. This is model-specific — do not assume. When in doubt, ventilate.

Always follow the specific model's installation guide. Ventilation requirements vary between models and non-compliance can void the warranty.

---

5. Frameless Enclosure Construction

Frameless cabinetry is the most natural pairing for integrated refrigerators because there is no face frame offset. The visual plane is defined entirely by the door/panel faces and the panel edges.

Design Principle

The appliance is **sandwiched between tall panels or tall cabinets.** You are not building a traditional appliance cabinet with a cutout — you are creating an opening between two vertical elements, spanned by a horizontal element (overhead cabinet) at the top.

Construction Sequence

1. Set adjacent cabinetry first. The base and wall cabinets flanking the refrigerator location must be installed, leveled, and secured before the enclosure panels go in.

2. Install the first side panel. Cut to the required depth and height. Verify plumb with a level. Secure to the adjacent cabinet with 1-1/4" screws and to the wall studs at the rear.

3. Position the second side panel. Use a horizontal spacer bar (cut to the exact opening width) clamped between the two panels at the top to set the correct distance. Verify plumb and parallel.

4. Install cleats. Bridge the two panels with 2–3 horizontal cleats at the rear. Pocket-screw into the panels and screw at least one into a wall stud.

5. Install the overhead cabinet. Set the cabinet box between the panels at the correct height (refrigerator height + ventilation clearance + grille panel height). Screw through the top of the cabinet into the cleats and through the sides into the panels.

6. Finish exposed surfaces. Apply edge banding to all visible panel edges. Finish the underside of the overhead cabinet. Install filler strips if needed.

7. Slide refrigerator into place. Connect water line and electrical. Verify door swing and clearance. Install grille panel.

8. Attach custom panels to appliance doors. Follow the manufacturer's panel mounting template exactly.

Assembly Tip

Assemble in place whenever possible. A fully assembled enclosure for a 36" refrigerator is enormous – often 37" wide × 27" deep × 84" tall. Wrestling this into a kitchen

and standing it up is extremely difficult. Building the enclosure in situ (panel by panel) is far more practical.

---

6. Panel Construction for Frameless Cabinets

The Advantage of Frameless

In frameless construction, the refrigerator panel is simply **a cabinet door scaled up to the appliance door dimensions.** There is no face frame to emulate, no additional thickness to build up. The panel profile, material, and finish should be identical to the adjacent cabinet doors.

Material

Match the cabinet door material exactly:

- **Thermofoil / melamine wrap:** Common on frameless European cabinets. The panel is a flat MDF core wrapped in the same film as the doors.
- **Lacquered MDF:** Spray-finished to match. Lighter weight than solid wood – favorable for hinge longevity.
- **Veneer on MDF or plywood:** Real wood appearance with dimensional stability.

- **Solid wood:** Most durable but heaviest. Verify against manufacturer panel weight limits.
- **Acrylic / high-gloss laminate:** Common on contemporary European kitchens (Pronorm, Nobilia, Leicht, etc.). Panel is typically 3/4" MDF with laminate or acrylic face applied.

Door Profile

Profile	Typical Thickness	Weight	Notes
Slab (flat)	3/4" (19mm)	Lightest	Simplest to fabricate. Most common in frameless kitchens.
Shaker	7/8"–1"	Medium	Applied rails and stiles over 3/4" base. Verify against max thickness spec.
J-pull / handleless	3/4" (19mm)	Light	Integrated edge pull routed into the panel. Requires co-ordination with appliance mounting brackets.
True handleless (push-to-open)	3/4" (19mm)	Light	Only on specific integrated models with push-to-open mechanisms (Thermador, Bosch).

Hardware

- **Handles:** Use appliance-length pulls (12"–18") matching the cabinetry hardware. In frameless kitchens with rail/channel handle systems (like Pronorm's grip rail), coordinate the handle profile with the panel dimensions.
- **Handleless kitchens:** If the kitchen uses a J-pull or integrated channel profile, verify whether the appliance can accept a panel routed with the same profile. Some integrated models (Thermador Freedom, Bosch Benchmark) offer handle-free push-to-open operation that aligns with this aesthetic.

Attachment

Most panel-ready appliances use one of two mounting systems:

- **Bracket/clip system:** Metal brackets pre-mounted on the appliance door. The panel clips onto the brackets. Common on Sub-Zero, Thermador.
- **Screw-through mounting:** Pre-drilled holes in the appliance door. Screws pass through from behind the door into the panel. Common on Bosch, Gaggenau, Miele.

Follow the manufacturer's panel template precisely — hole locations, edge offsets, and weight distribution are engineered for the specific hinge system.

---

7. Column Refrigeration

Modular column refrigeration is the dominant trend in European kitchen design and the most natural fit for frameless cabinetry.

Concept

Separate refrigerator and freezer columns (18", 24", 30", or 36" wide) are installed independently – side by side or in entirely different locations within the kitchen. Each column has a single door with a single panel.

Advantages in Frameless Design

- **Seamless tall cabinet line:** Refrigerator and freezer columns integrate into a run of tall cabinets (pantry, oven housing, storage) as visually identical elements. The kitchen reads as a wall of cabinetry rather than cabinetry interrupted by an appliance.
- **Simpler paneling:** One door per column = one panel per column. No multi-door alignment challenges.
- **Layout flexibility:** Place the refrigerator column near the cooking zone for workflow efficiency and the freezer column elsewhere. They don't need to be adjacent.
- **Width options:** 18" and 24" columns fit into narrow spaces. Pair a 30" refrigerator column with an 18" freezer column for a compact but full-capacity solution.

Side-by-Side Column Installation

When placing two columns adjacent to each other:

- A **dual installation kit** may be required (Sub-Zero and Gaggenau include or offer these).
- **Hinge placement:** Hinges go on the outside edges. Standard configuration: refrigerator column opens to the left, freezer column opens to the right (or vice versa).
- Verify that both doors can open simultaneously to at least 90° without interference.
- A single wide grille panel may span both columns at the top, or each column can have its own grille.
- Two separate cutouts with clearance between columns are an alternative to a single combined cutout – Gaggenau documents both approaches.

Column Brands for Frameless Kitchens

Brand	Column Widths Available	Flush Inset Capable	Notes
Sub-Zero (Designer)	18", 24", 30", 36"	Yes	Industry benchmark. 24" body depth.
Thermador Freedom	18", 24", 30"	Yes	Freedom hinge for fully flush install. Push-to-open option.

Gaggenau (Vario 400)	18", 24", 30"	Yes	German engineering. Detailed frameless planning guides.
Bosch Benchmark	24", 30"	Yes	Fully flush installation. More accessible price point.
Miele	24", 30"	Yes	MasterCool series. European flush integration.
Liebherr	24", 30"	Yes	Austrian/German. Strong European spec heritage.
Fisher & Paykel	24", 30", 36"	Select models	ActiveSmart technology.

---

8. Common Mistakes

1. **Building the enclosure too tight around one specific model.** Cabinetry outlasts 2–3 refrigerators over its lifetime. Refrigerator dimensions are not standardized across manufacturers. Build the opening to accommodate a reasonable range of models.
2. **Insufficient ventilation.** A sealed or nearly-sealed enclosure will overheat the compressor, spike energy consumption, and kill the appliance within 2–3 years. Always leave rear and top airflow paths open.

3. **Protruding utilities.** An electrical outlet or water line that sticks out from the wall even 1/2" can prevent the refrigerator from seating fully. Recess all utilities into the wall or route through an adjacent cabinet.
4. **Assuming panel-ready = flush.** Standard overlay models protrude 1–2" past the cabinet line. Only models specifically labeled "integrated" or "flush inset" with recessed hinge systems will sit flush.
5. **Exceeding panel weight limits.** Heavy solid-wood or profiled panels can exceed hinge capacity, causing door sag and alignment drift over time. Always check the spec sheet.
6. **Unfinished visible surfaces.** The front edges of side panels, the underside of the overhead cabinet, and the finished returns around the opening are all visible during normal use. Every exposed surface must be finished to match.
7. **Installing a freestanding refrigerator in a built-in enclosure.** Freestanding models have outward-swinging hinge arms. Recessed into cabinetry, the doors will collide with the side panels and cannot open properly. Only use appliances designed for built-in installation.
8. **Ignoring the installation guide.** Every model has specific cutout dimensions, panel templates, weight limits, and ventilation requirements. These vary between models from the same manufacturer. Always design from the spec sheet.

---

9. Design Checklist

Before finalizing a built-in refrigerator design in frameless cabinetry:

- [ ] Appliance model selected; installation guide and panel template obtained
- [ ] Installation type confirmed: overlay or flush inset
- [ ] Cutout width matches manufacturer specification
- [ ] Cutout height allows 74–78" minimum for future flexibility
- [ ] Cutout depth correct for installation type (24" overlay / 25–27" flush inset per model)
- [ ] Side panels are slightly deeper than adjacent cabinets (panel front edge flush with door faces)
- [ ] Ventilation clearances meet or exceed requirements (top, sides, rear)
- [ ] No back panel on enclosure
- [ ] Electrical outlet recessed into wall
- [ ] Water supply line routed and recessed (for ice maker / dispenser models)
- [ ] Panel thickness within manufacturer range (standard 3/4" / 19mm)
- [ ] Panel weight within hinge capacity
- [ ] Panel material and profile match adjacent cabinet doors exactly
- [ ] Door swing verified — minimum 90° opening without obstruction
- [ ] Handle / hardware specified and compatible with panel mounting
- [ ] Countertop edge does not interfere with door swing
- [ ] All visible panel edges finished (edge banding or laminate)
- [ ] Underside of overhead cabinet finished

- [ ] Grille panel specified (louvered, custom vented, or solid per manufacturer)
- [ ] Overhead cabinet depth decided (shallow recommended)
- [ ] Anti-tip bracket location confirmed per manufacturer spec
- [ ] For column pairs: dual installation kit ordered, hinge orientation confirmed, simultaneous door opening verified

---

Reference guide for kitchen designers, dealers, and cabinet makers working with built-in refrigeration in frameless (European) cabinetry systems. Always defer to the specific appliance manufacturer's installation documentation for exact dimensions, clearances, and panel specifications.