```
int redpin = 11; // select the input pin for the potentiometer
int bluepin =10;
                   // select the pin for the LED
int yellowpin =9;
int val;
void setup() {
 pinMode(redpin, OUTPUT);
 pinMode(bluepin, OUTPUT);
 pinMode(yellowpin, OUTPUT);
 Serial.begin(9600);
}
void loop()
{
for(val=255; val>0; val--)
 {
 analogWrite(11, val);
 analogWrite(10, 255-val);
 analogWrite(9, 128-val);
 delay(1);
 }
for(val=0; val<255; val++)
 {
 analogWrite(11, val);
 analogWrite(10, 255-val);
 analogWrite(9, 128-val);
 delay(1);
 }
Serial.println(val, DEC);
```

}

This article was published on Monday 09 January, 2012.