UART interface protocol between RPi and main uP

```
Pins use 3.3V logic levels
115200 baudrate, parity – none, 8 bits, 1 stop bit
```

Commands:

- -Player+ = start mp3/flac player
 - -GO+ = OK
 - -STOP+ = pause played song in player mode
 - -UP+ = up in menu movement
 - -DOWN+ = down in menu movement
 - -BACK+ = left/back-10 sec. in menu/song movement
 - **-NEXT+** = right/forward+10 sec. in menu/song movement
- -iRadio+ = starts internet radio
 - -GO+ = OK
 - **-UP+** = up in menu movement
 - -DOWN+ = down in menu movement
- -DAB+ = starts digital radio
 - -GO+ = OK
 - -UP+ = up in menu movement
 - -DOWN+ = down in menu movement
- -RDS+ = starts displaying radio station names indicated by command
 - -FM_01+, -FM_02+, -FM_03+, ... commands

Reception and decoding of RDS data is not implemented

-SHUTDOWN+ = powers down RPi

Returns:

On **-Player+** command:

- When browsing folders display
 - Selected folder number followed by
 - Number of subfolders in current folder followed by
 - Folder name using capital letters
- 24 characters to display followed by
 - Letter ";P"
 - New line and carriage return characters.
- When browsing files display
 - Selected file number followed by
 - Number of files in current folder followed by
 - o File name
- 24 characters to display followed by
 - Letter ";P"
 - New line and carriage return characters.
- When listening display
 - File name or artist/song names followed by
 - Number of remaining seconds of played file
- 24 characters to display followed by
 - Letter ";P"
 - New line and carriage return characters.

On -iRadio+ command:

- When browsing display
 - o Selected radio station number followed by
 - o Number of all radio stations in the file in iRadio folder followed by
 - o iRadio station name
- 24 characters to display followed by
 - When online by letter ";O"
 - When offline by letter ";F"
 - New line and carriage return characters.
- When **listening** display
 - o Radio station or artist/song names provided by iRadio station
- 24 characters to display followed by
 - When online by letter ";O"
 - When offline by letter ";F"
 - New line and carriage return characters.

On-DAB+ command:

- When **browsing** display
 - Selected radio station number followed by
 - o Number of all radio stations in the file in DAB folder followed by
 - o DAB station name
- 24 characters to display followed by
 - Letter ";D"
 - New line and carriage return characters.
- When **listening** display
 - o Radio station or artist/song names provided by DAB station
- 24 characters to display followed by
 - Letter ";D"
 - New line and carriage return characters.

On -RDS+ command:

- Radio station name read from RDS folder
- 24 characters to display followed by
 - Letter ";N"
 - New line and carriage return characters.
- Decode radio station RDS message
 - Reception and decoding of RDS data is not implemented
- 24 characters to display followed by
 - o Letter ";R"
 - New line and carriage return characters.

On -SHUTDOWN+ command:

- Message about power down state
- 24 characters to display followed by
 - Letter ";M"
 - New line and carriage return characters.

Once shutdown is started monitor state of RPi GPIO27. When Low RPi is off (needs to be checked).