

OMalley's Cat Flap Opener — Build Guide

A standalone gadget that lifts the cat flap when OMalley hops onto his shelf, on either side, then gently lowers it after he's gone.


Version 1 · 2026-09-28 · Project repo: <https://github.com/beveradb/cat-flap-opener>

How to use this guide. Read it end to end once before buying anything. Each build step says what you'll need, what to do and how to check it worked, in that order. Printed, it works as a workbench checklist: tick the ☐ boxes as you go.

Contents

1. [What you're building](#)
2. [How it behaves](#)
3. [Safety design](#)
4. [Shopping list](#)
5. [Tools and things you already own](#)
6. [Your window: measurements](#)
7. [Build steps](#), 12 stages from bench prototype to OMalley's first trip
8. [Troubleshooting](#)
9. [Maintenance](#)
10. [Appendices](#): pin map, settings, costs

1. What you're building




The whole system is four parts on the window plus one USB cable:

#	Part	Where	What it does
①	Controller box (80×50×26 mm, black)	Inside, on the wooden frame	The brain. A QT Py ESP32-S3 microcontroller and a ULN2003 motor driver. It reads both sensors and decides when to open.
②	Stepper motor + pulley	Inside, on the frame above the flap	Winds a cord in to lift the flap and lets it out to lower it. It moves to an exact position every time.
③	Inside distance sensor (VL53L1X)	Inside, on the frame <i>beside</i> the flap	A tiny laser rangefinder aimed at the inside shelf. "Something closer than the empty shelf" means "cat".
⑤	Outside distance sensor	Catio side, in a small sealed box	Same sensor, aimed at the catio shelf, so he gets help coming back in too.
⑦	Braided cord	Pulley → bottom edge of the flap	Hangs slack when the flap is closed, so the flap still swings freely by hand.
⑧	USB-C cable	Frame → down the wall → any USB plug	The only wire you'll see. Everything runs on 5 V.

Why no camera? We only need to know whether something is on the shelf, not *what* it is. If a hand or a bag triggers it, the flap just opens, which does no harm. A distance sensor has no model to train, works in the dark and doesn't mind the lighting. It's also about 1 cm square. Cameras for watching him are planned as a separate, optional later project (see `docs/future-cameras.md`).

Why a stepper motor and cord? A stepper counts its own steps, so "open" is always exactly the same position. There's nothing to time or tune, and it can't over-wind. The cord only *pulls*, and gravity does the closing. If the power fails with the flap closed, you're left with a normal cat flap.

2. How it behaves



In plain English:

1. **Waiting.** It checks both shelves 10 times a second.
2. **He hops up.** If either sensor sees something for **0.3 s in a row**, the flap starts opening. Rain drops and a hand swiping past are too brief to count.
3. **Opening** takes about **6–7 s**. There's a gap to sniff through almost at once, and he can take his time.
4. **Holding.** It stays open while he's on either shelf, **plus 20 seconds** after both shelves are clear. He's between the two sensors while he's in the tunnel, and he's sometimes slow, so the 20 s is deliberately generous.
5. **Closing.** The cord is let out slowly (about 6 s) and the flap lowers under its own weight. **If either sensor sees him again while it's closing, it reverses and reopens straight away.**
6. **Stuck-open protection.** If it has been open for **2 minutes straight** (a bag on the shelf, or O'Malley napping there), it closes. It then ignores that sensor until it reads "empty" again.
7. **Cooldown.** After closing, it waits 3 s before it can reopen, so it can't flap about.

All of these numbers are settings in one file and easy to change (see [Appendix B](#)).

The button on the box:

Press	Does
Short press	Runs one open → hold → close cycle (test/demo)
Hold 3 s, with both shelves empty	Learns the empty-shelf distances (calibration)

The status light (the QT Py's built-in colour LED): dim green means idle, blue means open or moving, red flashes mean a sensor problem.

3. Safety design

Nothing on the window can hurt OMalley. The design goals and how each one is met:

- **Only 5 V anywhere near him.** It's USB power, with no mains wiring and no big batteries.
- **A deliberately weak motor.** The 28BYJ-48 can lift a flap weighing a few tens of grams through its gearbox, but it can't pinch or trap a paw with any real force. If something resists, it simply stalls.
- **Gravity closes the flap**, just as it does when he pushes through today. The motor only controls how *slowly* it comes down.
- **A 20 s grace period** after both shelves are clear, and **it reopens if he reappears while it's closing.**
- **Braided nylon cord, not fishing line.** Loose monofilament is a real hazard to cats (chewing, swallowing, tangling). This cord is short, thick enough to see and anchored at both ends. It's taut when the flap is open and only slightly slack when closed.
- **All electronics are boxed**, and cables are clipped flat to the frame and wall.

What happens if something goes wrong:

Failure	Result
Power cut while closed	A normal cat flap
Power cut while open	The gearbox probably holds it open. The catio is enclosed, so that's acceptable; unplug and replug to recover.
A sensor stops responding	That sensor counts as "clear" and the light flashes red. The other side keeps working.
Something sits on a shelf	Closes after 2 min and ignores that shelf until it's clear
He swats the cord	Nothing happens. The motor doesn't react to the cord being pulled, and the cord is anchored at both ends.

4. Shopping list

Two orders. **Nothing has been bought yet.** Every item name or ASIN below links to its product page, so you can rebuild the carts in a future session. As of 2026-09-28 the carts were still filled in the Playwright Chrome profile. Before buying, you removed the VHB tape and one other Amazon item you already own, so check the cart against these lists when you come back.

Order A: Adafruit (core electronics), \$77.25 + shipping

	Item	Qty	Price	Why
	Adafruit QT Py ESP32-S3 (8 MB flash, no PSRAM), PID 5426	2	\$25.00	The brain. One is for bench testing and stays spare; the other goes in the final box. Thumb-sized, with a plug-in sensor socket.
	VL53L1X time-of-flight distance sensor , STEMMA QT, PID 3967	3	\$44.85	The "is he on the shelf?" sensors: one inside, one outside and one spare (the outdoor one is the most likely to die).
	STEMMA QT cable, 400 mm (PID 5385) and 200 mm (PID 4401)	2 + 2	\$5.50	Plug-in, solder-free cables from the QT Py to the inside sensor. Two lengths, so you can pick whichever suits the mounting spot.
	STEMMA QT → male header cable, 150 mm , PID 4209	2	\$1.90	Plugs into the outside sensor. Its other end is spliced onto the long 4-core cable. Also handy for breadboarding.

Order B: Amazon, about \$125 or less

Build parts:

	Item	ASIN	Price	Why
	ELEGOO 5x 28BYJ-48 stepper + ULN2003 driver	B01CP18J4A	\$14.99	The motor and its driver board. You get five, so there are plenty of spares.
	GT2 pulley, 60T, 5 mm bore, 2-pack	B0FNDDCRM1	\$9.19	The main cord spool. Your window needs about 15 cm of cord wound in, and the big 60-tooth pulley does that in about 1½ turns (6–7 s).
	GT2 pulleys, 20T + 40T, 5 mm bore (plus belts you won't need)	B09JWKLJW9	\$11.89	Fallback spools. They're slower but pull harder, in case the 60-tooth struggles.
	1 mm black braided nylon cord , 100 yd	B0CNPST7D9	\$5.79	The pull cord. It's strong and visible, and nothing like fishing line.
	Zulkit project boxes 80x50x26 mm , 5-pack	B07Q14K8YT	\$7.29	The controller box, with spares for mistakes.
	IP65 box 68x58x33 mm, clear lid (includes 2 cable glands)	B0CT5H9KPC	\$4.99	Weatherproof housing for the outside sensor
	22 AWG 4-conductor cable , 25 ft	B0CFJXMDT3	\$12.99	Connects the outside sensor to the controller (about 1 m used)

Electronics starter kit (for this build and future ones):

	Item	ASIN	Price	Why
	ELEGOO Electronics Fun Kit: breadboard, buttons, LEDs, resistors, header pins...	B01ERP6WL4	\$9.99	Breadboard for the bench prototype, plus the push button for the box
	ELEGOO 120 Dupont jumper wires (M-M, M-F, F-F)	B01EV70C78	\$6.98	Breadboard wiring
	Fermerry 22 AWG stranded wire , 6 colours × 10 ft	B089CQHRDT	\$12.79	Neat wires inside the final box
	Ginsco heat-shrink tubing kit	B01MFA3OFA	\$7.99	Insulates the splices (shrink with the side of the soldering iron or a lighter)
	VCELINK automatic wire stripper	B08G48R47N	\$9.99	Clean strips on 22 AWG wire
	NEIKO helping hands with magnifier	B000P42O3C	\$9.99	Holds wires while you solder splices

Total: about \$200 + Adafruit shipping. About \$144 of that is the build itself; the rest is the reusable starter kit.

5. Tools and things you already own

Found in your Amazon order history. **None of this is being bought again.**

Already have	Used for
MEAKEST 60 W soldering iron kit (solder, flux, pump, tweezers, stand)	All soldering
HTM-201 silicone repair mat, Weller brass tip cleaner	A safe surface to solder on
iFixit Pro Tech Toolkit	Small screwdrivers (grub screw on the pulley, box screws)
AstroAI multimeter	Checking the 5 V supply and continuity of the long cable
Adoric digital caliper	Taking the window measurements precisely
Drill + ENERTWIST / DEWALT bit sets	Box holes, the acrylic cable hole and a tiny hole in the flap
Jewelry pliers set (with wire cutters)	Snipping wires and header pins
Loctite super glue gel, Gorilla clear adhesive, hot glue gun	Securing knots and the button, sealing the cable hole
Bates nail-in cable clips (white), gaffer tape	Routing the USB cable down the wall
VELCRO heavy-duty strips, hook-and-loop tape, other mounting tapes	Mounting the sensors and boxes (replaces the VHB tape that was in the cart). Velcro also makes parts easy to remove.
Sabrent 10-port USB charger / Apple 40 W / spare USB plugs	5 V power (any 1 A+ USB port is enough)
Anker USB-C to USB-C cables, 6 ft	Power cable (measure the run first; see §6)
CeSunlight clamp lamp	Light for the workbench

You may also need a couple of small wood screws (#4–#6, ½") to fix the motor's mounting tabs to the frame. Heavy-duty Velcro works if you'd rather not drill.

6. Your window: measurements

You took these on 2026-09-28. Photos are in `docs/guide/photos/` .




Inside. The DIY insert sits under the raised lower sash. The flap is right of centre, above the big white shelf. There's a power outlet just right of the window.



Catio side. The weathered shelf directly outside the flap, under the catio roof beams.



Cord path, flap closed: 28 cm from the sash rail to the flap's bottom edge



Cord path, flap fully open: 13 cm



Open flap sticks out 4 cm past the housing



Open flap sits ~11 cm below the sash rail


Measurement	Value	What it means for the build
L: flap hinge → bottom edge	13 cm	A short, light flap, so little lifting force is needed
Cord path from mount point, closed → open	28 cm → 13 cm	About 15 cm of cord to wind in (plus about 2 cm resting slack). That's more than I'd guessed, which is why the 60-tooth pulley is now the main spool.
h: mount point above the hinge	~15 cm (28 – 13)	The motor goes on the face of the lower sash's bottom rail (the painted wood above the insert)
Open flap below the rail	~11 cm	Plenty of room: the open flap never gets near the motor
Open flap beyond the housing	4 cm	The inside sensor must sit well to the side of this swing zone
USB power	Outlet right beside the window	A ~1 m cable run, so your existing 6 ft USB-C cable is plenty

How much force? With your geometry the cord pulls almost straight up on the flap tip when it's nearly open. That gives it good leverage, so the worst case is only about 40 g of pull. The 60-tooth pulley still has about 2× headroom at full speed, and the smaller pulleys have more.

Still to check on the day (Step 9):


- ☐ **Cord clearance.** The cord must hang **at least 3 cm in front of the SureFlap housing's front face**, so it never rubs on the housing's top lip as it winds. If the sash rail's face is roughly level with the housing front, put the motor on a small wood spacer block (a 1×2 offcut) to bring it forward.
- ☐ **The sash.** The motor is on the lower sash, so **unhook the cord before ever raising or lowering that sash.**
- ☐ **The paint** on the rail is peeling in places, so use **screws for the motor** (adhesives don't hold on flaking paint). Heavy-duty Velcro is fine for the light sensor and box if you scrape to sound paint first.

How the cord opens the flap (side view — room on the left, catio on the right)




① Closed (resting)

Cord hangs with ~2 cm slack.
Flap swings freely both ways,
exactly like today.



② Open (motor winds cord)

Bottom edge lifts up and into the room;
he walks underneath — in or out.
Gravity closes it when cord is let out.



③ He pushes it himself

Pushing OUT makes the path
slightly longer — the resting slack
must cover this (check in Step 10).

Measure before install: h = pulley height above the flap hinge, L = hinge to flap bottom edge, d = how far the pulley sits into the room from the flap.

d must be at least ~3 cm so the pull starts the flap swinging *into the room*. Add a wooden spacer block behind the motor if needed.

Your window ($L = 13$ cm, $h \approx 15$ cm): cord path 28 cm closed $\rightarrow$ 13 cm open, so ≈ 15 cm to wind in $\rightarrow$ about $1\frac{1}{2}$ turns of the 60-tooth pulley $\rightarrow$ roughly 6–7 s to fully open.

7. Build steps

The plan. Get everything working on the desk first (Steps 1–3). Then build the mechanical parts (Steps 4–7), assemble the final box (Step 8), mount it (Steps 9–10), tune it (Step 11) and introduce OMalley (Step 12).


About the firmware: I'll write it and add it to the repo under `firmware/` while the parts ship. It will have unit tests for the behaviour rules and a serial console for testing. You'll only need to install one thing (the PlatformIO extension in VS Code) and click "Upload"; Step 3 walks through it.

Step 1: Unbox and check (15 min)

- ☐ Check each Adafruit and Amazon item against the §4 lists.
- ☐ Pick one QT Py as the **bench board** (write "B" on it with a marker). The other is the **final board**, and it stays in its bag for now.
- ☐ Plug the bench QT Py into your Mac with a USB-C cable. Its LED should light up; that proves the board and cable work.

Step 2: Bench prototype on the breadboard (45 min)

Wiring — everything connects to the QT Py ESP32-S3



Driver inputs: A0→IN1, A1→IN2, A2→IN3, A3→IN4 (any wire colours — these are just for clarity). Status light = the QT Py's built-in NeoPixel (no wiring).
Two I²C buses: inside sensor on the STEMMA QT port (Wire1), outside sensor on SDA/SCL pads (Wire) — so both can keep the same default address.

This is the wiring for **both** the bench prototype and the final box. On the bench everything plugs together with jumpers; later it's soldered.

- ☐ **Solder headers onto the bench QT Py.** Use the header strips supplied with the board (or snap two 7-pin lengths off the ELEGOO kit's strip). Push the long ends into the breadboard, sit the QT Py on top, and solder all 14 pins. The breadboard holds them straight.
- ☐ Put the QT Py across the breadboard's centre channel.
- ☐ **Motor driver:** use 4 female-to-male jumpers from the QT Py pins **A0, A1, A2, A3** to the ULN2003's **IN1, IN2, IN3, IN4**, in that order.
- ☐ **Driver power:** a jumper from QT Py **5V** to the ULN2003 **+**, and another from QT Py **GND** to the ULN2003 **-**.
- ☐ **Motor:** plug the 28BYJ-48's white 5-pin plug into the ULN2003 (it only fits one way).
- ☐ **Inside sensor:** plug a STEMMA QT cable from the QT Py's STEMMA socket (on its underside, at the end opposite the USB port) into either socket on a VL53L1X. No soldering needed.
- ☐ **Outside sensor (bench version):** plug a STEMMA QT → male-header cable into a second VL53L1X and push its four pins into the breadboard:

- **red** → QT Py **3V**
- **black** → **GND**
- **blue** → **SDA**
- **yellow** → **SCL**

☐ **Button:** put a tactile button from the ELEGOO kit on the breadboard. Wire one leg to QT Py **TX** and the diagonally opposite leg to **GND**.

☐ Peel the clear protective film off both sensors' faces (if there is one; it's a small tab).

Check: nothing gets warm when you plug in USB. The ULN2003's four red LEDs stay dark or blink only once the firmware is running.

Step 3: Flash firmware and bench test (30 min)

- ☐ Install **VS Code** and the **PlatformIO IDE** extension.
- ☐ `git clone https://github.com/beveradb/cat-flap-opener` and open the `firmware/` folder in VS Code.
- ☐ Plug in the bench QT Py and click **Upload** (→) in the PlatformIO toolbar. If it won't connect, hold the board's **BOOT** button, tap **RST**, release BOOT, then upload again.
- ☐ Open the **Serial Monitor**. You should see both distances printing about 10 times a second, e.g.
`in=1234mm out=987mm state=CLOSED .`

Bench test checklist. Point both sensors at the ceiling and hold the "hold 3 s" calibration with your hands clear. Then:

☐	Do this	Expect
☐	Wave a hand quickly past a sensor	Nothing happens (it's shorter than 0.3 s)
☐	Hold a hand ~20 cm above the inside sensor	The motor turns (the "open" direction) and the LED turns blue
☐	Take your hand away and start a timer	The motor reverses after about 20 s
☐	Put your hand back while it's reversing	It reverses back to open straight away
☐	Leave a book over one sensor	It opens, then closes after 2 min . Remove the book, wait, put it back: it opens again.
☐	Repeat with the outside sensor	Same behaviour
☐	Short-press the button	One full open → hold → close cycle
☐	Unplug the outside sensor mid-run	The LED flashes red and the inside sensor still works
☐	Touch the motor after idling a few minutes	Cold (coils are switched off when closed)

Step 4: Pulley and cord (15 min)

- ☐ Slide the **60-tooth pulley** onto the motor shaft, flange side outward, as close to the motor body as it will go without rubbing.
- ☐ Turn the shaft until one of the pulley's grub screws faces a **flat** on the shaft, then tighten it firmly with an iFixit hex bit. Tighten the second grub screw too.
- ☐ Cut about **60 cm of cord**. Tie one end around the pulley hub, between the flanges, with a **clove hitch** pulled tight. Put a drop of super glue gel on the knot.
- ☐ Wind 2 turns on by hand, neatly, between the flanges. That leaves spare cord on the spool in case you need to re-tie later.
- ☐ Seal the other end of the cord with a quick pass of a lighter flame so it can't fray.

Check: pull the cord firmly. The pulley shouldn't slip on the shaft, and the knot shouldn't move.

Step 5: Prepare the flap (15 min)


- ☐ If the flap will lift out (SureFlap flaps usually unclip at the hinge pins), take it out. Otherwise, hold a block of wood behind it while you drill.

- ☐ Mark a point **5 mm up from the bottom edge, about 1 cm to one side of the small clear clip** at the centre of the SureFlap's bottom edge. Keep clear of the brush seal along the edge.
- ☐ Drill a **1/16" (1.5 mm)** hole: slow speed, light pressure, with a scrap of tape over the spot to stop the bit wandering.
- ☐ Thread the cord through **from the room side** and tie a **figure-eight stopper knot** on the catio side. Pulling from the room then pulls the knot against the flap. Put a drop of super glue on the knot. (Leave the cord long for now; it's trimmed in Step 10.)

Step 6: Outside sensor box (30 min)

A. Controller box — top view, lid off

Zulkit 80 × 50 × 26 mm (drawn ~5 px per mm)



② Motor cable slot (left end) — feed the plug through before closing


③ Two 7 mm holes in the bottom edge: inside-sensor STEMMA cable + outside 4-core cable

④ Tactile button pokes through a 6 mm hole in the lid; hot-glue it in place

Solder wires straight onto the driver's IN1-4 and +/- pins, then snip the pins short — plug-on jumper housings are too tall for a 26 mm box.

B. Outside sensor box — side section

68 × 58 × 33 mm IP65 box, clear lid facing DOWN



- Mount with the clear lid facing **down** — rain falls onto the solid back of the box, never into the hole.
- Cut a ~10 mm hole in the lid right under the sensor, so it sees out directly (plastic in front of the sensor can cause false readings).
- Cable enters through the box's own gland, with a **drip loop** so water runs off the low point instead of into the box.

- ☐ On the IP65 box's **clear lid**, mark a spot about 1 cm from one edge. Drill a small pilot hole, then open it up to **~10 mm** (step up through the bit sizes). Go slow; the plastic cracks if you rush.
- ☐ Fit one of the box's supplied **cable glands** in a side wall, near the top when the box is mounted (drill to the gland's thread size).
- ☐ Stick the VL53L1X to the **inside of the lid** with a small dab of hot glue or a square of mounting tape. Put the sensor's black window **centred over the hole** and the STEMMA socket facing the gland.
- ☐ Plug the **STEMMA QT** → **male-header** cable into the sensor and feed its header end out through the gland. It's spliced to the long cable in Step 7.

Step 7: Route and build the outside cable (45 min)

- ☐ Decide the cable path from the controller box position → through the acrylic → to the outside box. Cut the **4-core cable** to that length **plus 20 cm**.

☐ **Hole in the acrylic** (skip this if there's a usable gap): drill **~7 mm** near a top corner, away from the flap. Stick masking tape on both faces first, use slow speed and light pressure, and support the panel from behind.

☐ Push the cable through. Seal it on both faces with a bead of **Gorilla clear adhesive**, and leave that to cure (check the tube for the time).

☐ **Splice at the sensor end.** Cut the male pins off the STEMMA cable, strip 5 mm from each of the 8 wire ends, and slide a small piece of heat-shrink onto each wire before joining. Match them up:

STEMMA wire	Signal	4-core wire (typical: check yours and write your mapping here)
red	3V	red → _____
black	GND	black → _____
blue	SDA (data)	white → _____
yellow	SCL (clock)	green → _____

☐ Twist each pair together, solder it, slide the heat-shrink over the joint and shrink it. Then put one larger piece of heat-shrink over all four joints.

☐ Tighten the gland nut and screw the lid on. Mount the box on the **outside face of the acrylic** with heavy-duty Velcro, **clear lid facing down**, so the sensor looks down at the catio shelf. Leave a **drip loop** (a U-bend below the gland) in the cable.

Check: with the multimeter on continuity (beep) mode, test each 4-core wire end-to-end against the colour at the far end. There should be 4 beeps, and no beep between any two different wires.

Step 8: Final controller box (60–90 min)

Now repeat the bench wiring on the **final** QT Py, soldered this time, so it fits in the 26 mm-deep box. See the controller box layout in diagram A above.

☐ **ULN2003 prep:** snip the IN1–IN4 and +/– header pins down to about 3 mm with the jewelry cutters. Plug-on jumper housings are too tall for the box.

☐ Cut 6 lengths of 22 AWG wire, each about 8 cm, using different colours. Solder:

- QT Py **A0 / A1 / A2 / A3** → ULN2003 **IN1 / IN2 / IN3 / IN4**
- QT Py **5V** → ULN2003 **+**
- QT Py **GND** → ULN2003 **–**

☐ Solder the **4-core outside cable** to the QT Py pads:

- red → **3V**

- black → **GND** (sharing the pad with the ULN2003 ground is fine)
 - white → **SDA**
 - green → **SCL**
- ☐ **Button:** drill a 6 mm hole in the lid. Solder two short wires from the button to **TX** and **GND**, push the button through the hole from inside and hot-glue it.
- ☐ **Box holes** (clean them up with a craft knife):
- a USB-C slot in the right end, lined up with the QT Py's port
 - a slot at the left end for the motor cable (feed the motor's plug through from outside, then plug it into the ULN2003)
 - two 7 mm holes in the bottom edge, for the inside sensor's STEMMA cable and the outside 4-core cable
- ☐ Stick both boards to the box floor with small squares of mounting tape (or hot glue), with the QT Py's USB port lined up to its slot.
- ☐ Put a **knot or a zip tie** on the 4-core and motor cables just inside the box, so a tug can't pull on the solder joints.
- ☐ Plug in USB and run the **Step 3 bench checklist again** before closing the lid.

Step 9: Mount on the window (45 min)

- ☐ **Motor:** mount it on the face of the **lower sash's bottom rail**, directly above the flap, with the cord hanging **at least 3 cm in front of the flap housing** (use a wood spacer block if needed; see §6). Fix the two mounting tabs with small wood screws, with the **shaft pointing into the room**, so the pulley turns in a plane parallel to the window and the cord drops straight down from it.
- ☐ **Inside sensor:** stick it with heavy-duty Velcro to the sash rail **about 15 cm left of the flap**, angled so it looks at the part of the shelf where he sits in front of the flap. **It must not see the flap or cord** as the flap swings up (see Step 11's check). Plug in its STEMMA cable.
- ☐ **Controller box:** Velcro it to the rail beside the motor.
- ☐ **Outside box:** Velcro it to the **outside face of the acrylic, beside the flap** (on the same side as the cable hole), lid facing down and aimed at the patio shelf just in front of the flap.
- ☐ **USB cable:** route it along the rail and down the window trim with the Bates clips, to a USB plug in the outlet just right of the window.

Step 10: Connect the cord (10 min)

- ☐ With the flap **closed** and the motor at its home position (just powered on), take the cord from the pulley to the flap. Tie it off so there's **about 2 cm of slack** when the flap hangs straight down.
- ☐ **Push the flap outward by hand** (as OMalley would, going out) as far as it goes. The cord must **not** go tight at any point; if it does, add a bit more slack.

- ☐ Push it **inward** by hand: the cord simply goes slacker.
- ☐ Trim the spare cord, leaving about 3 cm past the knot, and seal the end with a flame.

Step 11: Calibrate and tune (30 min)

- ☐ **Empty-shelf calibration:** with both shelves clear (and OMalley elsewhere), **hold the button for 3 s**. The LED flashes to confirm, and the Serial Monitor shows the learned distances.
- ☐ **Set the open position:** in the Serial Monitor, use the jog commands (`u` = wind in 100 steps, `d` = let out 100 steps) until the flap is open about 60–75°, enough for him to walk under easily. Type `save` to store it.
- ☐ **Short-press the button** a few times and watch full cycles. Check that:
 - the cord winds evenly between the pulley flanges
 - the flap closes fully and the cord goes slack again
 - opening takes about 6–7 s (swap to the 40-tooth pulley, then the 20-tooth, only if the motor struggles or skips)
- ☐ **Critical check:** while the flap is open, the Serial Monitor's `in=` reading must **not** change as the flap moves. If it does, the inside sensor can see the flap, so re-aim it further to the side.
- ☐ **Outside:** sit something cat-sized (a cushion or a bag of rice) on the catio shelf and confirm it opens. Try it again on a rainy day.

Step 12: Introduce OMalley (over a week)

- **Days 1–2:** leave the automatic mode off (`auto off` in the console). Run a few short-press cycles **while he's in the room but not near the flap**, and reward him with treats, so the whirr and the moving flap become boring.
- **Days 3–4:** turn automatic mode on (`auto on`). Stay nearby for his first few trips. If he startles, go back a step.
- **Days 5–7:** it runs on its own. Glance at the serial log or the LED now and then. Tune the 20 s grace, the 0.3 s trigger or the margin if he's getting "caught" or it opens too often.

You're done when he goes out and back in, on his own, several days in a row, and you haven't walked over to hold the flap once. 🐱

8. Troubleshooting

Symptom	Likely cause	Fix
Nothing happens, no LED	No power, or a charge-only cable	Try another USB cable and port; check for 5 V between the QT Py's 5V and GND pads with the multimeter
The ULN2003 LEDs flicker but the motor only buzzes	Motor wires swapped, or IN1–4 in the wrong order	Check A0→IN1 ... A3→IN4 in order
The motor turns the wrong way	The pulley winds the other way on your mounting	Type <code>reverse</code> in the console and <code>save</code>
It opens with nobody there	The empty-shelf calibration is stale (something was moved)	Re-calibrate: hold the button for 3 s with the shelves clear
It stays open far too long	A sensor can see the flap or cord (inside), or a plant or leaf (outside)	Re-aim the sensor; check its <code>in=</code> / <code>out=</code> reading while the flap is open
It opens in heavy rain	The outside box is too exposed	Lengthen the 0.3 s trigger to 0.5 s, or move the box further under the roof
Red flashing LED	A sensor isn't responding	Reseat the STEMMA plug; check the outside cable's continuity (Step 7 check)
The motor skips or stalls near "fully open"	The cord pulls almost along the flap's surface, so there's too little leverage	Reduce the open position a little, increase <code>d</code> , or switch to the 40-tooth (or 20-tooth) pulley
The flap doesn't close fully	The cord is still slightly taut at "home"	Let out a few hundred steps and re-save home (<code>d</code> , then <code>home</code>)
After a power cut the flap is stuck open	It rebooted thinking the flap was closed	In the console, type <code>d</code> repeatedly until the flap is down with about 2 cm of slack, then type <code>home</code> to re-set the home position

9. Maintenance

- **Monthly:** check the cord for fraying or chew marks, and replace it if there are any (there's 100 yards of it). Also wipe both sensor windows with a dry cloth.

- **After storms:** check the outside box for water inside.
- **Yearly:** check the pulley grub screws are still tight.

10. Appendices

Appendix A: Pin map

QT Py pad	Connects to	Notes
A0, A1, A2, A3	ULN2003 IN1, IN2, IN3, IN4	Stepper coils; 3.3 V logic drives the ULN2003 fine
5V	ULN2003 +	USB 5 V passes straight through; the motor draws about 250 mA while moving
GND	ULN2003 –, outside-cable GND, button	One common ground
3V	Outside-cable red (sensor power)	The sensor draws about 20 mA
SDA, SCL	Outside sensor (Arduino <code>Wire</code>)	I ² C bus 0
STEMMA QT socket	Inside sensor (Arduino <code>Wire1</code>)	I ² C bus 1, so both sensors can keep address 0x29
TX	Button → GND	Internal pull-up; reads "pressed" when low
(built-in)	NeoPixel status LED	No wiring

Appendix B: Settings

Setting	Default	What it means
Trigger time	0.3 s	How long a sensor must see something before opening
Trigger margin	50 mm	How much closer than the empty shelf counts as "something"
Grace time	20 s	How long it stays open after both shelves are clear
Max open	2 min	Closes after this long, and ignores that shelf until it clears
Cooldown	3 s	Minimum gap between closing and reopening
Open position	set in Step 11	Motor steps from home to open
Opening speed / closing speed	~15 rpm / ~10 rpm	Closing is slower so the flap lowers gently

Appendix C: Cost summary

	Amount
Adafruit (electronics)	\$77.25 + shipping
Amazon (build parts)	\$67.13
Amazon (starter kit)	\$57.73
Total	≈ \$200 + shipping (before the second item you removed)
Saved by using things you already own	≈ \$95