

# ECE-332:437 DIGITAL SYSTEMS DESIGN (DSD)

Fall 2016 – Lecture 8a Architecture (RISC - MIPS) - Recap

> Nagi Naganathan November 3, 2016

# Introduction

- Jumping up a few levels of abstraction
- **Architecture:** programmer's view of computer
  - Defined by instructions & operand locations
- Microarchitecture: how to implement an architecture in hardware (covered in Chapter 7)

Application Software	pr
Operating Systems	devi
rchitecture	ins re
Micro- rchitecture	da co
Logic	m
Digital Circuits	AN NO
Analog Circuits	ar
Devices	tra
Physics	e

Application Software	programs
Operating Systems	device driver
Architecture	instructions registers
Micro- architecture	datapaths controllers
Logic	adders memories
Digital Circuits	AND gates NOT gates
Analog Circuits	amplifiers filters
Devices	transistors diodes
Physics	electrons

# The Hardware of a Computer

**Control** 


**Datapath** 

Central Processing
Unit (CPU)
or "processor"

Input

**Memory** 

**Output** 



**FIVE EASY PIECES** 


# Computer Architecture

- Architecture: System attributes that have a direct impact on the logical execution of a program
- Architecture is visible to a programmer:
  - Instruction set
  - Data representation
  - I/O mechanisms
  - Memory addressing

# Where Does It All Begin?

- In a register called *program counter (PC)*.
- PC contains the memory address of the next instruction to be executed.
- In the beginning, PC contains the address of the memory location where the program begins.

# Where is the Program?



# Assembly Language

- Instructions: commands in a computer's language
  - Assembly language: human-readable format of instructions
  - Machine language: computer-readable format (1's and 0's)
- MIPS architecture:
  - Developed by John Hennessy and his colleagues at Stanford and in the 1980's.
  - Used in many commercial systems, including Silicon Graphics, Nintendo, and Cisco

Once you've learned one architecture, it's easy to learn others





# Architecture Design Principles

Underlying design principles, as articulated by Hennessy and Patterson:

- 1. Simplicity favors regularity
- 2. Make the common case fast
- 3. Smaller is faster
- 4. Good design demands good compromises




- Instruction Set Architecture
  - the machine behavior as observable and controllable by the programmer
- Instruction Set
  - the set of commands understood by the computer
- Machine Code
  - a collection of instructions encoded in binary format
  - directly consumable by the hardware
- Assembly Code
  - a collection of instructions expressed in "textual"
     format
     e.g. Add r1, r2, r3
  - converted to machine code by an assembler
  - one-to-one correspondence with machine code (mostly true: compound instructions, address labels

....)

# Instruction Set Architecture (ISA)

- A set of assembly language instructions (ISA) provides a link between software and hardware.
- Given an instruction set, software programmers and hardware engineers work more or less independently.
- ISA is designed to extract the most performance out of the available hardware technology.




Software



Hardware


# Instruction Set Architecture (ISA)

- Serves as an interface between software and hardware.
- Provides a mechanism by which the software tells the hardware what should be done.



### What's an ISA?

- ☐ The ISA is the interface between hardware and software.
- ☐ The ISA serves as an abstraction layer between the HW and SW
  - Software doesn't need to know how the processor is implemented
  - Any processor that implements the ISA appears equivalent



- □ An ISA enables processor innovation without changing software
  - This is how Intel has made billions of dollars.
- ☐ Before ISAs, software was re-written for each new machine.

# ISA


- Defines registers
- Defines data transfer modes between registers, memory and I/O
- Types of ISA: RISC, CISC, VLIW, Superscalar
- Examples:
  - IBM370/X86/Pentium/K6 (CISC)
  - PowerPC (Superscalar)
  - Alpha (Superscalar)
  - MIPS (RISC and Superscalar)
  - Sparc (RISC), UltraSparc (Superscalar)

### ISA


and the centrale. (for MIPS) An ISA consists of: arithmetic, logical, a set of operations (instructions) conditional, branch, etc. data units (sized, addressing modes, etc.) ← 32-bit data word • processor state (registers) - 32, 32-bit registers • input and output control (memory operations) ← load and store execution model (program counter)
 ← 32-bit program counter

# MIPS Instruction Set (RISC)

- Instructions execute simple functions.
- Maintain regularity of format each instruction is one word, contains opcode and arguments.
- Minimize memory accesses whenever possible use registers as arguments.
- Three types of instructions:
  - ■Register (R)-type only registers as arguments.
  - Immediate (I)-type arguments are registers and numbers (constants or memory addresses).
  - ■Jump (J)-type argument is an address.



### How are Instructions Executed?



Instruction Fetch:

Read instruction bits from memory

Decode:

Figure out what those bits mean

Operand Fetch:

Read registers (+ mem to get sources)

Execute:

Do the actual operation (e.g., add the #s)

Result Store:

Write result to register or memory

Next Instruction:

Figure out mem addr of next insn, repeat

## MIPS Arithmetic Instructions

- All instructions have 3 operands
- Operand order is fixed (destination first)


### Example:

```
C code: a = b + c;
```

MIPS 'code': add a, b, c

"The natural number of operands for an operation like addition is three... requiring every instruction to have exactly three operands conforms to the philosophy of keeping the hardware simple"

# Executing a MIPS program



- All instructions have
  - <= 1 arithmetic op</p>
  - <= 1 memory access</p>
  - <= 2 register reads</p>
  - <= 1 register write</p>
  - <= 1 branch
- All instructions go through all the steps
- As a result
  - Implementing MIPS is (sort of) easy!
  - The resulting HW is (relatively) simple!

# MIPS Register Set

Name	Register Number	Usage	
\$0	0	the constant value 0	
\$at	1	assembler temporary	
\$v0-\$v1	2-3	Function return values	
\$a0-\$a3	4-7	Function arguments	
\$t0-\$t7	8-15	temporaries	
\$s0-\$s7	16-23	saved variables	
\$t8-\$t9	24-25	more temporaries	
\$k0-\$k1	26-27	OS temporaries	
\$gp	28	global pointer	
\$sp	29	stack pointer	
\$fp	30	frame pointer	
\$ra	31	Function return address	



# To summarize:

### MIPS assembly language

Will 3 assembly language							
Category	Instruction	Example	Meaning	Comments			
	add	add \$s1, \$s2, \$s3	\$s1 = \$s2 + \$s3	Three operands; data in registers			
Arithmetic	subtract	sub \$s1, \$s2, \$s3	\$s1 = \$s2 - \$s3	Three operands; data in registers			
	add immediate	addi \$s1, \$s2, 100	\$s1 = \$s2 + 100	Used to add constants			
	load word	lw \$s1, 100(\$s2)	\$s1 = Memory[\$s2 + 100]	Word from memory to register			
	store word	sw \$s1, 100(\$s2)	Memory[ $$s2 + 100$ ] = $$s1$	Word from register to memory			
Data transfer	load byte	lb \$s1, 100(\$s2)	\$s1 = Memory[\$s2 + 100]	Byte from memory to register			
	store byte	sb \$s1, 100(\$s2)		Byte from register to memory			
	load upper immediate	lui \$s1, 100	\$s1 = 100 * 2 <sup>16</sup>	Loads constant in upper 16 bits			
	branch on equal	beq \$s1, \$s2, 25	if (\$s1 == \$s2) go to PC + 4 + 100	Equal test; PC-relative branch			
Conditional	branch on not equal	bne \$s1, \$s2, 25	if (\$s1 != \$s2) go to PC + 4 + 100	Not equal test; PC-relative			
branch	set on less than		if (\$s2 < \$s3) $$s1 = 1$ ; else $$s1 = 0$	Compare less than; for beq, bne			
	set less than immediate	slti \$s1, \$s2, 100	if ( $$s2 < 100$ ) $$s1 = 1$ ; else $$s1 = 0$	Compare less than constant			
	jump	j 2500	go to 10000	Jump to target address			
Uncondi-	jump register	jr \$ra	go to \$ra	For switch, procedure return			
tional jump	jump and link	jal 2500	\$ra = PC + 4; go to 10000	For procedure call			

# **Instruction Format**

- R-Type: instructions use opcode 000000.
  - This group Contains all instructions that do not require an immediate value, target offset, memory address displacement, or memory address to specify an operand.
  - Includes arithmetic and logic with all operands in registers, shift instructions, and register direct jump instructions (jalr and jr).
- I-Type: Opcodes except 000000, 00001x, and 0100xx
  - This group includes instructions with an immediate operand, branch instructions, and load and store instructions. In the MIPS architecture, all memory accesses are handled by the main processor, so coprocessor load and store instructions are included in this group.
- J-Type: instructions use opcode 00001x.
  - This group consists of the two direct jump instructions (j and jal).
  - These instructions require a memory address to specify their operand.

# Big-Endian & Little-Endian Memory

Little-Endian

**MSB** 

How to number bytes within a word?

Big-Endian

- Little-endian: byte numbers start at the little (least significant) end
- **Big-endian:** byte numbers start at the big (most significant) end
- Word address is the same for big- or little-endian

# Byte Address Address Byte Address Address Address Address C D E F C F E D C 8 9 A B 8 B A 9 8 4 5 6 7 4 7 6 5 4 0 1 2 3 0 3 2 1 0



**MSB** 


**LSB** 

# R-type instruction format

6 bits	5 bits	5 bits	5 bits	5 bits	6 bits	
op	rs	rt	rd	shamt	funct	

- Op + funct: instruction ID
- rs, rt, rd: register operands
  - 5 bits: long enough for register ID number
  - rs, rt: source registers
  - rd: destination register
- Shamt: shift amount (only used for shifts)
  - 5 bits: shift amount always in range 0..31

# R-type examples




# **I-type instruction format**

6 bits	5 bits	5 bits	16 bits
op	rs	rd	immediate

- Op: instruction ID
- rs, rt: register operands
- Immediate: branch target/immediate operand

# I-type example



# J-type instruction format

6 bits 26 bits
Op Target

- Op: instruction ID
- Target: (most of) jump address

# J-type examples

```
j bottom # bottom = 0 \times 00400058
         0000 0000 0100 0000 0000 0000 0101 1000
 000010
                 0000 0100 0000 0000 0000 0101 10
 Op (6)
                          Target (26)
 000011
                 0000 0100 0000 0000 0000 0101 10
                   # f = 0x00400058
jal f
```

# **Control**

- Decision making instructions
  - alter the control flow,
  - i.e., change the "next" instruction to be executed
- MIPS conditional branch instructions:

```
bne $t0, $t1, Label beq $t0, $t1, Label
```

Example: if (i==j) h = i + j;

```
bne $s0, $s1, Label add $s3, $s0, $s1
Label: ....
```

# **Control**

MIPS unconditional branch instructions:

```
j label
```

Example:

```
if (i!=j)
    h=i+j;
else
    h=i-j;
Lab1:sub $s3, $s4, $s5
Lab2:...
beq $s4, $s5, Lab1
add $s3, $s4, $s5

j Lab2
Lab2:...
```

# So far (including J-type instr):

### Instruction

### **Meaning**

```
add \$s1,\$s2,\$s3 \$s1 = \$s2 + \$s3

sub \$s1,\$s2,\$s3 \$s1 = \$s2 - \$s3

lw \$s1,100(\$s2) \$s1 = Memory[\$s2+100]

sw \$s1,100(\$s2) Memory[\$s2+100] = \$s1

beq \$s4,\$s5,L Next instr. is at Label if \$s4 = \$s5

j Label Next instr. is at Label
```

### Formats:

R	op	rs	rt	rd	shamt	funct
I	op	rs	rt	16 bit address		
J	op	26 bit address				

- Write the instruction that loads the word at address 0x00400060 into register \$8. Assume that register \$10 contains 0x00400000
- lw \$8, ?? ,??
- lw \$8, 0x60(\$10)

Copy 0xFF00AA11 into Big Endian and Little Endian