



Software Safety Requirements and Architecture Lane Assistance

Document Version: [Version]

Template Version 1.0, Released on 2017-06-21



Document history

[Instructions: Fill in the date, version and description fields. You can fill out the Editor field with your name if you want to do so. Keep track of your editing as if this were a real world project.

For example, if this were your first draft or first submission, you might say version 1.0. If this is a second submission attempt, then you'd add a second line with a new date and version 2.0]

Date	Version	Editor	Description
06/08/2018	1.0	Banning Lyth	First edits

Table of Contents

[Instructions: We have provided a table of contents. If the table of contents is not showing up correctly in your word processor of choice, please update it. The table of contents should show each section of the document and page numbers or links. Most word processors can do this for you. In Google Docs, you can use headings for each section and then go to Insert > Table of Contents. Microsoft Word has similar capabilities]

Document history

Table of Contents

Purpose

Inputs to the Software Requirements and Architecture Document

Technical safety requirements

Refined Architecture Diagram from the Technical Safety Concept

Purpose

[Instructions: Answer what is the purpose of this document?]

This document aims to identify possible problems with software design or architecture that could lead to violations of safety goals. New requirements are identified at a component level, and requirements are more detail oriented than technical safety requirements.

Inputs to the Software Requirements and Architecture Document

[Instructions:

REQUIRED:

You are only required to develop this document for the LDW (lane departure warning) amplitude malfunction. So here, provide the technical safety requirements for the LDW amplitude malfunction as well as the refined system architecture diagram from the technical safety concept.

OPTIONAL:

Expand this document to include software safety requirements for the LDW frequency malfunction as well. Go even further and document software safety requirements for the Lane Keeping Assistance (LKA) function as well.

Technical safety requirements

Technical Safety Requirements related to Functional Safety Requirement 01-01 are:

ID	Technical Safety Requirement	A S I L	Fault Tolerant Time Interval	Architecture Allocation	Safe State
Technical Safety	The LDW safety component shall ensure that the	С	50 ms	LDW Safety	Lane Departure

Requirement 01-01-01	amplitude of the 'LDW_Torque_Request' sent to the 'Final electronic power steering Torque' component is below 'Max_Torque_Amplitude.'				Warning Torque Request Amplitude shall be set to zero.
Technical Safety Requirement 01-01-02	When the LDW is deactivated, the 'LDW Safety' software module shall send a signal to the Car Display ECU to turn on a warning signal.	С	50 ms	LDW Safety	Lane Departure Warning Torque Request Amplitude shall be set to zero.
Technical Safety Requirement 01-01-03	When a failure is detected by the Lane Departure Warning functionality, it shall deactivate the Lane Departure Warning feature and set 'LDW_Torque_Request' to zero.	С	50 ms	LDW Safety	Lane Departure Warning Torque Request Amplitude shall be set to zero.
Technical Safety Requirement 01-01-04	The validity and integrity of the data transmission for 'LDW_Torque_Request' signal shall be ensured.	С	50 ms	Data Transmission Integrity Check	Lane Departure Warning Torque Request Amplitude shall be set to zero.
Technical Safety Requirement 01-01-05	Memory test shall be conducted at startup of the EPS ECU to check for any memory problems	Α	Ignition cycle	Memory Test	Lane Departure Warning Torque Request Amplitude shall be set to zero.

Refined Architecture Diagram from the Technical Safety Concept

[Instructions:

REQUIRED: Provide the refined system architecture diagram from the technical safety concept




Image taken from Udacity lesson material

Software Requirements

Lane Departure Warning (LDW) Amplitude Malfunction Software Requirements:

[Instructions: Fill in the software safety requirements for the LDW amplitude malfunction technical safety requirements. We have provided the associated technical safety requirements. Hint: The software safety requirements were discussed in the text from the software and hardware lesson.

OPTIONAL:

CHALLENGE ONE

Develop software safety requirements for the Lane Departure Warning (LDW) frequency function and modify the system architecture as needed.

CHALLENGE TWO

Develop software safety requirements for the Lane Keeping Assistance (LKA) function and modify the system architecture as needed.

ID	Technical Safety Requirement	A S I L	Fault Tolerant Time Interval	Allocation to Architecture	Safe State
Technical Safety Requirement 01-01-01	The LDW safety component shall ensure that the amplitude of the LDW_Torque_Request sent to the Final Electronic Power Steering Torque component is below Max_Torque_Amplitude	С	50 ms	LDW safety	Lane Departure Warning Torque Request Amplitude shall be set to zero

ID	Software Safety Requirement	A % _ L	Allocation Software Elements	Safe State
Software Safety Requirement 01-01-01-01	The input signal 'Primary_LDW_Torq_Req' shall be read and pre-processed to determine the torque request coming from the 'Basic/Main LAFunctionality' SW Component. Signal 'processed_LDW_Torq_Req' shall be generated at the end of the processing.	С	LDW_SAFETY_INPUT_P ROCESSING	N/A
Software Safety Requirement 01-01-01-02	In case the 'processed_LDW_Torq_Req' signal has a value greater than 'Max_Torque_Amplitude_LDW' (maximum allowed safe torque), the torque signal 'limited_LDW_Torq_Req' shall be set to zero, else 'limited_LDW_Torq_Req' shall take the value of	O	TORQUE_LIMITER	'limited_LDW_T orq_Req' = 0 (Nm=Newton- meter)

	'processed_LDW_Torq_Req'			
Software Safety Requirement 01-01-03	The 'limited_LDW_Torq_Req' shall be transformed into a signal 'LDW_Torq_Req' which is suitable to be transmitted outside the LDW Safety component ('LDW Safety') to the 'Final EPS Torque' component.	O	LDW_SAFETY_OUTPUT _GENERATOR	LDW_Torq_Req = 0 (Nm)

ID	Technical Safety Requirement	A S I L	Fault Tolerant Time Interval	Allocation to Architecture	Safe State
Technical Safety Requirement 01-01-02	When the LDW is deactivated, the 'LDW Safety' software module shall send a signal to the Car Display ECU to turn on a warning signal.	С	50 ms	LDW safety	Lane Departure Warning Torque output shall be set to zero.

ID	Software Safety Requirement	A S I L	Allocation Software Elements	Safe State
Software Safety Requirement 01-01-02-01	When the LDW function is deactivated (activation_status set to 0), the activation_status shall be sent to the car displayECU.	С	LDW safety, car display ECU	N/A

ID	Technical Safety Requirement	A S I L	Fault Tolerant Time Interval	Allocation to Architecture	Safe State
Technical Safety Requirement 01-01-03	As soon as a failure is detected by the LDW function, it shall deactivate the LDW feature and the LDW_Torque_Request shall be set to zero		50 ms	LDW safety	Lane Departure Warning Torque Request Amplitude shall be set to zero.

ID	Software Safety Requirement	ASIL	Allocation Software Elements	Safe State
Software Safety Requirement 01-01-03-01	Each of the SW elements shall output a signal to indicate any error which is detected by the element. Error signal = error_status_input(LDW_SAFET Y_INPUT_PROCESSING), error_status_torque_limiter(TOR QUE_LIMITER), error_status_output_gen(LDW_SAFETY_OUTPUT_GENERAT OR)	С	All	N/A
Software Safety Requirement 01-01-03-02	A software element shall evaluate the error status of all the other software elements and in case any 1 of them indicates an error, it shall deactivate the LDW feature ("activation_status"=0)	С	LDW_SAFETY _ACTIVATION	Activation_status = 0 (LDW function deactivated)
Software Safety	A software element shall evaluate the error status of all	С	LDW_SAFETY _ACTIVATION	N/A

Requirement 01-01-03-03	the other software elements and in case any 1 of them indicates an error, it shall deactivate the LDW feature ("activation_status"=0)			
Software Safety Requirement 01-01-03-04	In case an error is detected by any of the software elements, it shall set the value of its corresponding torque to 0 so that "LDW_Torq_Req" is set to 0	С	All	LDW_Torq_Req = 0
Software Safety Requirement 01-01-03-05	Once the LDW functionality has been deactivated, it shall stay deactivated till the time the ignition is switched from off to on again.	С	LDW_SAFETY _ACTIVATION	Activation_status = 0 (LDW function deactivated)

ID	Technical Safety Requirement	A S I L	Fault Tolerant Time Interval	Allocation to Architecture	Safe State
Technical Safety Requirement 01-01-04	The validity and integrity of the data transmission for 'LDW_Torque_Request' signal shall be ensured.	С	50 ms	Data transmission integrity	N/A

ID	Software Safety Requirement	A S I L	Allocation Software Elements	Safe State
Software Safety Requirement 01-01-04-01	Any data to be transmitted outside of the LDW Safety component ("LDW Safety") including "LDW_Torque_Req" and "activation_status" (see SofSafReq03-02) shall be protected by an End2End(E2E) protection mechanism	С	E2ECalc	LDW_Torq_Req= 0 (Nm)
Software Safety Requirement 01-01-04-02	The E2E protection protocol shall contain and attach the control data: alive counter (SQC) and CRC to the data to be transmitted.	С	E2ECalc	LDW_Torq_Req = 0 (Nm)

ID	Technical Safety Requirement	A S I L	Fault Tolerant Time Interval	Allocation to Architecture	Safe State
Technical Safety Requirement 01-01-05	Memory test shall be conducted at start-up of the EPS ECU to check for any faults in memory	Α	Ignition cycle	Memory check	Lane Departure Warning Torque Request Amplitude shall be set to zero.

ID	Software Safety Requirement	A S I L	Allocation Software Elements	Safe State
Technical Safety Requirement 01-01-05-01	A CRC verification check over the software code in the Flash memory shall be done every time the ignition is switched from off to on to check for any corruption of content.	Α	Memory test	Activation_status = 0
Technical Safety Requirement 01-01-05-02	Standard RAM tests to check the data bus, address bus and device integrity shall be done every time the ignition is switched from off to on (E.g.walking 1s test, RAM pattern test. Refer RAM and processor vendor recommendations)	Α	Memory test	Activation_status = 0
Technical Safety Requirement 01-01-05-03	The test result of the RAM or Flash memory shall be indicated to the LDW_Safety component via the "test_status" signal	Α	Memory test	Activation_status = 0
Technical Safety	In case any fault is indicated via the "test_status" signal the	Α	LDW safety	Activation_status = 0

Requirement 01-01-05-04 INPUT_LDW_PROCESSING shall set an error on error_status_input (=1) so that the LDW functionality is deactivated and the LDWTorque is set to 0	
---	--

Refined Architecture Diagram

[Instructions: Include the refined system architecture. Hint: The refined system architecture should include the system architecture from the end of the software and hardware lesson, including all of the ASIL labels.]




Image taken from Udacity lesson material