
Aquatech User Guide

Virtual aquarium • 1.8" AMOLED touchscreen • the game runs in real time

1 The aquarium



① **Tap the top of the screen**: drops a dose of food (5 flakes, €0.05).
② **Tap a fish**: opens its card. Tap a decoration: offers to sell it.
③ Round button: **menu**. ④ Shop icon: **shop**.
⑤ **Swipe a finger** across the screen: the sponge wipes off algae.

2 The shop



①② **Tabs**: fish (3 pages) or decorations. ③ Your balance.
④ **Tap a fish** to buy it: it appears in the aquarium (greyed price = too expensive).
⑤ Arrows: next / previous page. ⑥ Red cross: close.
Decoration: tap “Buy”, drag it into place, confirm with OK.

3 A fish's card



① **Age** (heart) against its lifespan. ② **Hunger**: green = full, red = starving.
③ Current **resale value**. ④ **“Sell”** (asks to confirm); “Remove” for a skeleton.
⑤ Previous / next fish. ⑥ Red cross: back.

4 The menu



① **“New”**: starts over (asks to confirm). ② **“Save”**: manual save.
③ **Speaker**: sound on / off. ④ **Flag**: **language**, FR → EN → ES in a loop.
⑤ **Battery**: % and voltage; yellow outline while charging. ⑥ **Brightness** slider. ⑦ Red cross: back.

Main game mechanics

Economy

Start: **€10.00**. Income: **+€2.00 per day**, paid during sleep or power-off too (elapsed time is caught up at power-on).

One dose of food: €0.05.

Decorations: Chest and Helmet €6 • Plant €9 • Coral €12 • Rock €21 • Rocks €45 • Full set €60.

Selling an animal: **80 %** of its new price, falling daily to 0 at end of life. Limits: 20 animals, 12 decorations.

The animals

16 species: 10 fish, the Pufferfish, the Jellyfish, the Seahorse, the Crayfish, the Snail and the Axolotl. Price, lifespan and behaviour: **page 2**.

Fish swim freely and dash for the flakes when hungry.

The **Crayfish** and the **Axolotl** walk on the sand and only eat flakes that reached the bottom.

The **Snail** climbs the glass and the **Jellyfish** drifts: they eat the flakes that touch them.

The **Pufferfish** inflates when scared (page 2).

Hunger and life

Young animals (first **8 %** of their life) are shown at half size.

Hunger climbs to its maximum in **3 days**. From 30 % an animal heads for the nearest flake; each flake eaten feeds it.

Uneaten flakes stay on the bottom for 12 h, then vanish.

After **36 h** at maximum hunger an animal starves. It also dies of old age at the end of its lifespan. It turns into a **skeleton** to remove from its card.

Algae

A green film builds up gradually (about 17 new patches a day) and spreads outward from its edges.

By hand: **swipe a finger** to wipe it off.

The **Black molly** and the **Blue tang** graze on it as they swim, the **Snail** as it climbs the glass. Two grazers clean nearly everything, one leaves some. Grazing feeds them slightly.

A heavily overgrown tank looks bad, but only hunger or age kills an animal.

Power and saving: **PWR** button — short press = sleep / wake, long press = full power-off. The game saves itself every 5 minutes and after every purchase or sale; sound, brightness and language are remembered. The board's clock keeps time, so animals, hunger and algae keep evolving while off.

5 The animals

In shop order (3 pages). Purchase price and maximum lifespan.



Betta — €5.00 • 30 d

Swims freely, medium pace. Big fish: scares the Pufferfish.



Black molly — €2.50 • 24 d

Swims freely, fast. Grazes on algae.



Blue tang — €7.00 • 50 d

Swims freely, medium pace. Grazes on algae. Big eater. Big fish: scares the Pufferfish.




Clown — €3.00 • 34 d

Swims freely, fast.



Corydoras — €3.50 • 40 d

Swims freely, very fast.



Discus — €9.00 • 60 d

Swims freely, slow. Big eater. Big fish: scares the Pufferfish.



Guppy — €1.50 • 14 d

Swims freely, fast.



Loach — €4.00 • 44 d

Swims freely, fast. Big fish: scares the Pufferfish.



Neon — €1.00 • 20 d

Swims freely, very fast.



Oscar — €8.00 • 56 d

Swims freely, slow. Big eater. Big fish: scares the Pufferfish.




Pufferfish — €7.00 • 30 d

Swims slowly. Inflates when scared (see below).



Jellyfish — €5.00 • 20 d

Pulses to rise, then sinks back, drifting. Does not chase food: eats the flakes that touch it.




Seahorse — €8.00 • 25 d

Swims upright, very slowly, and stays near the decorations. Goes for flakes when hungry.



Crayfish — €4.00 • 40 d

Walks on the sand. Only eats flakes that reached the bottom.



Snail — €3.00 • 60 d

Climbs the glass (left, top, right). Grazes on algae and eats the flakes that touch it.



Axolotl — €6.00 • 50 d

Walks on the sand, faster than the Crayfish. Only eats flakes that reached the bottom.

The Pufferfish inflates for 4 seconds when a big adult fish comes close, when you touch the water near it, or when you touch its picture on its card. While inflated it rises slowly and does not eat. It then stays calm for at least 20 seconds before inflating again on its own; from its card, it inflates every time.

Young animals: every animal you buy is first shown at half size, for the first 8 percent of its life. It is then a little harder to tap.