[FAQ14128]L版本如何关闭默认加密

[DESCRIPTION]

L版本手机默认加密,那如何关闭默认加密呢?

[SOLUTION]

关闭加密功能有两种情况:

- 1 How to disable default encryption in your own image
- (1) Modify fstab. {ro.hardware} in 'out' folder

alps\out\target\product\[project]\root\ fstab. {ro. hardware}

Set the flag back to encryptable for /data

```
# Android fstab file.
#Ksrc> \lamt_point\ \tag{type} \lamt_flags and options\ #The filesystem that contains the filesystem checker binary (typically /system) cannot # specify MF_CHECK, and must come before any filesystems that do specify MF_CHECK
 /dev/block/platform/mtk-msdc.8/by-name/system
                                                                            /system
                                                                                                            oatine, nMG, dia, Tokkda_alloc, discard
                                                                                                          noatime, nosuid, nodev, noauto_da_alloc, discard
noatime, nosuid, nodev, noauto_da_alloc, commit=1, nodelalloc
noatime, nosuid, nodev, noauto_da_alloc, commit=1, nodelalloc
 /dev/block/platform/mtk-msdc.8/by-name/cache
                                                                            /cache
                                                                                                ext4
                                                                                                                                                                                                     wait, check
                                                                            /protect f ext4
 /dev/block/platform/mtk-msdc.0/by-name/protect1
                                                                                                                                                                                                     wait, check, autoformat
 /dev/block/platform/mtk-msdc.0/by-name/protect2
                                                                            /protect_s
                                                                                                                                                                                                     wait, check, autoformat
```

(2) Re-pack boot.img

make ramdisk-nodeps; make bootimage-nodpes

- (3) Download the new boot, img by flashtool
- 2 How to disable default encryption in your codebase
- a) Modify fstab. {ro. hardware} in your codebase

device\mediatek\ [project]\ fstab. {ro. hardware}

If the project doesn't have it own fstab. {ro.hardware}. Please create it

Modify device. mk to use the modified fstab. {ro. hardware}.

```
# PRODUCT_COPY_FILES overwrite
# Please add flavor project's PRODUCT_COPY_FILES here.
# It will overwrite base project's PRODUCT_COPY_FILES.
PRODUCT_COPY_FILES += device/mediatek/%[DTK_TARSET_PROJECT]/fstab.mt6582:root/fstab.mt6582
```

Set the flag back to encryptable for /data

```
# Android fstab file.
## Android fstab file.
# Android file.
# Android fstab file.
# Android fstab file.
# Android fstab file.
# Android file.
# Android
```

b) Re-build boot.img

make bootimage

c) Download the new boot.img by flashtool