Instruction Manual for Health Drink Mix Making Machine

Product Overview

The Health Drink Mix Making Machine is a specialized appliance designed to quickly and efficiently blend health drink mix with liquids. With easy-to-use controls and advanced blending technology, this machine ensures a smooth and consistent mixture every time.

Components:

- **Main Unit**: The body of the machine with a motor.
- Mixing Bowl: A detachable bowl where ingredients are placed for blending.
- **Blender Blade**: A high-speed blade for mixing and dissolving the drink powder.
- Control Panel: Includes settings for speed, mixing time, and preset options for different types of health drink mixes.
- Measuring Cup: To help measure the correct amount of powder and liquid for each mix.

Setup Instructions:

1. Unbox the Machine:

 Carefully remove the Health Drink Mix Making Machine and all components from the packaging. Ensure that all parts (main unit, mixing bowl, blade, control panel) are intact.

2. Place the Machine on a Stable Surface:

o Ensure the machine is on a dry, stable surface such as a countertop or table.

3. Install the Mixing Bowl:

o Place the mixing bowl onto the base unit and twist it to lock it securely in place.

4. Insert the Blade:

o Attach the blade to the base of the mixing bowl. Make sure it is firmly in place before use.

Operating Instructions:

1. Step 1: Measure Ingredients

 Use the provided measuring cup to measure 1 scoop (30g) of health drink mix and pour it into the mixing bowl.

2. Step 2: Add Liquid

o Add **200-250ml** of your preferred liquid (water, milk, or juice) into the mixing bowl. Ensure the liquid level does not exceed the **MAX line** inside the bowl.

3. Step 3: Choose a Program

- o **Standard Mix**: Press the **"Standard" button** for a basic blend. This setting is ideal for most health drink mixes and will blend for **20 seconds**.
- Extra Smooth: Press the "Smooth" button for a creamier and finer consistency, blending for 30 seconds.
- Quick Blend: Press the "Quick" button for a faster blend, lasting only 15 seconds for light mixing.

4. Step 4: Start the Machine

o Press the "Start" button to begin blending. The machine will automatically stop once the preset time has been completed.

5. Step 5: Pour and Serve

o After blending, carefully remove the mixing bowl and pour the drink into your glass or bottle.

Cleaning Instructions:

1. Step 1: Turn Off the Machine

o Always turn off the machine and unplug it from the power source before cleaning.

2. Step 2: Remove the Mixing Bowl

o Detach the mixing bowl from the base unit.

3. Step 3: Clean the Components

- o Rinse the mixing bowl and blender blade under warm water. Use mild soap and a soft sponge to clean all parts.
- o If needed, use a cleaning brush to remove any residue from the blade.

4. Step 4: Dry and Store

o Wipe the machine's exterior with a damp cloth. Ensure that all parts are completely dry before reassembling or storing the machine.

Troubleshooting:

• Machine Won't Start:

 Ensure the machine is plugged in properly. Check if the mixing bowl is securely locked in place.

• Inconsistent Mixing:

 Make sure the correct amount of liquid and powder are used. If the mix is too thick, add more liquid. If too thin, reduce the liquid.

• Loud Noise or Vibration:

• Check the machine for any loose components. Ensure that the blade is securely attached to the mixing bowl.

Safety Precautions:

- Always use the machine on a flat, stable surface.
- Never immerse the main unit in water.
- Keep fingers and utensils away from the blender blade while in operation.
- Do not overload the mixing bowl with too many ingredients.
- Do not operate the machine for more than **2 minutes** continuously; allow it to cool down between uses.

Warranty Information:

This product comes with a **1-year warranty** covering manufacturing defects. For repairs or replacements, please contact customer service at [company email] or call [company phone number].