


1. Types of Printers, Scanners and Webcams

Device	Type	Real-life Use Case
Printer	Inkjet Printer	Printing college assignments and color photos
Printer	Laser Printer	Printing documents quickly in an office
Printer	Dot Matrix Printe	Printing bills and multi-copy forms
Scanner	Flatbed Scanner	Scanning documents and certificates
Scanner	Handheld Scanner	Scanning small documents or barcodes
Webcam	USB Webcam	Online classes and video meetings
Webcam	Built-in Webcam	Video calls using a laptop

2. Printer Connection Diagram





Printed Paper

Connection interfaces: USB, Wi-Fi, or Bluetooth can be used depending on the printer model.

3. Connection Interfaces

Interface	Advantage	Disadvantage
USB	Fast and reliable connection	Requires a cable
Wi-Fi	Wireless and convenient; multiple devices can connect	Requires a Wi-Fi network and setup
Bluetooth	Easy short-range wireless connection	Limited range and generally slower than USB

4. Connecting a USB Printer to a Computer

Device: USB Printer

Steps:

1. Place the printer near the computer and connect it to a power source.
2. Turn on the printer.

3. Connect the printer to the computer using a USB cable.
4. The computer may automatically detect the printer.
5. Install the printer driver if it is required.
6. Open Settings → Printers & Scanners on the computer.
7. Select Add Device/Printer.
8. Select the connected printer.
9. Set it as the default printer if required.
10. Print a test page to check whether the printer is working properly.