

Analytics & Alert Logic

1. Main Objective of Analytics & Alert Logic

The **main objective** of Analytics & Alert Logic is to:

Convert raw data into meaningful insights and timely alerts to enable fast, accurate decisions.

In simple words:

- **Analytics** → Understand *what is happening and why*
- **Alert Logic** → Notify *when immediate action is required*

Key objectives:

- Detect abnormal conditions early (faults, overheating, failures)
 - Reduce manual monitoring
 - Enable proactive and predictive actions
 - Improve system safety, reliability, and performance
 - Support real-time decision making (Edge or Cloud)
-

2. Advantages of Analytics & Alert Logic

1. Early Fault Detection

- Identifies issues **before failure happens**
- Example: Battery temperature rising beyond safe limit

2. Real-Time Response

- Alerts trigger **immediate action**

- Useful in safety-critical systems (vehicles, IoT, industrial systems)

3. Reduced Downtime

- Prevents sudden breakdowns
- Enables planned maintenance instead of emergency repair


4. Improved Safety

- Alerts protect users, equipment, and environment
- Example: Over-voltage, over-temperature alerts

5. Better Decision Making

- Data-driven insights instead of assumptions
- Helps engineers, operators, and management

This is work flow



Step 1: Sensor Data Collection

First, a **temperature sensor connected to the ESP32** continuously measures the battery or ambient temperature.

These readings are generated in **real time** as raw sensor data.

Step 2: Threshold Defined at the Edge

Inside the ESP32, a **temperature threshold of 28 °C** is already defined.

This is important because it means the **decision logic runs locally on the device**, instead of sending all data to the cloud for processing.

Step 3: Data Filtering

Now, the ESP32 performs **analytics** by filtering the data:

- **If the temperature is below 28 °C**, the data is simply ignored.
No alert is generated and no data is sent to the cloud.
This helps reduce **network usage and cloud cost**.
- **If the temperature exceeds 28 °C**, the edge device detects a **threshold violation**.
It generates an **alert flag**, increments a **violation counter**, and prepares only this important information for transmission.

So instead of sending continuous raw data, only **meaningful events** are selected.

Step 4: Data Sent to Cloud (Firebase)

Using **Wi-Fi**, the ESP32 sends only the alert-related data to the **Firebase Realtime Database**.
The cloud stores:

- Alert flag
- Current temperature
- Threshold exceed count

This ensures the cloud receives **filtered and relevant data only**.

Step 5: Continuous Monitoring by Cluster

The **instrument cluster (OKT507-C)** continuously monitors the alert flag and exceeds count from Firebase in real time.

Step 6: Decision Logic at Cluster Side

To avoid false alarms, the cluster applies its own logic:

If the temperature **exceeds 28 °C more than three times**, only then a service warning is triggered.

This prevents alerts caused by short or temporary temperature spikes.

Step 7: Driver Alert Display

Once the condition is met, the cluster displays the message:

“Service Required: Battery Temperature High.”

This informs the driver at the **right time**, helping prevent battery damage and improving vehicle safety.

Arduino Code

```
#include <Arduino.h>
#include <WiFi.h>
#include <OneWire.h>
#include <DallasTemperature.h>
#include <Firebase_ESP_Client.h>

#include "addons/TokenHelper.h"
#include "addons/RTDBHelper.h"

/* ===== WiFi Credentials ===== */
#define WIFI_SSID      "iSprout-NRE"
#define WIFI_PASSWORD   "Isprout@n-202$"

/* ===== Firebase Credentials ===== */
#define API_KEY        "AIzaSyCR_FwvqqMGctW9i6MNn4ZUAGculjxPAqQ"
#define DATABASE_URL    "https://edge-data-filtering-default-rtdb.firebaseio.com/"
#define USER_EMAIL      "tejaswini.kopperla@votarytech.com"
#define USER_PASSWORD   "Votarytech@2025"

/* ===== Temperature Sensor ===== */
#define ONE_WIRE_BUS    15
#define TEMP_THRESHOLD  28.0

/* ===== Objects ===== */
OneWire oneWire(ONE_WIRE_BUS);
DallasTemperature sensors(&oneWire);

FirebaseData fbdo;
```

```
FirebaseAuth auth;
FirebaseConfig config;

/* ===== Timing ===== */
unsigned long lastSend = 0;
const unsigned long interval = 5000;

/* ===== Analytics Tracking ===== */
int highTempCount = 0;
bool wasAboveThreshold = false;

/* ===== SETUP ===== */
void setup() {
  Serial.begin(115200);
  delay(1000);

  /* Temperature Sensor */
  sensors.begin();
  Serial.println("DS18B20 Initialized");

  /* WiFi */
  WiFi.begin(WIFI_SSID, WIFI_PASSWORD);
  Serial.print("Connecting to WiFi");
  while (WiFi.status() != WL_CONNECTED) {
    delay(500);
    Serial.print(".");
  }
  Serial.println("\nWiFi Connected");
  Serial.print("IP Address: ");
  Serial.println(WiFi.localIP());

  /* Firebase */
  config.api_key = API_KEY;
  config.database_url = DATABASE_URL;

  auth.user.email = USER_EMAIL;
  auth.user.password = USER_PASSWORD;

  Firebase.begin(&config, &auth);
  Firebase.reconnectWiFi(true);

  Serial.println("Firebase Connected");
}

/* ===== LOOP ===== */
void loop() {
```

```

if (millis() - lastSend >= interval) {
    lastSend = millis();

    /* ===== Read Temperature ===== */
    sensors.requestTemperatures();
    float temperatureC = sensors.getTempCByIndex(0);

    if (temperatureC == DEVICE_DISCONNECTED_C) {
        Serial.println(" DS18B20 not detected");
        return;
    }

    Serial.print("Temperature: ");
    Serial.print(temperatureC);
    Serial.println(" °C");

    /* ===== EDGE ANALYTICS ===== */
    bool isAboveThreshold = (temperatureC > TEMP_THRESHOLD);

    // Rising-edge detection (Normal → High)
    if (isAboveThreshold && !wasAboveThreshold) {
        highTempCount++;
        Serial.print("⚠️ High Temp Event Count: ");
        Serial.println(highTempCount);
    }

    wasAboveThreshold = isAboveThreshold;

    /* ===== Firebase Analytics ===== */
    Firebase.RTDB.setFloat(&fbdo, "/analytics/temperature/value", temperatureC);
    Firebase.RTDB.setInt(&fbdo, "/analytics/temperature/event_count", highTempCount);
    Firebase.RTDB.setBool(&fbdo, "/alerts/high_temp/status", isAboveThreshold);

    /* ===== Alert Messages ===== */
    if (isAboveThreshold) {

        Firebase.RTDB.setFloat(&fbdo, "/alerts/high_temp/value", temperatureC);

        if (highTempCount >= 3) {
            Firebase.RTDB.setString(
                &fbdo,
                "/alerts/high_temp/msg",
                "Service Required: Battery Temperature High"
            );
        } else {
    
```

```

        Firebase.RTDB.setString(
            &fbdo,
            "/alerts/high_temp/msg",
            "Temperature crossed 28C"
        );
    }

} else {
    Firebase.RTDB.setString(
        &fbdo,
        "/alerts/high_temp/msg",
        "Temperature Normal"
    );
}
}
}
}

```

Conclusion: Analytics & Alert Logic

Analytics & Alert Logic plays a **critical role in turning raw sensor data into actionable insights and timely alerts**, enabling faster and smarter decision-making. By processing data at the edge and applying intelligent thresholds, it **reduces unnecessary data transfer, avoids false alarms, and ensures only meaningful events are communicated**.

The workflow—from **sensor data collection** → **edge threshold checking** → **filtered cloud transmission** → **cluster-side decision** → **driver alert**—demonstrates a **real-time, efficient, and scalable system** that improves safety, reliability, and performance.

Implementing this logic using platforms like **ESP32 with Firebase** shows how **IoT edge devices can handle analytics locally**, while the cloud supports monitoring and alert management. Overall, Analytics & Alert Logic **enables proactive maintenance, prevents failures, and enhances user safety**, making it an indispensable component in modern connected systems such as vehicles and industrial IoT.