




Bank 1 decay: 4700-4800 MHz




Bank 1 decay: 4800-4900 MHz




Bank 1 decay: 4900-5000 MHz




Bank 1 decay: 5000-5100 MHz




Bank 1 decay: 5100-5200 MHz




Bank 1 decay: 5200-5300 MHz




Bank 1 decay: 5300-5400 MHz




Bank 1 decay: 5400-5500 MHz




Bank 1 decay: 5500-5600 MHz




Bank 1 decay: 5600-5700 MHz




Bank 1 decay: 5700-5800 MHz




Bank 1 decay: 5800-5900 MHz



Bank 1 decay: 5900-6000 MHz



Bank 1 decay: 6000-6100 MHz



Bank 1 decay: 6100-6180 MHz

