




Bank 1 decay: 4720-4820 MHz




Bank 1 decay: 4820-4920 MHz




Bank 1 decay: 4920-5020 MHz




Bank 1 decay: 5020-5120 MHz




Bank 1 decay: 5120-5220 MHz




Bank 1 decay: 5220-5320 MHz




Bank 1 decay: 5320-5420 MHz




Bank 1 decay: 5420-5520 MHz




Bank 1 decay: 5520-5620 MHz




Bank 1 decay: 5620-5720 MHz




Bank 1 decay: 5720-5820 MHz




Bank 1 decay: 5820-5920 MHz



Bank 1 decay: 5920-6020 MHz



Bank 1 decay: 6020-6120 MHz



Bank 1 decay: 6120-6180 MHz

