Oxygen sensors in AquaResp

Pyroscience examples by Morten Bo

Pyroscience Firesting Firmware >4


For the latest firmware for Firestings, you need to use AquaOxyLog to communicate oxygen measurements to Aquaresp.

This is easily done by added the path of the AquaResp oxygen folder to OxyLog settings.

See next slide for images and arrows.

When settings are done. Start OxyLog, then Aquaresp.

OxyLog and AquaResp communication




Move or copy Settings.txt to OxyLog Directory and REPLACE previous


Note

Active channels in OxyLog should match that of AquaResp

Settings can be change via the bat file, but also using the html file in ../settinggui the settings file should be named "settings.txt" for OxyLog to find it

On starting OxyLog







2 active channels should give 1.aqua and 2.aqua The format is just a text file. Open in notepad to see contents if you are interested


Open AquaResp

Open AquaResp. The default choice for a new installation is Firesting New but go to experimental settings. Make sure **Firesting New** is chosen.



Check that measurements are live in AquaResp





are refreshed every 5s. But sampled approx

1s

Firmware < 4 (per nov 2021)

1 Choose Firesting ... (OLD)

2 Open Firesting SW and make it save to AquaResp

3/oxygen/firesting.txt

3 Check that AquaResp measurements are live

